


# BA688CF-F FOUNDATION™ fieldbus Panel mounting display

Issue: 12

For revision 3 instruments with  
revision 4.03 firmware



## CONTENTS

### 1. Description

- 1.1 Documentation
- 1.2 Version 2.3 firmware

### 2. Operation

- 2.1 Controls

### 3. System Design

- 3.1 External switches
- 3.2 Alarm outputs

### 4. Installation

- 4.1 Location
- 4.2 Installation procedure
- 4.3 EMC

### 5. Display & Alarm Configuration

- 5.1 Display transducer block
- 5.2 Screen selection and alarm configuration.
- 5.3 Default configuration
- 5.4 Accessing instrument configuration menu.
- 5.5 Screen selection
  
- 5.6 Alarm configuration
  - 5.6.1 Alarm summary
  - 5.6.2 Alarm activation
  - 5.6.3 Alarm output
  
- 5.7 Display configuration
  - 5.7.1 Settings
  - 5.7.2 Quick access
  - 5.7.3 Access code
  - 5.7.4 Status text
  - 5.7.5 Last input
  - 5.7.6 Keys
  - 5.7.7 Code
  - 5.7.8 Unit info
  - 5.7.9 Defaults
  - 5.7.10 Display defaults
  - 5.7.11 Interface board defaults
  
- 5.8 Quick access menu

### 6. Maintenance

- 6.1 Fault finding during commissioning
- 6.2 Fault finding after commissioning
- 6.3 Servicing
- 6.4 Routine maintenance
- 6.5 Guarantee
- 6.6 Customer comments

### 7. Accessories

- 7.1 Tag number
- 7.2 FOUNDATION™ fieldbus Interface Guide.

The BA688CF-F is CE marked to show compliance with the European EMC Directive 2014/30/EU. It is also UKCA marked to show compliance with UK Electromagnetic Compatibility Regulations UKSI 2016:1091 (as amended)

## 1. DESCRIPTION

The BA688CF-F FOUNDATION™ fieldbus display is a panel mounting instrument that can display up to eight fieldbus process variables, together with their units of measurement and tag information. The instrument is bus powered so no additional power supply is required.

The instrument's communication protocol is shown on the rear panel. The '-F' order code suffix also indicates the protocol but is not shown on the instrument identification label. There is an alternative version of the fieldbus display, order code BA688CF-P for use on PROFIBUS PA networks.

This instruction manual describes revision 3 BA688CF-F Foundation fieldbus displays which were introduced in January 2019. Revision 3 displays have been verified in the FieldComm Labs as compliant with ITK 6.3.

Instruction manuals for the earlier revision 1 and 2 instruments may be downloaded from the superseded documentation section of the BEKA website.

Most of the BA688CF-F display parameters are configured on-site via the fieldbus. Screen format selection and alarm configuration is performed using an internal menu and the instrument's front panel push buttons.

Up to eight process variables can be displayed using the two Input Selector function blocks.

The required Device Description files, which may be downloaded from either the FieldComm or the BEKA websites, depend upon which BA688CF-F FOUNDATION™ fieldbus display revision is selected.

Eleven selectable standard display screen formats enable one, two, three, four or eight process variables, some with bargraphs to be displayed on one screen.

The BA688CF-F FOUNDATION™ fieldbus display can be supplied with six optional alarm outputs that may be linked to any of the displayed fieldbus variables. These alarm outputs are locally activated from the fieldbus variables and are configured via the instrument menu and push buttons. They can not be controlled via the fieldbus.

Housed in a robust 72 x 144 panel mounting DIN enclosure, the BA688CF-F FOUNDATION™ fieldbus display has an IP66 front panel and is supplied with a gasket to seal the joint between the instrument and the panel.

## 1.1 Documentation

This instruction manual describes system design, conditioning and installation of the BA688CF-F FOUNDATION™ fieldbus display. For detailed commissioning information please refer to the FOUNDATION™ fieldbus Interface Guide that can be downloaded from the BEKA website [www.beka.co.uk](http://www.beka.co.uk)

## 1.2 Version 4.03 Firmware

Updated firmware was released in January 2019 which includes the following key features:

- 11 standard screens

- Multiple bargraph limits

- Individual input scaling

- Two 4-input Input Selector function blocks:

- Last variable parameter prevents display of unused inputs.

- Fieldbus compliance verified to ITK 6.3

- Option added to remove status text from single variable screens.

The instrument's firmware version can be established using the 'Unit Info' function in the main configuration menu – see section 5.7.8 of this manual.

## 2. OPERATION

Fig 1 shows a simplified block diagram of the BA688CF-F FOUNDATION™ fieldbus display. When the optional alarms are not fitted, the instrument only requires a two-wire connection to the fieldbus.

Parameters that can not be configured via the fieldbus can be configured via the four front panel push buttons. Menus enable the required standard display screen format to be selected.

The optional alarms are locally activated from the fieldbus variable and can only be configured and the setpoints adjusted using the BA688CF-F push buttons. The alarms can not be configured or controlled via the fieldbus.

Device Description files for the BA688CF-F FOUNDATION™ fieldbus display may be downloaded from either the Fieldbus Foundation or from the BEKA associates websites.




Fig 1 Simplified block diagram of BA688CF-F

## 2.1 Controls

The user can scroll through the display screens by operating the ▼ or ▲ push buttons. The number of screens available depends upon how the BA688CF-F display has been configured. If one fieldbus variable per screen has been configured, eight screens will be present; if four fieldbus variables per screen have been configured, only two screens will be available.

Irrespective of the number of fieldbus variables assigned to the BA688CF-F, the instrument always has provision for displaying eight variables. Unassigned inputs are displayed as zero with a bad data warning i.e. light digits on a dark background. The Last Input parameter allows unused inputs to be skipped when scrolling through the instrument display screens, see section 5.7.5.

If enabled, operating the **P** and ▲ push buttons simultaneously activates the Quick Access Menu, allowing the user to adjust the display contrast without providing access to any of the other configuration parameters. Additional security may be provided by an optional access code.

### 3. SYSTEM DESIGN

The BA688CF-F FOUNDATION™ fieldbus display may be connected to any fieldbus segment as shown in Fig 2 providing it can provide the additional 25mA required to operate the instrument.




Fig 2 Fieldbus system

#### 3.1 External switches

For applications requiring operator inputs to be made by large industrial push buttons, terminals S1 to S7 allow up to six external switches to be connected to the Fieldbus Display. When external switches are connected the front panel push buttons may be operated in parallel or disabled – see section 5.7.6.

Terminals S1 to S7 are not electrically isolated from the fieldbus terminals, therefore external switches and wiring must be isolated from earth and all other electrical circuits.

For reliable operation it is recommended that the cable connecting the Fieldbus Display to external switches is less than 5m long.

#### 3.2 Alarm outputs

Each alarm output is a galvanically isolated single pole solid state switch output as shown in Fig 3.




Fig 3 Equivalent circuit of each switch output

The outputs are polarised and current will only flow in one direction. Odd numbered terminals should be connected to the positive side of the supply.

$$\begin{aligned} R_{on} &= 5\Omega + 0.7V \\ R_{off} &= \text{greater than } 1M\Omega \end{aligned}$$

**Note:** Because of the series protection diode, some test meters may not detect a closed alarm output

#### WARNING

**These Alarm Outputs should not be used for critical safety applications such as an emergency shut down system.**

When the BA688CF-F FOUNDATION™ fieldbus display is disconnected from the fieldbus, or the fieldbus is de-energised all the alarm outputs will open irrespective of how they have been configured.

## 4. INSTALLATION

### 4.1 Location

The BA688CF-F FOUNDATION™ fieldbus display is housed in a robust aluminium enclosure with a toughened glass window mounted in a Noryl bezel. The front of the instrument provides IP66 protection and a gasket seals the joint between the instrument enclosure and the panel. The instrument may be installed in any panel providing the environmental limits shown in the specification are not exceeded.

Fig 4 shows the overall dimensions of the BA688CF-F and the panel cut-out. To achieve an IP66 seal between the instrument enclosure and the panel, the smaller cut-out must be used and the instrument secured with four panel mounting clips.

The BA688CF-F liquid crystal display has maximum contrast when viewed from directly ahead and slightly below the centre line of the instrument.





Fig 4 BA688CF-F dimensions

### 4.2 Installation Procedure

- Insert the BA688CF-F into the instrument panel cut-out from the front of the panel.
- Fix panel mounting clips to opposite sides of the instrument and tighten. Recommended tightening torque is 22cNm (1.95lbf in). **Do not over tighten**. Four clips are required to achieve an IP66 seal between the instrument enclosure and the panel.
- Connect the panel wiring to the rear terminal block(s) as shown in Fig 5. To simplify installation, the terminals are removable so that panel wiring can be completed before the instrument is installed.



Slide panel mounting clip into the slotted rail on the side of the enclosure. Four clips are required to achieve an IP65 seal between instrument and panel.




Fig 5 Installation and terminal connections

**4.3 EMC**

The BA688CF-F complies with the requirements of the European EMC Directive 2014/30/EU and UK Electromagnetic Compatibility Regulations UKSI 2016:1091 (as amended). For specified immunity all wiring should be in screened twisted pairs with the screens connected to the plant's potential equalising network.

## 5. DISPLAY & ALARM CONFIGURATION

### 5.1 Display transducer block

In addition to loading the BA688CF-F FOUNDATION™ fieldbus display Device Description files onto the system host, the eight inputs require individually configuration.

Each of the four inputs of the two Display Transducer Blocks has the following fieldbus configurable parameters:

<b>Bargraph_Min</b>	Defines bargraph lower limit
<b>Bargraph_Max</b>	Defines bargraph higher limit
<b>Display_format</b>	Defines the position of the displayed decimal point. Six options are available:
Auto	Max resolution with selected display format.
4 DP	4 digits on right of decimal point
3 DP	3 digits on right of decimal point
2 DP	2 digits on right of decimal point
1 DP	1 digit on right of decimal point
0 DP	No decimal point
<b>Zero_offset</b>	Adds a positive or negative offset to the fieldbus variable before it is displayed.
<b>Gain_factor</b>	Multiplies the fieldbus variable by a factor before it is displayed.
	Display = (Gain factor x fieldbus variable) + Offset
<b>Descriptor</b>	Displayed fieldbus variable identification. Up to 16 characters can be accepted but the number displayed varies depending upon the display screen selected.
<b>Units</b>	Displayed units of measurement. Up to 8 characters can be accepted, but the number displayed varies depending upon the display screen selected.
<b>IN_value</b>	Fieldbus value to be displayed
<b>IN_value_status</b>	Indicates validity of displayed fieldbus value.

### 5.2 Screen selection and alarm configuration

Screen selection and, if fitted, alarm configuration is performed via the four front panel push buttons.

All the display and alarm configuration functions are contained in an easy to use menu that is shown in Fig 7. Where necessary the sub-menus contain on-screen prompts to guide the user through each adjustment.

When navigating through the configuration menu, the push button(s) should be held until the required screen is displayed.

### 5.3 Default configuration

Unless otherwise requested at the time of ordering, BA688CF-F FOUNDATION™ fieldbus displays will be supplied configured as follows:

Keys	Both
Display brightness	100%
Display contrast	50%
Quick access menu	On
Quick access menu code	0000
Configuration menu access code.	0000
Screen	Single variable
Number Format	Auto
All alarms	Disabled
Alarm activation	Good data only
Alarm outputs	N/C
Bargraph	
Low	0
High	100
Input scaling	
Zero offset	0
Gain factor	1
Status text	On
Last input	8
Revision	Revision 3 (2 x IS function blocks)

#### 5.4 Accessing the instrument configuration menu.

Throughout this manual push buttons are shown in italics e.g. *P E ▼ ▲* and legends displayed by the instrument are shown within inverted commas e.g. 'Enter Access Code'. Operating the *P* and *E* push buttons simultaneously accesses the display configuration menu. If the BA688CF-F is not protected by an access code the main menu will be displayed. If an access code other than the default code 0000 has already been entered, the BA688CF-F will request that the access code be entered.

Using the *▼* or *▲* button set the first digit of the code which will be flashing. Pressing *P* will transfer control to the next digit, which should be adjusted in the same way. When all four digits have been set, pressing the *E* button will enter the access code. If the code is correct the main menu will be displayed, if the code is incorrect 'Invalid Code' will be displayed.

When entering an access code, timeout will occur and the instrument will automatically return to the operating mode ten seconds after a push button was last operated. In all other menus, timeout occurs after sixty seconds.

The structure of the display configuration menu is shown in Fig 7. Navigation is achieved by highlighting the required function using the *▼* and *▲* buttons and then operating the *P* button to display the selected function sub-menu, from which a further selection or adjustment may be made. Operating the *E* button moves the display back one level.

A flashing highlight indicates that an option or alphanumeric character may be selected using the *▼* and *▲* buttons and entered using the *E* button. If only one entry or adjustment can be made in a sub-menu, the display will automatically move up one menu level when the adjustment is entered. If more than one adjustment can be made in a sub-menu, the highlight may be moved to the second variable using the *▼* or *▲* button after the first setting has been entered. Operating the *P* button allows the second variable to be adjusted.

When multiple numeric or alpha characters are adjusted e.g. an alarm setpoint or a tag legend, the adjustment is made one digit at a time using the *▼* and *▲* buttons. After the first flashing digit has been set as required, the flashing highlight can be moved to the next digit by operating the *P* button. When all digits have been set, operating the *E* button will enter the setting.

Following completion of the instrument configuration, the *E* button should be operated to step the display back to the main menu. One more operation of the *E* button will then return the BA688CF-F to the operating mode.


**5.5 Screen selection**

The BA688CF-F can display up to eight fieldbus variables. These are identified as IN\_1 to IN\_8. The fieldbus variable that each one represents is determined by the BA688CF-F configuration at the fieldbus system host – see *the FOUNDATION™ fieldbus Interface Guide*.


This sub-menu allows one of eleven standard display formats to be selected. The standard formats contain one, two, three, four or eight fieldbus variables some with bargraphs as shown below.




**One variable**



**Two variables**




**Four variables**




**Eight variables**




**One variable + horizontal bargraph**




**Two variables + horizontal bargraphs**




**One variable + vertical bargraph**




**Two variables + vertical bargraphs**



**Three variables + vertical bargraphs**



**Four variables + vertical bargraphs**



**Eight variables + horizontal bargraphs**

## 5.6 Alarm configuration

**Note:** Alarm menus are only included when the BA688CF-F is fitted with optional alarm outputs. Outputs are locally activated from the fieldbus variables and are configured via the instrument menus and push buttons. They can not be controlled via the fieldbus.

Each of the six alarms may be linked to any one of the eight fieldbus variables displayed by the BA688CF-F. Each alarm output can be conditioned to function as a high or a low alarm, or as a combined high and low alarm. The output can be conditioned as normally open 'N/O', or normally closed 'N/C' in the non-alarm condition. Irrespective of settings alarm outputs will be open when the instrument is not powered from the fieldbus.

When an alarm is activated, the associated fieldbus variable display flashes, i.e. alternates between dark figures on a light background and light figures on a dark background.

There are eight alarm-conditioning sub-menus.

### 5.6.1 Alarm summary

Shows to which fieldbus variable each alarm is linked and how each alarm has been conditioned i.e. high, low, or combined high & low alarm with normally open or closed output. No adjustments can be made in this sub-menu.

### 5.6.2 Alarm activation

Fieldbus variables that have not been validated are displayed with dark characters on a light background, and some screen formats also contain a status indication. This sub-menu allows the alarm outputs to be conditioned so that they only operate with validated fieldbus data, or to operate irrespective of data validity.

### 6.6.3 Alarm output

There is a separate sub-menu for each of the six alarm outputs; these link the alarm to one of the displayed fieldbus variables and define the alarm function and the setpoints.

To link the alarm to a displayed variable, position the cursor over the 'IN\_n' field, press **P** and using the ▼ or ▲ button select the required input source. Enter the selection by pressing the **E** button.

Each alarm output can be N/O or N/C in the non-alarm condition. To change the setting, position the highlight over the 'N/O' or 'N/C' field, press **P** and use the ▼ or ▲ button to toggle the setting. Enter the selection by pressing the **E** button.

Each alarm has three functions that can be

independently enabled to condition the output as a low or high alarm, or as a combined low and high alarm, either with or without hysteresis.

The required functions can be individually enabled by positioning the highlight over the Enb/Dis (Enabled/Disabled) column, pressing **P** and toggling the function to the required state, then entering the selection by pressing the **E** button.

Alarm setpoints are entered digit by digit. Place the highlight over the setpoint to be adjusted and press **P**; the flashing digit to be adjusted may then be selected by again pressing **P**. When all the digits have been adjusted, operating the **E** button enters the value and moves the menu up one level.

The function of all alarms may be reviewed from the alarm summary menu - see 5.6.1.

## 5.7 Display configuration

### 5.7.1 Settings

The backlight brilliance and display contrast are adjustable from this sub-menu.

### 5.7.2 Quick Access

This sub-menu enables the Quick Access Menu which is described in sections 2.1 & 5.8. When enabled, an operator can adjust the display contrast and backlight brilliance without having access to any other conditioning menus.

### 5.7.3 Access Code

Defines a four digit alphanumeric code that must be entered to gain access to the Quick Access Menu. Alpha characters are case sensitive. Default code 0000 allows direct access without a code.

### 5.7.4 Status Text

The two single variable screens 1 and 4 will show the status of the FOUNDATION™ fieldbus variable as 'Good' or 'Bad' if the Status Text function is activated.

### 5.7.5 Last Input

This function allows the maximum number of FOUNDATION™ fieldbus variables to be defined so that unused inputs are skipped when the display is scrolled in the operating mode.

### 5.7.6 Keys

The function of the front panel push buttons may be transferred to the six optional external push buttons, with or without disabling the BA688CF-F front panel push buttons. The table below shows the function of the BA688CF-F front panel and the external push buttons for each of the four options that may be selected in the Keys sub-menu.

Selected option from Keys sub-menu	Push buttons	Function of push buttons		
		Screen scrolling	P+E access to configuration menu	P+Up access to quick access menu
Internal	BA688CF-F	Yes	Yes	Yes
	External	No	No	No
External	BA688CF-F	No	Yes	No
	External	Yes	Yes	Yes
Both	BA688CF-F	Yes	Yes	Yes
	External	Yes	Yes	Yes

For applications where the instrument is only displaying 1, 2, 3, 4 or 8 variables on a single screen, it is recommended that external buttons are selected but not fitted. This will disable the instrument front panel buttons, but still provide access to the configuration menu, which may be protected by a security code.

### 5.7.7 Code

Defines the four digit alphanumeric code that must be entered to gain access to the instrument configuration menus. Alpha characters are case sensitive. Default code 0000 allows direct access without a code.

### 5.7.8 Unit Info

Displays the instrument model number and the firmware version.

### 5.7.9 Defaults

This function enables the display and interface board factory defaults to be restored.

### 5.7.10 Display Defaults

This function restores the display defaults defined in section 5.1.

#### CAUTION

**Existing settings can not be recovered after this function has been used.**

### 5.7.11 Interface Board Defaults

This function restores the Fieldbus Interface Board factory defaults.

#### CAUTION

**Do not use this function when the BA688CF-F is connected to an operational fieldbus, as communication will be terminated.**

## 5.8 Quick Access Menu

The Quick Access Menu allows an operator to adjust the backlight brilliance and the display contrast without having access to the other configuration parameters.

The quick access menu is accessed by operating the **P** and **▲** push buttons simultaneously. If the Quick Access Menu is not protected by an access code the contrast and brilliance controls will be displayed immediately. If an access code other than the default code 0000 has already been entered, the BA688CF-F will request that the access code be entered.

The backlight brilliance is adjusted using the **▼** and **▲** push buttons. Operating the **P** push button will transfer control to the display contrast adjustment. When both are set as required, operating the **E** button will store both settings and return the instrument to the operating mode.




Fig 6 Structure of Configuration Menu

## 6. MAINTENANCE

### 6.1 Fault finding during commissioning

If a BA688CF-F FOUNDATION™ fieldbus display fails to function during commissioning the following procedure should be followed:

Symptom	Cause	Check:
No Display	Fieldbus not powered	9 to 32V between terminals 1 & 2.
No variables	Fieldbus not configured  BA688CF-F does not have correct protocol.	Instrument configuration at host.  That BA688CF-F protocol is same as fieldbus. i.e. Fieldbus Foundation or Profibus PA.
Wrong variable displayed	Wrong screen selected	Other screens by operating <i>Up</i> or <i>Down</i> button
Display shows "????"	Display overrange	Number format
No backlight	Brilliance turned down	Setting in display menu
Low or excessive contrast	Incorrect contrast setting	Setting in display menu
Displayed variable is inverted i.e. light digits on dark background	Variable has 'bad' status	Configuration and instrument supplying variable
Displayed variable is flashing	Associated alarm has been activated	Setpoints
Bargraph on standard display format is shown dotted	Displayed fieldbus variable is outside bargraph limits or data is 'bad'	Bargraph limits

### 6.2 Fault finding after commissioning

#### ENSURE PLANT SAFETY BEFORE STARTING MAINTENANCE

If a BA688CF-F fails after it has been functioning correctly, the table shown in section 6.1 may help to identify the cause of the failure.

If this procedure does not reveal the cause of the fault, it is recommended that the instrument is replaced.

### 6.3 Servicing

We recommend that faulty BA688CF-F FOUNDATION™ fieldbus displays are returned to BEKA associates or to our local agent for repair.

### 6.4 Routine maintenance

The mechanical and electrical condition of the instrument should be regularly checked. Initially annual inspections are recommended, although the inspection frequency should be adjusted to suit the environmental conditions.

### 6.5 Guarantee

Instruments which fail within the guarantee period should be returned to BEKA associates or our local agent. It is helpful if a brief description of the fault symptoms is provided.

### 6.6 Customer comments

BEKA associates is always pleased to receive comments from customers about our products and services. All communications are acknowledged and whenever possible, suggestions are implemented.

## **7. ACCESSORIES**

### **7.1 Tag number**

The BA688CF-F can be supplied with a thermally printed tag number on the rear panel. This tag number is not visible from the front of the instrument after installation.

### **7.2 FOUNDATION™ fieldbus Interface Guide**

The BEKA FOUNDATION™ fieldbus Interface Guide which may be downloaded from the BEKA web site at [www.beka.co.uk](http://www.beka.co.uk) contains configuration information for all BEKA FOUNDATION™ fieldbus products.