


**BA334NG**  
**Ex nA and Ex tc**  
**Externally powered**  
**Rate Totaliser**  
Issue 5



## CONTENTS

- 1. Description**
- 2. Operation**
  - 2.1 Initialisation
  - 2.2 Controls
  - 2.3 Displays
  - 2.4 Display over-range
- 3. Certification**
  - 3.1 ATEX Ex nA certification
  - 3.2 Zones, gas groups & T rating
  - 3.3 Safety parameters
  - 3.4 Special conditions for safe use
  - 3.5 Power supply
  - 3.6 Pulse input
  - 3.7 Remote reset terminals
  - 3.8 Certification label information
- 4. System design for gas hazardous areas**
  - 4.1 Power supply
  - 4.2 Pulse input
    - 4.2.1 Input switching thresholds
    - 4.2.2 Switch contact input
    - 4.2.3 Open collector input
    - 4.2.4 2-wire proximity detector input
    - 4.2.5 Magnetic pick-off input
    - 4.2.6 Voltage pulse input
  - 4.3 Remote reset
- 5. Installation**
  - 5.1 Location
  - 5.2 Installation procedure
  - 5.3 EMC
  - 5.4 Units of measurement and tag marking on scale card.
- 6. Configuration and Calibration**
  - 6.1 Configuration structure
  - 6.2 Accessing configuration functions
  - 6.3 Summary of configuration functions
  - 6.4 Rate totaliser function: *Functi on*
  - 6.5 Input: *Input*
  - 6.6 Input type: *InputType*
  - 6.7 Debounce: *Debounce*
  - 6.8 Display update interval: *UpdateRate*
  - 6.9 Upper display: *d1 SP-1*
  - 6.10 Lower display: *d1 SP-2*
  - 6.11 Position of decimal points: *dP*
  - 6.12 Flowmeter K-factor: *FlowRate*
  - 6.13 Total scale factor: *ScaleFactor*
  - 6.14 Rate scale factor: *RateScaleFactor*
  - 6.15 Timebase: *TimeBase*
  - 6.16 Display filter: *Filter*
  - 6.17 Clip-off: *ClipOff*
  - 6.18 Local reset: *LocalReset*
  - 6.19 Local total reset: *LocalTotalReset*
  - 6.20 Local grand total reset: *LocalGrandTotalReset*
  - 6.21 Grand total reset from configuration menu: *GrandTotalReset*
  - 6.22 Security code: *SecurityCode*
  - 6.23 Reset to factory defaults: *ResetToFactoryDefaults*
  - 6.24 Pulse output
    - 6.24.1 Ex nA certification
    - 6.24.2 System design
    - 6.24.3 Configuration
    - 6.24.4 Pulse output
    - 6.24.5 Enable pulse output
    - 6.24.6 Source of output pulse
    - 6.24.7 Divide output pulse frequency
    - 6.24.8 Output pulse width
    - 6.24.9 Pulse storage
- 7. Lineariser**
  - 7.1 Flowmeter specification
  - 7.2 Summary of lineariser configuration functions.
  - 7.3 Add a segment: *Add*
  - 7.4 Remove a segment: *Remove*
  - 7.5 Input frequency: *InputFrequency*
  - 7.6 Flowmeter K-factors: *FlowRate*
  - 7.7 Lineariser error messages
- 8. Configuration example**
  - 8.1 Configuration procedure

**9. Maintenance**

- 9.1 Fault finding during commissioning
- 9.2 Fault finding after commissioning
- 9.3 Servicing
- 9.4 Routine maintenance
- 9.5 Guarantee
- 9.6 Customer comments

**Appendix 1** ATEX dust certification**Appendix 2** IECEx gas and dust certification**Appendix 3** ETL & cETL certification for installation in USA and Canada.**10. Accessories**

- 10.1 Units of measurement and instrument identification.

- 10.2 Backlight

## 10.3 Alarms

- 10.3.1 Solid state output
- 10.3.2 Ex nA certification
- 10.3.3 Configuration and adjustment
- 10.3.4 Alarm enable: `EnbL`
- 10.3.5 Type of alarm: `LYPE`
- 10.3.6 Setpoint adjustment: `SP1x` and `SP2x`
- 10.3.7 Alarm function: `HiLo`
- 10.3.8 Alarm output status: `nonE`
- 10.3.9 Hysteresis: `HSEr`
- 10.3.10 Alarm delay: `delR`
- 10.3.11 Alarm silence time: `SL`
- 10.3.12 Flash display: `FL5H`
- 10.3.13 Access setpoint: `RCSP`
- 10.3.14 Adjusting alarm setpoints from totalisation mode:

## 10.4 4/20mA output

- 10.4.1 Ex nA certification
- 10.4.2 Configuration
- 10.4.3 4/20mA output: `4-20oP`
- 10.4.4 Enable 4/20mA output: `EnbL`
- 10.4.5 Select rate or total source: `4-20LYPE`
- 10.4.6 Display for 4mA output: `4.000`
- 10.4.7 Display for 20mA output: `20.000`

## 1. DESCRIPTION

The BA334NG is an Ex nA and Ex tc certified, field mounting, pulse input rate totaliser primarily intended for use with flowmeters in Zones 2 or 22. The instrument simultaneously displays the rate of flow and the total flow in the same or different engineering units. It is controlled and configured via the four front panel push buttons, a user defined four digit code may be entered to prevent accidental access to the instrument's configuration menu.

This instruction manual supplements the abbreviated instruction sheet supplied with each instrument.

The BA334NG has been issued with a Type Examination Certificate ITS16ATEX48409X by Notified Body Intertek Testing and Certification Ltd. This confirms compliance with the type of protection requirements for non-sparking Ex nA apparatus, and for dust ignition protection by enclosure Ex tc. This certificate has been used to confirm compliance with the European ATEX Directive 2014/34/EU.

For international applications the BA334NG also has IECEx certification which is described in Appendix 2.

For applications in the USA and Canada the BA334NG has ETL and cETL approval, see Appendix 3.

## 2. OPERATION

Fig 1 shows a simplified block diagram of the BA334NG Rate Totaliser. The instrument can accept pulses from most flowmeter transducers. When connected to a pulse output flowmeter the BA334NG will provide an accurate display of the rate of flow and the total flow in the same or different engineering units. The internal lineariser, which can have up to sixteen straight-line segments, may be calibrated to compensate for flowmeter non-linearity.

The BA334NG has a single pair of input terminals for connection to all types of sensor. When counting pulses from a sensor requiring energising, such as a switch contact, open collector or a two wire proximity detector, an external link between terminals 3 and 4 supplies power to the transducer.

Factory fitted accessories include an internally powered display backlight, dual alarms and an isolated 4/20mA output which may be configured to retransmit the rate or total display.




Fig 1 BA334NG block diagram

## 2.1 Initialisation

Each time power is applied to the Rate Totaliser initialisation is performed. After a short delay the following display sequence occurs:



All segments of the display are activated



Instrument starts functioning using the configuration information stored in permanent memory. Unless total and grand total displays have been reset to zero, new flow will be added to the existing totals.






## 2.2 Controls

The BA334NG is controlled and configured via four front panel push buttons. In the totalisation mode i.e. when the instrument is displaying rate and total flow the push button functions are:





### Push Button Functions

 +  Grand total - shows  $L_a$  followed by least significant 8 digits of the 16 digit grand total.

 +  Grand total - shows  $H_i$  followed by the most significant 8 digits of the 16 digit grand total.



If Local Grand Total Reset  $L_r \text{ } \overline{L} \text{ } \overline{a}$  in the instrument configuration menu has been activated, operating the  and  buttons for ten seconds will result in  $L_r.na$  being displayed with the  $na$  flashing. Operating the  or  button will change the display to  $L_r . \overline{y} \overline{E} \overline{5}$ , the  button will then reset the grand total to zero which will be confirmed by a brief display of  $\overline{L} \text{ } \overline{E} \text{ } \overline{L} \text{ } \overline{r} \text{ } \overline{d}$ .

See 6.20



 +  If Local Total Reset  $L_r \text{ } \overline{L} \text{ } \overline{a}$  in the instrument configuration menu has been activated, operating the  and  buttons for three seconds will reset the total display to zero and clear any pulses stored in the optional pulse output.

The Grand Total is not reset.



See 6.19

 +  Shows in succession, firmware version number, instrument function  $\overline{L} \text{ } \overline{a} \text{ } \overline{E} \text{ } \overline{L} \text{ } \overline{5} \text{ } \overline{E}$  and any output accessories that are fitted:

- $\overline{R}$  Dual alarm outputs
- $\overline{P}$  Pulse output (always fitted)
- $\overline{L}$  4/20mA output

 +  Provides direct access to the alarm setpoints when the Rate Totaliser is fitted with optional alarms and the  $\overline{R} \text{ } \overline{E} \text{ } \overline{5} \text{ } \overline{P}$  setpoints function has been enabled.

See 10.3.13

 +  Access to configuration menu

## 2.3 Displays

The BA334NG has two digital displays and associated annunciators, plus a flow indicator as shown on front cover of this manual.

<b>Total display</b>	Shows the total flow on the upper eight digit display. May be reset to zero via front panel push buttons or by a remote reset switch.
<b>Rate Display</b>	Shows the flow rate on the lower six digit display.
<b>Flow indicator</b>	This disc in the lower left hand corner of the display 'rotates' for two seconds each time an input pulse is received. Appears to rotate continuously when input frequency exceeds 0.5Hz.
<b>Hold annunciator</b>	Activated when input frequency is below the clip-off threshold.
<b>Reset annunciator</b>	Activated while instrument is being reset via the front panel push buttons, or the external reset terminals.
<b>Rate annunciator</b>	Identifies rate display
<b>Total annunciator</b>	Identifies total display
<b>RTx annunciator</b>	Retransmitted pulse annunciator. Depends upon the setting of <i>Source</i> in the pulse output configuration menu. <b>SCALE:</b> Annunciator activated each time pulse output open collector is <i>on</i> , i.e. Ron is less than $60\Omega + 3V$ . <b>duration:</b> Annunciator continuously activated.

## 2.4 Display over-range

Over-range of the upper eight digit display or the lower six digit display is indicated by all the digits displaying 9 and all the decimal points flashing.

## 3. CERTIFICATION

The BA334NG has ATEX and IECEx Ex nA gas and Ex tc dust certification. The main sections of this instruction manual describes ATEX gas certification. ATEX dust certification is described in Appendix 1 and IECEx gas and dust certification in Appendix 2.

### 3.1 ATEX Ex nA certification

Notified Body Intertek Testing and Certification Ltd have issued the BA334NG with a Type Examination Certificate number ITS16ATEX48409X. This has been used to confirm compliance with the European ATEX Directive for Group II, Category 3G equipment. The instrument carries the Community Mark and, subject to local codes of practice, may be installed in any of the European Economic Area (EEA) member countries and in the EEA EFTA states, Iceland, Liechtenstein and Norway. ATEX certificates are also acceptable in Switzerland and Turkey. The European Commission's Blue Guide lists the member states, overseas countries and territories that have adopted harmonisation legislation.

This section of the instruction manual describes ATEX installations in explosive gas atmospheres conforming with EN 60079-14 *Electrical installations design, selection and erection*. When designing systems for installation outside the UK the local Code of Practice should be consulted.

### 3.2 Zones, gas groups and T rating

The Rate Totaliser has been certified as Group II Category 3G Ex ic nA IIC T5 Gc Ta -40°C to +60°C apparatus. This is non-sparking apparatus complying with EN 60079-15 *Equipment protection by type of protection 'n'* that minimises the risk of arcs or sparks capable of creating an ignition hazard occurring during conditions of normal operation.

The Rate Totaliser's front panel push button contacts are non incandive and have been certified intrinsically safe Ex ic as shown on the Type Examination Certificate. This allows the Rate Totaliser to be adjusted and configured live when installed in Zones 2.

When connected to a suitable system the BA334NG Rate Totaliser may be installed in:

Zone 2 explosive gas air mixture not likely to occur, and if it does will only exist for a short time.

Be used with gases in groups:

Group A propane  
Group B ethylene  
Group C hydrogen

In gases that may safely be used with equipment having a temperature classification of:

T1	450°C
T2	300°C
T3	200°C
T4	135°C
T5	100°C

At ambient temperatures between -40 and +60°C.

This allows use with all commonly used industrial gases except carbon disulphide CS<sub>2</sub>.

### 3.3 Safety parameters

The certificate specifies input safety parameters in normal operation i.e. without faults for all the instrument terminals. Where only a voltage or only a current is specified, the unspecified parameter will be defined by components within the instrument.

### 3.4 Special conditions for safe use

The Ex nA certificate has an 'X' suffix indicating that the certificate defines special conditions for safe use. These state that the BA334NG Rate Totaliser should be:

- Supplied from a *limited energy* circuit with output parameters in normal operation equal to, or less than the instrument's input parameters. The certificate states that it is **not** necessary to power the instrument from an intrinsically safe interface, such as a certified shunt diode safety barrier or a galvanic isolator to comply with this requirement.
- Fitted with cable entry glands or conduit fittings which maintain the impact and ingress protection of the enclosure. Certified Ex e or Ex n components satisfy these requirements.

The BA334NG is supplied fitted with one certified M20 stopping plug and one temporary hole plug which should be replaced with the required gland or conduit fitting.

### 3.5 Power supply

The input safety parameters for the power supply terminals 1 and 2 are:

Ui	=	30V dc
Ii	=	100mA

This allows the BA334NG to be powered from any dc supply which in normal operation has an output of less 30V and 100mA. See section 4.1 for power supply recommendations.

### 3.6 Pulse input

The BA334NG Rate Totaliser has a single pair of pulse input terminals 5 and 6 that may be configured for use with different types of sensor.

For sensors that require energising to determine their state, such as switch contacts or a 2-wire proximity detector, an external link between terminals 3 & 4 of the BA334NG connects an internal 7V, 6mA supply to the input terminals.

Energising is not required when the Rate Totaliser input is connected to a voltage pulse source.

Fitting an external link between terminals 3 & 4 changes the Rate Totaliser's pulse input safety parameters in normal operation as shown below. This table also shows the types of sensor requiring energising (link fitting).

Type of input	Link 3 & 4	Safety parameters		
		Input	Output	
		Ui	Uo	Io
Switch contact	Yes	15V	10.5V	9.2mA
Proximity detector	Yes	15V	10.5V	9.2mA
Open collector	Yes	15V	10.5V	9.2mA
Magnetic pick-off	No	30V	1.1V	0.5mA
Voltage input (low)	No	30V	1.1V	0.5mA
Voltage input (high)	No	30V	1.1V	0.5mA

### 3.7 Remote reset terminals

The BA334NG total display may be reset to zero by connecting the external reset terminals RS1 and RS2 together for more than one second. The two reset terminals have the following safety parameters in normal operation:

Ui	=	30V
Uo	=	3.8V
Io	=	1mA

### 3.8 Certification label information

The Rate Totaliser certification information label is fitted in a recess on the top outer surface of the enclosure. It shows the ATEX and IECEx certification information plus BEKA associates name, location, year of manufacture and the instrument serial number.

BA334NG 1 Input Rate Totaliser			
CE	Ex	II 3 GD	Conforms to UL Std. 61010-1, IEC Std. 12.12.01 & UL/ISA Std. 60079-0, 60079-11, 60079-15, 60079-31
Ex nA ic IIC T5 Gc, -40°C ≤ Ta ≤ +60°C			Certified to CSA Std. C22.2 No. 25, 213, 60079-0, 60079-11, 60079-15, 60079-31, 61010-1
Ex ic IIC T80°C Dc IP66, -40°C ≤ Ta ≤ +60°C			Class I Div 2 Gp A,B,C,D T5, Class II Div 2 Gp F,G, Class III Div 2
ITS16ATEX48409X IECEx ITS16.0005X			Zone 22 AEx ic IIC T80°C Dc, Ex nA ic IIC T5 Gc, Zone 22 AEx ic IIC T80°C Dc, Ex nA ic IIC T5 Gc
Year of manufacture shown within terminal compartment			Ex n IIC T5 Gc, Ex ic IIC T80°C Dc
			Intertek 4088610 Nonintrusive per BEKA Deg. C1330-53
BEKA associates Hitchin England www.beka.co.uk			

BA334NG Certification information label

#### 4. SYSTEM DESIGN FOR GAS HAZARDOUS AREAS.

When correctly installed in Zone 2 the BA334NG Rate Totaliser may be connected to almost any apparatus in the safe area and to Ex n, Ex e, Ex p and Ex d protected apparatus located in Zone 2. Because the BA334NG is not certified intrinsically safe it should not be connected to an intrinsically safe system.

BEKA Application Guide AG310, *Guide for Installation of [extra low voltage d.c.] Ex nA instrumentation*, which can be downloaded from [www.beka.co.uk](http://www.beka.co.uk), contains explanations and recommendations for the installation of Ex nA equipment.

In addition to being able to be connected to other equipment in the safe area and in Zone 2, the BA334NG may also be connected to suitably protected and certified equipment located in Zone 1. This is illustrated in Fig 5 and explained in Application Guide AG310.

There are four design requirements:

1. The BA334NG should be powered from a circuit that has output safety parameters in normal operation equal to, or less than, the input safety parameters for terminals 1 and 2 specified by the BA334NG ATEX Type Examination Certificate.
2. BA334NG terminals should only be connected to circuits having safety parameters in normal operation compliant with the BA334NG safety parameters which are specified by the ATEX Type Examination Certificate.
3. Hazardous area apparatus to which the BA334NG is connected should be protected by a technique suitable for the Zone in which the equipment is located such as Ex n or Ex e if located in Zone 2. Equipment protected by intrinsic safety should not be connected to a BA334NG.
4. Wiring should comply with Clause 9 of EN 60079-14.

When designing a system it is important to remember that terminals 2, 6 and RS2 are interconnected within the BA334NG. See Fig 1.

#### 4.1 Power supply

The BA334NG Rate Totaliser requires a minimum of 10V between terminal 1 & 2 and consumes:

	10mA	without optional backlight
plus	6mA	when terminals 3 & 4 are linked
plus	16mA	with optional backlight

A 24V dc regulated, current limited supply located in a safe area is suitable.

The power supply should meet the requirements for personnel safety so that 'live maintenance' can safely be performed. The implicit requirement for galvanic isolation from the mains supply ensures that the possible difficulties from circulating earth currents caused by mains faults is minimised. In European terms if the power supply is CE marked it is almost certainly acceptable.

To comply with the requirements of EN 60079:14 *Electrical installations design, selection and erection*, each of the wires entering the hazardous area should be individually fused and contain a means of isolation. These two requirements may be satisfied by using DIN rail mounted terminals incorporating easily removable fuses which can be extracted to achieve isolation as shown in Fig 2. The fuse also limits the current to comply with the instruments li safety parameter in normal operation.

Clear identification of, and easy access to the means of isolation is essential for their effective use. It is also necessary to ensure that the maintenance procedure makes sure that unauthorised re-closure of the switches does not occur.

It is not considered necessary to have a means of isolation or electrical protection for the screen.




Fig 2 DIN rail mounting terminals incorporating a fuse.

For some applications Ex nA instrumentation energised by a current limited power supply or instrument that can be switched off, is considered adequate and to comply with the requirements of the standard.



## 4.2 Pulse input

The BA334NG can display the rate and total flow from flowmeters with a wide variety of pulse outputs located in a Zone 2 hazardous areas or in a safe area. Fig 3 shows the connections when the flowmeter is located in Zone 2 and Fig 4 the connections required when the flowmeter is in a safe area.




Fig 3 Connections for flowmeter sensor in Zone 2




Fig 4 Connections for flowmeter sensor in safe area  
Providing the BA334NG Rate Totaliser is correctly installed in Zone 2, the input terminals may be connected to a certified flowmeter sensor located in

Zone 1 as shown in Fig 5. The flowmeter sensor should have Ex e or Ex d certification permitting installation in Zone 1. Intrinsically safe Ex i certified flowmeter sensors should not be used.




Fig 5 Connection to an Ex d or Ex e flowmeter in Zone 1.

### 4.2.1 Input switching thresholds

For reliable totalisation the Rate Totaliser pulse input must fall below the lower threshold and rise above the upper thresholds shown in the following table.

Input transducer	Switching thresholds	
	Lower	Upper
Open collector	2kΩ	10kΩ
Voltage pulse low	1.0V	3.0V
Voltage pulse high	3.0V	10.0V
Magnetic pick-off	0mV	40mV peak
Proximity detector	1.2mA	2.1mA
Switch	100Ω	1000Ω

Flowmeters with a switch contact, proximity detector or an open collector output require energising which is achieved by linking Rate Totaliser terminals 3 and 4.

### 4.2.2 Switch contact input

Any flowmeter with a mechanically or magnetically activated switch contact located in Zone 2 or in the safe area may be directly connected to pulse input terminals 5 and 6 which are non incandive, providing the flowmeter and associated wiring can withstand a 500V rms insulation test to earth. Most magnetically activated reed relays used in turbine flowmeters comply with these requirements. The BA334NG contains a configurable debounce circuit to prevent contact bounce being counted. See section 6.7.

### 4.2.3 Open collector input

Flowmeters with an open collector output located in Zone 2 or in the safe area may be directly connected to input terminals 5 & 6 providing the flowmeter and associated wiring can withstand a 500V rms insulation test to earth.

The BA334NG contains a configurable debounce circuit to prevent false triggering. See section 6.7.

### 4.2.4 2-wire proximity detector input

Most Zone 2 certified flowmeters incorporating a NAMUR 2-wire proximity detector may be directly connected to a BA334NG input terminals 5 & 6 providing minimum operating voltage is greater than 7.5V. The flowmeter and the associated wiring should be able to withstand a 500V rms insulation test to earth.

The BA334NG contains a configurable debounce circuit to prevent false triggering. See section 6.7.

### 4.2.5 Magnetic pick-off input

Flowmeters incorporating a magnetic pick-off to sense flow will usually have a low level ac voltage output which a BA334NG Rate Totaliser can sense when configured for a  $\Sigma$  input. The Rate Totaliser input terminals 5 and 6 may be connected to any Zone 2 certified magnetic pick-off output flowmeter, providing the output in normal operation is equal to or less than 30V the Rate Totaliser's  $U_i$ . The flowmeter and associated wiring should be able to withstand a 500V rms insulation test to earth.

The BA334NG contains a configurable debounce circuit to prevent false triggering. See section 6.7.

### 4.2.6 Voltage pulse input



Two voltage pulse input ranges are selectable in the BA334NG Rate Totaliser configuration menu,  $U_{0.1 \text{ to } 5 \text{ V}}$  and  $U_{0.1 \text{ to } 5 \text{ H}}$ . The Rate Totaliser input terminals 5 and 6 may be connected to any Zone 2 certified voltage pulse output flowmeter, providing the output in normal operation is equal to or less than 30V the Rate Totaliser's  $U_i$ . The flowmeter and associated wiring should be able to withstand a 500V rms insulation test to earth.

The BA334NG contains a configurable debounce circuit to prevent false triggering. See section 6.7.

## 4.3 Remote reset

The BA334NG Rate Totaliser's total display may be remotely reset to zero by connecting terminals RS1 and RS2 together. Permanent interconnection inhibits totalisation. Remote resetting may be accomplished by any mechanically operated switch located in Zone 2 as the Rate Totaliser's reset circuit is non incensive. The reset switch and the associated wiring should be able to withstand a 500V rms insulation test to earth.

A BA334NG may also be remotely reset from the safe area. Any switch may be used. Fig 4 illustrates how a BA334NG may be reset from both the safe and the hazardous area.

The BA334NG total display may also be reset when the  and  push buttons are operated simultaneously in the totalising mode i.e. when the instrument is displaying flow. See 6.19

## 5. INSTALLATION

### 5.1 Location

The BA334NG Rate Totaliser is housed in a robust IP66 glass reinforced polyester (GRP) enclosure incorporating an armoured glass window and stainless steel fittings making it suitable for exterior mounting in most Zone 2 industrial on-shore and off-shore installations. The Rate Totaliser should be positioned where the display is not in continuous direct sunlight.

Field wiring terminals are located on the rear of the Rate Totaliser assembly as shown in Fig 7.

To ensure electrical continuity between the two conduit or cable entries, the enclosure back-box is fitted with a bonding plate between the cable entries which includes an M4 earth stud. This bonding plate may be mounted on the inside or outside of the back-box. If the carbon loaded GRP enclosure is not bolted to an earthed post or structure, this earth stud should be connected to a local earth or the plant potential equalising conductor.


An insulated M4 stud is provided in the bottom right hand corner of the back-box for interconnecting cable screens.

The BA334NG Rate Totaliser may be pipe mounted using a BA393G pipe mounting kit, or panel mounted using a BA394G or BA395G panel mounting kit.

### 5.2 Installation Procedure


Fig 6 illustrates the instrument installation procedure.

- Remove the Rate Totaliser assembly by unscrewing the four captive 'A' screws.
- Mount the enclosure back-box on a flat surface and secure with screws or bolts through the four 'B' holes. Alternatively use one of the pipe or panel mounting kits which are available as accessories.
- Remove the temporary hole plug and install an appropriate IP and impact rated M20 x 1.5mm cable gland or conduit fitting. A certified Ex e or Ex n component satisfies the requirements. If two entries are required, the supplied certified IP66 stopping plug should be replaced with an appropriate IP and impact rated M20 x 1.5mm cable gland or conduit fitting. A certified Ex e or Ex n component satisfies the requirements.
- Feed the field wiring through the cable entry in the back-box and connect the wires to the terminals on the rear of the instrument assembly as shown in Fig 7. Tighten cable glands to ensure they are sealed and replace the instrument assembly on the back-box. Finally evenly tighten the four 'A' screws.




#### Step A

Unscrew the four captive 'A' screws and separate the indicator assembly and the back-box.




#### Step B

Secure the enclosure back-box to a flat surface with M6 screws through the four 'B' holes. Alternatively use a pipe mounting kit.



#### Step C

Remove the temporary hole plug and install an appropriate IP rated cable gland or conduit fitting. Feed the field wiring through the cable entry.



#### Step D

Terminate field wiring on the indicator assembly. Replace the indicator assembly on the enclosure back-box and tighten the four 'A' screws.

Fig 6 BA334NG installation procedure






Fig 7 Dimensions and terminal connections

### 5.3 EMC

The BA334NG complies with the requirements of the European EMC Directive 2014/30/EU. For specified immunity all wiring should be in screened twisted pairs, with the screens earthed at one point in the safe area.

### 5.4 Units of measurement and tag marking on scale card.

The Rate Totaliser's units of measurement and tag information are shown on a scale card which slides into the instrument.

New Rate Totalisers are supplied with a printed scale card showing the requested units of measurement and tag information. If this information is not supplied when the instrument is ordered, a blank scale card will be fitted which can easily be marked on-site with a dry transfer or a permanent marker. Custom printed scale cards are available from BEKA associates as an accessory.

To remove the scale card from a Rate Totaliser carefully pull the transparent tab at the rear of the instrument assembly away from the assembly as shown in Fig 8a.




Fig 8a Removing scale card




Fig 8b Inserting scale card into the instrument assembly.

To replace the scale card carefully insert it into the slot on the right hand side of the input terminals as shown in Fig 8b. Force should be applied evenly to both sides of the scale card to prevent it twisting. The card should be inserted until about 2mm of the transparent tab remains protruding.

## 6. CONFIGURATION AND CALIBRATION

The BA334NG Rate Totaliser is configured and calibrated via four front panel push buttons. All the configuration functions are contained in an easy to use intuitive menu that is shown diagrammatically in Fig 10.

Each menu function is summarised in section 6.3 of this manual and each summary includes a reference to more detailed information. The sixteen segment lineariser is described separately in section 7.

Configuration of the isolated pulse output, which is fitted to all BA334NG Rate Totalisers is described separately in section 6.24. The optional outputs which when fitted appear as additional functions in the configuration menu are described in section 10.

All new Rate Totalisers are supplied calibrated as requested at the time of ordering. If calibration is not requested, Rate Totalisers will have factory default configuration as shown in the following table, but can easily be re-configured on-site.

Function	Display	Default
Access code	Code	0000
Function	Function	Std
Input	Input TYPE	oP.CoL
Debounce	deBounCE	dEFFuLt
Update	uPdRtE	0.5
Upper display	diSP-1	toAL
Lower display	diSP-2	on
Decimal point	dP	Rate 00 Total 0
K Factor	FRctOr	1.0
Total scale factor	SCALE.t	1.0
Rate scale factor	SCALE.r	1.0
Timebase	t-bASE	SEC
Filter	FiLTER	24
Clip-off	CLP-oFF	0
Local total reset	CLr toL	oFF
Local grand total reset	CLr GtoL	oFF
Security code	Code	0000

**Note:** While the instrument is being configured totalisation continues so that any flow occurring during this time is recorded.

### 6.1 Configuration structure

Fig 9 shows the BA334NG calibration structure. The rate and total display calibrations are independent which allows the displays to have different engineering units.

The rate totaliser pulse input is divided by  $FRctOr$  which is usually set to the K-factor of the flowmeter, thus converting the flowmeter output into engineering units. When the 16 segment lineariser  $Li n$  is selected in the Function sub-menu, up to 16 values for  $FRctOr$  may be entered each at a specified input pulse frequency to compensate for flowmeter nonlinearity. See section 7.

$SCALE-r$  is a dividing factor that converts the output from  $FRctOr$  into the required rate display in engineering units. e.g. if the output from  $FRctOr$  is one pulse per litre and the rate display is required in gallons,  $SCALE-r$  should be set to 4.5461 which is the number of litres in an imperial gallon.

The timebase  $t-bASE$  is a multiplying factor that determines if the instrument displays flow per second, per minute or per hour.

The total flow display is independent of the rate display.  $SCALE-t$  is a dividing factor that converts the output from  $FRctOr$  into the required total display engineering units. e.g. if the output from  $FRctOr$  is one pulse per litre and the total display is required in thousands of gallons,  $SCALE-t$  should be set to 4546.1 which is the number of litres in 1,000 imperial gallons.

The BA334NG uses 'real' decimal points. Moving the position of a decimal point in a scale factor will affect the instrument calibration.






















Fig 9 Calibration structure



## 6.2 Accessing configuration functions

Throughout this manual push buttons are shown as , ,  and  and legends displayed by the instrument are shown in a seven segment font exactly as they appear on the instrument display e.g.  and .

Access to the configuration menu is obtained by operating the  and  push buttons simultaneously. If the instrument is not protected by a security code the first parameter  will be displayed. If a security code other than the default code 0000 has already been entered, the instrument will display . Press  to clear this prompt and enter the security code for the instrument using the  or  push button to adjust each digit, and the  push button to transfer control to the next digit. If the correct code has been entered pressing  will cause the first parameter  to be displayed. If an incorrect code is entered, or a push button is not operated within ten seconds, the instrument will automatically return to the totalisation mode.



















All configuration functions and prompts are shown on the upper eight digit display.

Once within the main configuration menu the required parameter can be selected by scrolling through the menu using the  or  push button. The configuration menu is shown diagrammatically in Fig 10.

When returning to the totalisation mode following reconfiguration, the Rate Totaliser will display  followed by  while the new information is stored in permanent memory.





## 6.3 Summary of configuration functions

This section summarises all the configuration functions. When read in conjunction with Fig 10 it provides a quick aid for configuring the Rate Totaliser. If more detail is required, each section contains a reference to a full description of the function.

Display	Summary of function
	<b>Rate Totaliser function</b> Defines the relationship between the pulse input and the Rate Totaliser display. May be set to:  Standard linear relationship  16 segment adjustable lineariser - see section 7. <b>See section 6.4</b>
	<b>Input</b> Contains sub-menu with two functions  Select Input type  Set debounce <b>See section 6.5</b>
	<b> TYPE</b> Configures the Rate Totaliser to accept one of six types of input:  Open collector *  Voltage pulse <1 >3V  Voltage pulse <3 >10V  Magnetic pick-off  Proximity detector *  Switch contact *
	* Link terminals 3 & 4 <b>See section 6.6</b>
	<b> DEBOUNCE</b> Defines level of input debounce applied to the pulse input to prevent false counting:  DEFAULT  HEAVY  LIGHT <b>See section 6.7</b>
	<b>Display update interval</b> Define the interval between display updates between 0.5 and 5 seconds. <b>See section 6.8</b>

Display	Summary of function
<b>d, SP-1</b>	<b>Upper display</b> Defines whether <i>rate</i> or <i>total</i> is shown on the upper display. The other variable will be shown on the lower display, providing the lower display is on in function <i>d, SP-2</i> . <b>See section 6.9</b>
<b>d, SP-2</b>	<b>Lower display</b> Turns the lower display, which normally shows rate, on or off. <b>See section 6.10</b>
<b>dP</b>	<b>Decimal points</b> Defines the position of the decimal point in both the rate and total displays. <b>See section 6.11</b>
<b>FACtor</b>	<b>Flowmeter K-factor</b> The rate totaliser pulse input is divided by <i>FACtor</i> , which is usually set to the K-factor of the flowmeter, thus converting the flowmeter output into engineering units. <i>FACtor</i> may be adjusted between 0.0001 and 99999. When the 16 segment lineariser <i>Lin</i> is selected in the Function sub-menu, up to 16 values for <i>FACtor</i> may be entered, each at a specified input pulse frequency to compensate for flowmeter non-linearity. <b>See section 6.12</b>
<b>SCALE.t</b>	<b>Total Scale Factor</b> <i>SCALE.t</i> is a dividing factor that converts the pulse output from <i>FACtor</i> into the required total display in engineering units. e.g. if the output from <i>FACtor</i> is one pulse per litre and the total display is required in thousands of gallons, <i>SCALE.t</i> should be set to 4546.1 which is the number of litres in 1,000 imperial gallons. <i>SCALE.t</i> may be adjusted between 0.0001 and 99999. The total flow display is independent of the rate display. <b>See section 6.13</b>

Display	Summary of function
<b>SCALE.r</b>	<b>Rate scale factor</b> <i>SCALE.r</i> is a dividing factor that converts the pulse output from <i>FACtor</i> into the required rate display in engineering units. e.g. if the output from <i>FACtor</i> is one pulse per litre and the rate display is required in gallons, <i>SCALE.r</i> should be set to 4.5461 which is the number of litres in an imperial gallon. <i>SCALE.r</i> may be adjusted between 0.0001 and 99999. The flow rate display is independent of the total flow display. <b>See section 6.14</b>
<b>t-base</b>	<b>Timebase</b> Selectable multiplier allowing flow rate to be displayed in units per second, per minute or per hour.  Select: <b>t-b-01</b> for flow / second <b>t-b-60</b> for flow / minute <b>t-b-3600</b> for flow / hour <b>See section 6.15</b>
<b>Filter</b>	<b>Display filter</b> An adjustable digital filter to reduce noise on the rate display is controlled by two parameters each adjustable between 0 and 9. The first digit defines the amount of filtering applied to the display, the second deviation from the displayed rate at which the filter will be overridden and the rate display will move rapidly to the new value. <b>See section 6.16</b>
<b>CLP-off</b>	<b>Clip-off</b> To prevent totalisation of very low flow rates, clip-off enables the user to select a flow rate display below which totalisation is inhibited. <b>See section 6.17</b>

Display	Summary of function
LoL LLr	<p><b>Local reset</b> Contains sub-menu with two functions enabling total and grand total to be reset to zero via the front panel push buttons when the Rate Totaliser is in the totalisation mode. <b>See section 6.18</b></p> <p><b>Local total reset LLr tot</b> When on is selected total display is reset when  and  buttons are operated simultaneously for more than 3 seconds in the operating mode. <b>See section 6.19</b></p> <p><b>Local grand total reset LLr Gtot</b> When on is selected the grand total is reset when  and  buttons are operated simultaneously for more than 10 seconds in the operating mode. <b>Note:</b> Once reset, the grand total can not be restored. <b>See section 6.20</b></p>

Display	Summary of function
LLr - Gtot	<p><b>Reset grand total from configuration menu.</b> This function resets the grand total to zero from within the configuration menu when LLr YE5 is selected, and SurE is entered to confirm the instruction. <b>Note:</b> Once reset, the grand total can not be recovered. <b>See section 6.21</b></p>
Lo dE	<p><b>Security code</b> Defines a four digit alphanumeric code which must be entered to gain access to the configuration menu. Default code 0000 disables the security function and allows unrestricted access to all configuration functions. <b>See section 6.22</b></p>
rSEt dEF	<p><b>Reset to factory defaults</b> Returns the Rate Totaliser configuration functions to the factory default shown in section 6. To prevent accidental use the request must be confirmed by entering SurE before the reset will be executed. <b>See section 6.23</b></p>



#### 6.4 Rate Totaliser function: **Functi on**

The Rate Totaliser contains an adjustable sixteen segment lineariser which may be used to compensate for flowmeter non-linearity. This function turns this lineariser **on** or **off**.

**Std** Lineariser not activated  
**Lin** Lineariser activated

To reveal the existing Rate Totaliser function select **Functi on** from the configuration menu and press **P**. If the function is set as required, press **E** to return to the configuration menu, or press the **▼** or **▲** button to change the setting, followed by the **E** button to return to the **Functi on** prompt in the configuration menu.

#### **Std Linear**

Provides a linear relationship between the pulse input and the Rate Totaliser displays.

#### **Lin 16 segment adjustable lineariser**

Enables a sixteen segment adjustable lineariser. When **Lin** is selected the **Functi on** function is expanded to allow up to 16 values to be entered for different input pulse frequencies. Detailed information about the lineariser including configuration is contained in section 7 of this instruction manual.

#### 6.5 Input: **inPut**

The Input function contains two sub-functions **InputType** and **debounce** which configure the Rate Totaliser input and input noise rejection.

#### 6.6 Input type: **InputType**

**InputType** is a sub-menu in the **Input** function which defines the type of flowmeter or input pulse that the Rate Totaliser will count. To check or change the type of input, select **Input** in the main configuration menu and press **P** which will reveal the **InputType** prompt, pressing **P** again will show the Rate Totaliser input. If set as required press **E** twice to return to the configuration menu, or repeatedly press the **▼** or **▲** button until the required type of input is displayed, then press **E** twice to return to the configuration menu.

One of following six types of input may be selected:

		Switching thresholds	
		Low	High
<b>Open Col</b>	Open collector <sup>2</sup>	2	10kΩ
<b>Voltage pulse low</b>	Voltage pulse low <sup>1</sup>	1	3V
<b>Voltage pulse high</b>	Voltage pulse high <sup>1</sup>	3	10V
<b>Magnetic</b>	Magnetic pick-off	0	40mV
<b>Proximity detector</b>	Proximity detector <sup>2</sup>	1.2	2.1mA
<b>Switch contact</b>	Switch contact <sup>2</sup>	100	1000Ω

#### Notes:

1. Maximum voltage input +30V.
2. For flowmeter transducers that require energising i.e. proximity detectors, switch contacts or open collectors, terminals 3 & 4 of the Rate Totaliser should be linked together.
3. To count correctly, the input pulse must fall below the lower switching threshold and rise above the higher switching threshold.
4. See section 6.7 for the typical maximum counting frequency.





Fig 10 Configuration menu

When fitted optional alarms  
and 4/20mA output  
functions appear here.



<p><b>Rate scale factor</b></p> <p>Divides <b>FACt</b> to produce rate display</p> <p>Press <input type="button" value="▼"/> or <input type="button" value="▲"/> to adjust value and <input type="button" value="P"/> to move to next digit or decimal point</p>	<p><b>Timebase</b></p> <p><input type="button" value="▼"/> or <input type="button" value="▲"/> to select rate display timebase</p> <p>t-b-01 for flow/sec</p> <p>t-b-60 for flow/min</p> <p>t-b-3600 for flow/hour</p>	<p><b>Filter</b></p> <p><input type="button" value="▼"/> or <input type="button" value="▲"/> to adjust value of each digit and <input type="button" value="P"/> to transfer control to other digit</p> <p>First digit: filter magnitude</p> <p>second digit: step response</p> <p><b>Note:</b> While making adjustments the filtered rate display is shown on lower display so stability can be assessed</p>	<p><b>Clip off</b></p> <p>Rate display below which totalisation is inhibited</p> <p>Press <input type="button" value="▼"/> or <input type="button" value="▲"/> to adjust value of each digit and <input type="button" value="P"/> to move to next digit</p>	<p><b>Local total reset</b></p> <p><input type="button" value="▼"/> or <input type="button" value="▲"/> to turn the local total reset function on or off. When on, total display is reset to zero when <input type="button" value="▼"/> and <input type="button" value="▲"/> are operated simultaneously in display mode for more than 3 seconds</p>	<p><b>Local grand total reset</b></p> <p><input type="button" value="▼"/> or <input type="button" value="▲"/> to turn the local grand total reset function on or off. When on, grand total display may be reset to zero when <input type="button" value="E"/> and <input type="button" value="▲"/> are operated simultaneously in display mode for more than 10 seconds</p>	<p><b>Clear grand total</b></p> <p>Press <input type="button" value="▼"/> or <input type="button" value="▲"/> to select YES to reset grand total to zero</p> <p>Confirm instruction by entering <b>SurE</b>. Press <input type="button" value="▼"/> or <input type="button" value="▲"/> to adjust each digit and <input type="button" value="P"/> to move to next digit</p>	<p><b>Define Security Code</b></p> <p>Enter by pressing <input type="button" value="▼"/> or <input type="button" value="▲"/> and <input type="button" value="P"/> to move to next digit</p>	<p><b>Reset configuration to factory defaults</b></p> <p>Confirm instruction by entering <b>SurE</b>. Press <input type="button" value="▼"/> or <input type="button" value="▲"/> to adjust each digit and <input type="button" value="P"/> to move to next digit</p>
--	--	--	---	--	---	---	---	--

### 6.7 Debounce: dEBounceE

dEBounceE is an adjustable sub-menu in the **Rate** function which prevents the Rate Totaliser miscounting when the input pulse has noisy edges, such as those resulting from a mechanical contact closing and bouncing. Three levels of protection may be selected and the amount of debounce applied depends upon the type of Rate Totaliser input that has been selected in the **Rate Type** function.

The following table shows the minimum time that the input pulse must be continuously above the upper input switching threshold and continuously below the lower switching threshold to ensure that the Rate Totaliser processes the input pulse. Input switching thresholds are shown in section 4.1.2.

De-bounce level	Min input pulse width	
	Type of Input	
	Contact	All others
Default	1600µs	40µs
Heavy	3200µs	350µs
Light	400µs	5µs

The Rate Totaliser's maximum counting frequency depends upon the debounce level selected, the shape of the input pulse and its amplitude. The following table assumes a square wave input and is only for guidance. The maximum counting frequency will be lower if the input pulses have sloping edges and the pulse amplitude only slightly exceeds the input switching thresholds.

ONLY FOR GUIDANCE		
De-bounce level	Max counting frequency	
	Type of input	
	Contact	All others
Default	250Hz	12kHz
Heavy	120Hz	2kHz
Light	1000Hz	100kHz

The minimum input frequency is 0.01Hz. Below this frequency the rate display will be forced to zero.

The dEBounceE function is a sub-menu located in the **Rate** function. Select **Rate** in the configuration menu and press **P** which will reveal the **Rate Type** prompt, press the **▼** or **▲** button to select dEBounceE followed by **P** to reveal the existing setting. Pressing the **▼** or **▲** button will scroll through the three levels. When the required level has been selected, pressing **E** twice will enter the selection and return the display to the **Rate** prompt in the configuration menu.

### 6.8 Display update interval: uPdRateE

If either the rate or the total display is likely to change rapidly, a longer interval between display updates may simplify reading the Rate Totaliser display. This function allows one of six different display intervals between 0.5 and 5 seconds to be selected. The selected display update interval does not affect the update time of any other instrument function.

To adjust the update interval select uPdRateE from the configuration menu and press **P** to reveal the existing time. Pressing the **▼** or **▲** button will scroll through the six times. When the required interval has been selected press **E** to enter the selection and return to the configuration menu.

### 6.9 Upper display: d, 5P-1

Usually total flow is shown on the larger upper eight digit display, but this function allows rate to be shown on the upper display and total on the smaller lower display which can show six positive digits.

To check the status of the upper display, select d, 5P-1 from the configuration menu and press **P** which will reveal if the display is showing **Rate** or **Total**. The setting can be changed by pressing the **▼** or **▲** button followed by the **E** button to enter the selection and return to the configuration menu.

### 6.10 Lower display: d, 5P-2

This function turns the lower display *on* or *off*. When turned *off*, the BA334NG will only have one eight digit display which may be configured in the d, 5P-1 function to show total flow or rate of flow.

To check the status of the lower display, select d, 5P-2 from the configuration menu and press **P** to reveal if the lower display is **on** or **off**. The setting may be changed by pressing the **▼** or **▲** button followed by the **E** button to enter the selection and return to the configuration menu.

### 6.11 Position of the decimal points: $dP$

The upper and lower displays have eight and six digits respectively. This function enables the position of the decimal point on both displays to be independently positioned.

To adjust the position of the decimal points select  $dP$  from the configuration menu and press  $[P]$ . The upper display defined as the rate or total display by function  $dSP-1$  (section 6.9) will be activated and identified by the display annunciator as Rate or Total. The decimal point is positioned by operating the  $\blacktriangledown$  or  $\blacktriangle$  push button.

In the total display the  $\blacktriangledown$  button moves the position of the decimal point to the left and the  $\blacktriangle$  button moves it to the right. It may be positioned between any of the six right hand digits or absent by moving it to the right of the least significant digit.

There are no restrictions on the position of the decimal point in the rate display.

When the decimal point in the upper display has been positioned pressing the  $[P]$  button will transfer control to the lower display variable, but it will be shown and annunciated on the larger upper display. The position of the decimal point may be positioned in the same way by operating the  $\blacktriangledown$  or  $\blacktriangle$  push buttons. When set as required enter the settings and return to the configuration menu by operating the  $[E]$  button.

### 6.12 Flowmeter K-factor: $FACtor$

The rate totaliser pulse input is divided by  $FACtor$ , which is adjustable between 0.0001 and 99999, for flow applications  $FACtor$  should be set to the K-factor of the flowmeter. K-factor is the number of pulses that the flowmeter produces per unit volume of flow e.g. 20 pulses per litre,  $FACtor$  therefore converts the flowmeter output into engineering units ready for further scaling to produce the required rate and total flow displays. See Fig 9.

When the 16 segment lineariser  $Lin$  is selected in  $Function$  up to 16 values of  $FACtor$  may be entered, each at a specified input pulse frequency to compensate for flowmeter non-linearity. See section 7 of this manual.

To check or change the value select  $FACtor$  from the configuration menu and press  $[P]$  which will reveal the existing value with one digit flashing.

The flashing digit may be adjusted by pressing the  $\blacktriangledown$  or  $\blacktriangle$  button. When this digit has been adjusted pressing  $[P]$  will transfer control to the next digit. When all the digits have been adjusted pressing  $[P]$  will transfer control to the decimal point that may be positioned between any of the digits, or may be omitted by moving it to the right of the least significant digit. When set as required, press  $[E]$  to return to the  $FACtor$  prompt in the configuration menu.

### 6.13 Total scale factor: $SCALE.t$

$SCALE.t$  is a dividing factor adjustable between 0.0001 and 99999 that enables total flow to be displayed in the required engineering units. e.g. if the output from  $FACtor$  is one pulse per litre and the total display is required in thousands of gallons,  $SCALE.t$  should be set to 4546.1 which is the number of litres in 1,000 imperial gallons. The total flow display is independent of the rate display.

To check or change the total scale factor select  $SCALE.t$  from the configuration menu and press  $[P]$  which will reveal the existing value with one digit flashing. The value of the flashing digit may be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  button. When this digit has been adjusted as required, pressing  $[P]$  will transfer control to the next digit. When all the digits have been adjusted pressing  $[P]$  will transfer control to the decimal point that may be positioned between any of the digits, or may be omitted by moving it to the right of the least significant digit. When the required total scale factor has been entered, press  $[E]$  to return to the  $SCALE.t$  prompt in the configuration menu.

### 6.14 Rate scale factor: $SCALE.r$

$SCALE.r$  is a dividing factor adjustable between 0.0001 and 99999 that enables the flow rate to be displayed in the required engineering units. e.g. if the output from  $FACtor$  is one pulse per litre and the rate display is required in gallons,  $SCALE.r$  should be set to 4.5461 which is the number of litres in an imperial gallon.

The units of the rate display are volume per unit of time. The unit of time is the timebase of the instrument which is determined by  $t-BASE$  described in section 6.15.

To check or change the rate scale factor select  $SCALE.r$  from the configuration menu and press  $[P]$  which will reveal the existing value with one digit flashing. The value of the flashing digit may be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  button. When this digit has been adjusted as required, pressing  $[P]$  will transfer control to the next digit. When all the digits have been adjusted pressing  $[P]$  will transfer control to the decimal point which may be positioned between any of the digits, or may be omitted by moving it to the right of the least significant digit. When the required rate scale factor has been entered, press  $[E]$  to return to the  $SCALE.r$  prompt in the configuration menu.

### 6.15 Timebase: $\text{t-bR5E}$

The timebase multiplies the rate display by 1, 60 or 3,600 depending upon whether the Rate Totaliser is required to display rate per second, per minute or per hour. See Fig 9.

To check or change the timebase, select  $\text{t-bR5E}$  from the configuration menu and press  $\text{P}$  which will reveal the existing setting. Pressing the  $\text{V}$  or  $\text{A}$  button will scroll through the three options:

$\text{t-b-1}$	for flow / second
$\text{t-b-60}$	for flow / minute
$\text{t-b-3600}$	for flow / hour

When the required multiplier is displayed press  $\text{E}$  to return to the  $\text{t-bR5E}$  prompt in the configuration menu.

### 6.16 Display filter: $\text{F,LEEr}$

The digital display filter has two independent adjustable parameters enabling the rate display response to be tailored for optimum performance. The filter parameters are controlled by a two digit number. The first digit defines the amount of filtering applied to the display as shown below.

First digit	Filter time constant seconds
0X	0
1X	1.3
2X	4.3
3X	6.5
4X	8.7
5X	11.3
6X	15.7
7X	20.9
8X	25.2
9X	31.5

The second digit defines the deviation from the displayed rate at which the filter will be overridden and the rate display will move rapidly to the new value.

Second digit	Magnitude of step change which will produce a rapid response
X0	off
X1	1%
X2	2%
X3	4%
X4	8%
X5	12%
X6	16%
X7	24%
X8	32%
X9	64%

By careful adjustment of the two parameters a stable display with an acceptable input step response can be obtained for most applications.

During commissioning it is recommended that initially the second digit is set to 0 (off) and the first digit is adjusted to provide acceptable rate display stability. The second digit should then be increased until the selected step size is greater than the noise on the display signal, at which setting the rate display will become stable. These will be the optimum filter parameters for acceptable rate display stability and a fast response to a large rate signal change.

To check or change the filter select  $\text{F,LEEr}$  in the configuration menu and press  $\text{P}$  which will reveal the existing settings with the first digit flashing. Pressing the  $\text{V}$  or  $\text{A}$  button will change the flashing digit and  $\text{P}$  will transfer control to the second digit. While making adjustments the filtered rate display is shown on the lower display so that stability can be assessed while adjustments are being made. When set as required, press the  $\text{E}$  button to enter the revised parameters and return to the  $\text{F,LEEr}$  prompt in the configuration menu.

### 6.17 Clip-off: $\text{CLP oFF}$

To prevent totalisation of very low flow rates that over long periods may result in significant totalisation errors, the BA334NG may be configured to stop totalising when the flow rate falls below an adjustable threshold.

To check or change the clip-off threshold select  $\text{CLP oFF}$  from the configuration menu and press  $\text{P}$  which will reveal the current setting. The threshold is shown in the units already selected for the flow rate display. One digit will be flashing. The value of the flashing digit may be changed by pressing the  $\text{V}$  or  $\text{A}$  button. When this digit is correct pressing  $\text{P}$  will transfer control to the next digit. When clip-off is set as required, press the  $\text{E}$  button to enter the revised figure and return to the  $\text{CLP oFF}$  prompt in the configuration menu.

When the flow rate falls below the clip-off threshold, the rate display will show zero flow, totalisation will stop and the HOLD annunciator will be activated. The flow indicator will continue to rotate for 2 seconds each time an input pulse is received i.e. at input pulse frequencies above 0.5Hz it will appear to rotate continuously.

#### Note:

To avoid confusion, when the K-factor  $\text{FRLEr}$ , rate scale factor  $\text{SFRLEr}$ , timebase  $\text{t-bR5E}$ , or the position of the rate display decimal point are changed, clip-off will automatically be reset to zero. A new clip-off threshold must therefore be entered after any of these functions have been adjusted.

### 6.18 Local reset: **LoC CLr**

The Local reset function contains two sub-functions **CLr tOt** and **CLr GtOt** which when enabled allow the total display and grand total to be reset to zero via the instrument push buttons while the Rate Totaliser is in the totalisation mode.

### 6.19 Local total reset: **CLr tOt**

**CLr tOt** is a sub-menu in the **LoC CLr** function which when activated allows an operator to reset the total display to zero while in the totalisation mode by operating the **▼** and **▲** push buttons simultaneously for more than three seconds.

Select **LoC CLr** in the configuration menu and press **P** which will reveal the **CLr tOt** prompt then operate **P** again which will show if the local total reset is **on** or **oFF**. If set as required operate the **E** button twice to return to the configuration menu, or the **▼** or **▲** button to change the setting followed by the **E** button twice to enter the change and return to the **LoC CLr** prompt in the configuration menu.

#### Note:

The total display may also be reset to zero remotely by connecting terminals RS1 and RS2 together for more than one second. See sections 3.7 and 4.3 of this manual.

### 6.20 Local grand total reset: **CLr GtOt**

The grand total is a separate sixteen digit counter which is incremented in parallel with the total display, but is not zeroed when the total display is reset to zero. The grand total may be viewed in the totalisation mode in two eight digit sections as described in section 2.2 of this manual.

**CLr GtOt** is a sub-menu in the **LoC CLr** function which when activated allows the operator to reset the grand total display to zero in the totalisation mode by operating the **E** and **▲** push buttons simultaneously for more than ten seconds.

Select **LoC CLr** in the configuration menu and press **P** which will reveal **CLr tOt**. Using the **▼** or **▲** button to select **CLr GtOt** and press **P** which will show if local grand total reset is **on** or **oFF**. If set as required operate the **E** button twice to return to the configuration menu, or the **▼** or **▲** button to change the setting followed by the **E** button twice to enter the change and return to the **LoC CLr** prompt in the configuration menu.

### 6.21 Grand total reset from configuration menu: **CLr GtOt**

The grand total is a separate sixteen digit counter which is incremented in parallel with the total display, but is not zeroed when the total display is reset to zero. The grand total may be viewed in the totalisation mode in two eight digit sections as described in section 2.2 of this manual.

The grand total can be reset to zero from within the configuration menu using this **CLr GtOt** function, or from the totalisation mode if sub-function **CLr GtOt** in the **LoC CLr** function is activated - see 6.20.

To zero the grand total from within the configuration menu select **CLr GtOt** and press **P** which will cause the instrument to display **CLr .no** with **no** flashing. Press the **▼** or **▲** push button until **CLr .YES** is displayed and then press **P** which will result in a **0000** prompt being displayed with the first digit flashing. This is a request for the instruction to be confirmed by entering **SurE** using the **▼** or **▲** buttons and the **P** button to move control to the next digit. Pressing **E** will then reset the grand total to zero and return the Rate Totaliser to the configuration menu.

#### Note:

Once reset, the grand total can not be recovered.

### 6.22 Security code: **LodE**

Access to the instrument configuration menu may be protected by a four digit security code which must be entered to gain access. New instruments are configured with the default security code **0000** which allows unrestricted access to all configuration functions.

To enter a new security code select **LodE** from the configuration menu and press **P** which will cause the Rate Totaliser to display **0000** with one digit flashing. The flashing digit may be adjusted using the **▼** or **▲** push buttons, when set as required operating the **P** button will transfer control to the next digit. When all the digits have been adjusted press **E** to return to the **LodE** prompt. The revised security code will be activated when the Rate Totaliser is returned to the totalisation mode.

Please contact BEKA associates sales department if the security code is lost.

## 6.23 Reset configuration to factory defaults

### 5EE dEF

This function resets the Rate Totaliser including the lineariser, to the factory default configurations which are shown in section 6.0

To reset the Rate Totaliser to the factory default configurations select 5EE dEF from the configuration menu and press **P** which will result in a 0000 display with the first digit flashing. This is a request to confirm the reset to factory default instruction by entering 5urE. Using the **▼** or **▲** button set the flashing digit to 5 and press **P** to transfer control to the second digit which should be set to u. When 5urE has been entered, pressing the **E** button will reset the BA334NG to the factory defaults and return the instrument to the totalising mode.

## 6.24 Pulse output

The BA334NG Rate Totaliser has an opto-isolated open collector pulse output with following electrical parameters:

Ron	=	60Ω + 3V
Roff	=	1M
I max	=	10mA

The output pulse may be a duplicate of the input pulse for re-transmission applications, or it may be derived from the least significant digit of the total display. When derived from the total display the output pulse frequency may be divided and the output pulse width defined.

The retransmitted RTx annunciator on the instrument display shows the status of the retransmitted pulse output. Annunciator activation depends upon the setting of 5aurEE in the pulse output configuration menu.

### 5CALEd

Annunciator activated each time pulse output open collector is on, i.e. Ron is less than 60Ω + 3V.

### d, rEEt

Annunciator continuously activated

## 6.24.1 Ex nA certification

The pulse output is a separate opto-isolated Ex nA circuit with the following input safety parameters:

Ui	=	30V dc
Ii	=	100mA

This allows the pulse output to be connected to any dc circuit providing that in normal operation the maximum supply voltage is not greater than 30V dc.

Providing the BA334NG Rate Totaliser is correctly installed in Zone 2, the pulse output may be directly connected to any suitably protected equipment located in Zone 1 or 2 of a hazardous area, or to equipment located in a safe area. The pulse output should not be directly connected to intrinsically safe equipment.

Fig 11 shows a BA334NE Rate Totaliser mounted in Zone 2 retransmitting a pulse to the safe area. The current pulse flows through R1 resulting in a voltage pulse output with an amplitude of about 20V.

To comply with the requirements of EN 60079-14 *Electrical installations design, selection and erection*, each of the wires entering the hazardous area should be individually fused and contain a means of isolation. These two requirements may be satisfied by installing DIN rail mounted terminals incorporating a fuse which can easily be removed as shown in Fig 2 to provide isolation. Clear identification of, and easy access to the means of isolation is essential for their effective use. It is also necessary to ensure that the maintenance procedure makes sure that unauthorised re-closure of the switches does not occur. It is not considered necessary to have a means of isolation or electrical protection for cable screens.

For some applications Ex nA instrumentation energised by a current limited power supply or instrument that can be switched off, is often considered adequate and to comply with the requirements of the standard.



### 6.24.2 System design

The Rate Totaliser's pulse output is a passive circuit i.e. not powered, but it is totally isolated from all other Rate Totaliser circuits. Subject to complying with Ex nA interconnection requirements, the terminals P1 and P2 may be connected to any other instrument with an open collector pulse input.

Fig 11 shows how to produce a voltage pulse in the safe area that could be used to drive a safe area counter. The positive terminal of the pulse output circuit P1 is connected to the Rate totaliser's positive supply terminal 1. When an output pulse occurs and the open collector output 'closes', P2 is connected to P1 and the pulse current flows through the diode return barrier to resistor R1 in the safe area. The current flowing in the circuit is determined by R1 which should be chosen to limit the pulse output current to less than 10mA. For a 24V supply R1 should be greater than 2,200Ω.




Fig 11 Transferring pulse output to the safe area using Zener barriers

### 6.24.3 Configuration

The pulse output menu shown in Fig 12 is in the BA334NG configuration menu. The output pulse may be a duplicate of the input pulse by selecting *direct* in the *Source* sub-function. Alternatively, selecting *SCALed* derives the output pulse from incrementation of the least significant digit of the total display. When *SCALed* is selected two additional functions, *divisor* and *duration* are added to the sub-menu allowing the output pulse frequency to be divided and the output pulse width (duration) to be defined.

#### 6.24.4 Pulse output: PULSE oP

The pulse output is configured in a sub-menu contained in the *PULSE oP* function.

Using the  $\nabla$  or  $\Delta$  push button scroll through the configuration menu until *PULSE oP* is displayed, pressing  $\text{P}$  will then access the pulse output sub-menu which is shown in Fig 12.




Fig 12 Pulse output configuration sub-menu

#### 6.24.5 Enable pulse output: *EnbL*

This function allows the pulse output to be enabled or disabled without altering any of the pulse output parameters. Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select *EnbL* in the pulse output sub-menu and press  $\text{P}$  which will reveal the existing setting *on* or *off*. The function can be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  push button followed by the  $\text{E}$  button to return to *EnbL* prompt in the sub-menu.

#### 6.24.6 Source of output pulse: *Source*

The output pulse may be derived from:

*SCALed* Incrementation of least significant digit of the total display. May be divided and width defined by the *d, U, dE* and *durAt, on* functions to generate the required output pulse.

*d, rEE* Output is synchronous duplicate of the Rate Totaliser input pulse.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select *Source* in the pulse output sub-menu and press  $\text{P}$  to reveal the existing pulse source. The function can be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  push button followed by the  $\text{E}$  button to return to *Source* prompt in the sub-menu.

#### 6.24.7 Divide output pulse frequency: *d, U, dE*

When *SCALed* is selected in the *Source* sub-function (6.24.6) the output pulse is derived from incrementation of the least significant digit of the total display divided by one of the following five factors to produce the output pulse:

*1*  
*10*  
*100*  
*1000*  
*10000*

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select *d, U, dE* in the pulse output sub-menu and press  $\text{P}$  which will reveal the existing divisor. The selected divisor can be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  push button followed by the  $\text{E}$  button to return to *d, U, dE* prompt in the sub-menu.

**Note:** This function only appears in the pulse output sub-menu when the *SCALed* is selected in the *Source* sub-function (6.24.6).

#### 6.24.8 Output pulse width: *durAtion*

When *SCALed* is selected in the *Source* sub-function (6.24.6) the output pulse width is defined by this function. One of following millisecond pulse widths may be selected:

*0.1*  
*0.5*  
*1*  
*2.5*  
*5*  
*10*  
*25*  
*50*  
*100*  
*250*  
*500*

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select *durAt, on* in the pulse output sub-menu and press  $\text{P}$  which will reveal the existing pulse duration. The value can be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  push button to select the required value followed by the  $\text{E}$  button to return to *durAt, on* prompt in the sub-menu.

**Note:** This function only appears in the pulse output sub-menu when *SCALed* is selected in the *Source* sub-function (6.24.6).

#### 6.24.9 Pulse storage

If the *d, U, dE* and *durAt, on* functions are configured such that the output pulse frequency with the specified pulse width can not be output in real time, the number of pulses will be stored and transmitted at the maximum possible speed.

When the total display is reset to zero or the power supply to the Rate Totaliser is disconnected or turned off, any stored pulses will not be retained.

## 7. LINEARISER

The BA334NG Rate Totaliser can produce accurate results when used with a flowmeter having a K-factor that varies with the flow rate, such as a turbine meter used over a wide range of flows. The instrument includes a sixteen segment straight-line lineariser that may be adjusted to compensate for flowmeter non-linearity.

The lineariser is enabled by selecting **LIN** in the **FUNCTION** section of the configuration menu. The configuration menu shown in Fig 10 remains basically unchanged, except that up to 16 values of the flowmeter K-factor can be entered as **L-FRCTOR**, together with **PULSE Freq** the corresponding input frequency at which each starts.

Fig 14 shows how the Rate Totaliser configuration function **FRCTOR** is extended when the lineariser is activated by selecting **LIN** in the **FUNCTION** menu.




Fig 13 shows a typical linearising characteristic

The lineariser configuration is retained irrespective of how **FUNCTION** in the Rate Totaliser configuration menu is subsequently changed. It is therefore possible to select and deselect the lineariser without having to reconfigure it.

### 7.1 Flowmeter specification

Flowmeters are usually supplied with a calibration certificate specifying the average K-factor and the flow range over which it applies. For use over extended flow ranges and for non-linear devices, multiple K-factors will be specified, often in a table similar to the one shown below.

Flow Rate Litres/min	K-factor Pulses/litre
5	200
10	230
15	239
20	242

From this calibration certificate information the output frequency of the flowmeter, which is required for conditioning the Rate Totaliser lineariser, can be calculated.


$$\text{Output frequency Hz} = \frac{(\text{Flow rate per min}) \times (\text{K-factor})}{60}$$

Flow Rate Litres/min	K-factor Pulses/litre	Output frequency Hz
0	0	0
5	200	16.666
10	230	38.333
15	239	59.750
20	242	80.666

### 7.2 Summary of lineariser configuration Functions.

This section summarises the lineariser configuration functions. When read in conjunction with Fig 14 it provides a quick aid for configuring the lineariser. If more detail is required, each section contains a reference to a full description of the function.

The number of straight-line lineariser segments required should first be entered using the **ADD** and **DEL** functions. In both of these sub-functions the Rate Totaliser displays the current segment and the total number of segments being used as shown below.



Increasing the number of segments will provide a more accurate approximation of the flowmeter characteristic and increase totalisation accuracy.




Fig 14 Lineariser configuration menu

For each segment an input pulse frequency in Hz  $P_{UL5E\ Fr}$  and a corresponding flowmeter K-factor  $L-FR\ Error$  are required. See section 7.1

Lineariser factory defaults are shown below:

Break point	$P_{UL5E\ Fr}$	$L-FR\ Error$
0.	10Hz	1.00
1.	15000Hz	1.00

Display	Summary of function
---------	---------------------

**Rdd****Add a segment**

Adds a new segment before the displayed segment. The calibration of existing segments is not changed, but the identification number of all subsequent segments is increased by one.  
See section 7.3

**dEL****Remove a segment**

Removes the displayed segment, the identification number of all subsequent segments is decreased by one.  
See section 7.4

 **$P_{UL5E\ Fr}$** **Pulse input frequency**

Defines the input frequency in Hz at which the selected lineariser segments starts.  
See section 7.5

 **$L-FR\ Error$** **Flowmeter K-factor**

The rate totaliser pulse input is divided by  $L-FR\ Error$ , which is usually set to the K-factor of the flowmeter, thus converting the flowmeter output into engineering units.  $L-FR\ Error$  may be adjusted between 0.0001 and 99999. Up to 16 values for  $L-FR\ Error$  may be entered, each starting at a specified input pulse frequency  $P_{UL5E\ Fr}$ .  
See section 7.6

**7.3 Add a segment: Rdd**

**Rdd** is a sub-menu in the **FR** function that enables a straight-line segment to be added to the lineariser at any point. Select **FR** in the configuration menu and press **[P]**, which will reveal one of four sub-functions. If **Rdd** is not displayed repeatedly press the **[V]** or **[A]** button to select **Rdd** followed by **[P]** which will cause the current segment and the total number of lineariser segments to be displayed as shown below:

current      total number  
breakpoint   of breakpoints

Each time the **[P]** push button is operated a segment will be added to the lineariser. If configuring the lineariser for the first time, repeatedly press **[P]** until the required total number of segments is shown on the right hand side of the display. Any number between 1 and 16 may be selected.

If adding an additional segment to an already configured lineariser, the insertion position, which is shown on the left hand side of the display, can be selected using the **[V]** or **[A]** push button. When inserting an additional segment, the identification numbers of all segments equal to and above the insertion point are increased by one.



Press **[E]** to return to the **Rdd** prompt in the **FR** sub-menu.


**7.4 Remove a segment: dEL**

**dEL** is a sub-menu in the **FR** function that enables any segment to be removed from the lineariser configuration. Select **FR** in the configuration menu and press **[P]**, which will reveal one of four sub-functions. If **dEL** is not displayed repeatedly press the **[V]** or **[A]** button to select **dEL** followed by **[P]** which will cause the current segment with the total number of segments to be displayed as shown below:

current      total number  
breakpoint   of breakpoints





Each time the **[P]** push button is operated the current segment will be deleted from the lineariser. If configuring the lineariser for the first time, repeatedly press **[P]** until the total number of segments is reduced to the required number.


If removing a segment from a configured lineariser, the segment to be deleted, which is shown on the left hand side of the display, can be selected using the  or  push button. When a segment is deleted, the identification numbers of all segments above the deleted segment are decreased by one.










Press  to return to the *dEL* prompt in the lineariser sub-menu.


### 7.5 Input frequency: *PULSE Fr*

*PULSE Fr* is a sub-menu in the *FRCEtor* function for entering the pulse input frequency at which each of the lineariser segments starts, see Fig 13.

To enter the input pulse frequency at which one or more lineariser segments start, select *FRCEtor* in the configuration menu and press  which will reveal one of four sub-functions. If *PULSE Fr* is not displayed repeatedly press the  or  button to select *PULSE Fr* followed by  to display the current segment for which the start frequency will be entered and the total number of segments that have already been defined using the *Rdd* and *dEL* functions, see below.



The required segment, which is shown on the left hand side of the display, can be selected using the  or  push button. When selected press  which will reveal the current input frequency with one digit flashing. The value of the flashing digit may be changed by pressing the  or  button. When this digit is correct pressing  will transfer control to the next digit. When the input frequency for this lineariser segment is set as required, press the  button to return to the segment identification display from which the next segment may be selected using  or  push button.





When the input frequency for all of the segments has been entered, return to the *FRCEtor* prompt in the configuration menu by operating the  push button.



### 7.6 Flowmeter K-factor *L-FRCEtor*


*L-FRCEtor* is a sub-menu in the *FRCEtor* function for entering the flowmeter K-factor for each of the lineariser segments, see Fig 13.






The rate totaliser pulse input is divided by *L-FRCEtor*, which is adjustable between 00001 and 99999; for flow applications it should be set to the K-factor of the flowmeter. K-factor is the number of pulses that





the flowmeter produces per unit volume of flow e.g. 20 pulses per litre, *L-FRCEtor* therefore converts the flowmeter output into engineering units ready for further scaling to produce the required rate and total flow displays.

To enter the flowmeter K-factor for one or more segments, select *FRCEtor* in the configuration menu and press  which will reveal one of four sub-functions. If *L-FRCEtor* is not displayed in the sub-menu repeatedly press the  or  button to select *L-FRCEtor* followed by  to display the current segment for which *L-FRCEtor* will be entered and the total number of segments that have already been defined using the *Rdd* and *dEL* functions.

The required segment, which is shown on the left hand side of the display, can be selected using the  or  push button, see below.



When selected, press  which will reveal the current *L-FRCEtor* for the selected segment with one digit flashing. The value of the flashing digit may be changed by pressing the  or  button. When this digit has been adjusted as required, pressing  will transfer control to the next digit. When all the digits have been adjusted pressing  will transfer control to the decimal point that may be positioned between any of the digits, or may be omitted by moving it to the right of the least significant digit.

When *L-FRCEtor* for this lineariser segment is set as required, press the  button to return to the segment identification display from which the next segment may be selected using  or  push button. When *L-FRCEtor* for all of the segments has been entered, return to the *FRCEtor* prompt in the configuration menu by operating the  push button twice.

### 7.7 Lineariser error messages

If an attempt is made to position a segment at an input frequency which is not greater than the frequency of the preceding segment, or at an input frequency which is not less than the frequency of the following segment, the error message *URLuErr* will be displayed.

## 8. CONFIGURATION EXAMPLE

In this example a BA334NG Rate Totaliser is connected to a turbine flowmeter having a K-factor of 105 pulses per litre with a magnetic pick-off.

The BA334NG is required to display rate of flow in imperial gallons per hour with a resolution of one gallon and total flow in cubic metres with a maximum total of 100000 and a resolution of 0.01 cubic metres. Linearisation is not required. Totalisation is to stop when the flow rate falls below 10 gallons per hour. The display is to be updated twice per second.

For this application the operator needs to reset the total display to zero from the totalisation mode, but should not be able to reset the grand total. To prevent tampering the instrument configuration menu is to be protected by security code of 1209

### 8.1 Configuration procedure

The BA334NG Rate Totaliser may be configured on-site without disconnection from the power supply or from the flowmeter.

#### Step 1 Enter the configuration menu

Enter the configuration menu by simultaneously pressing **[P]** and **[E]**. Assuming a security code has not already been entered the instrument will respond by displaying *Funct, on* which is the first function in the configuration menu. See Fig 10.

#### Step 2 Select a linear function

With *Funct, on* displayed press **[P]** to reveal the function of the Rate Totaliser. Using the **[▼]** or **[▲]** button select *Std* to switch off the lineariser and provide a linear function. Press **[E]** to enter the selection. See 6.4

#### Step 3 Select the type of input & debounce

Using the **[▼]** or **[▲]** button select *input* in the configuration menu and press **[P]** which will reveal the sub-menu. Again using the **[▼]** or **[▲]** button select *input type* and press **[P]** to reveal the existing input. The Rate Totaliser is required to work with a magnetic pick-off therefore using the **[▼]** or **[▲]** button select *pick* followed by **[E]** to return to the *input type* prompt in the sub-menu. Using the **[▼]** or **[▲]** button select *debounce* from the sub-menu and press **[P]**. Using the **[▼]** or **[▲]** button select *edge* which will provide moderate pulse edge noise protection. If the Rate Totaliser is subsequently found to miscount the noise rejection can be increased. Enter the selection and return to the *input type* prompt in the configuration menu by pressing the **[E]** button twice. See 6.6 and 6.7

#### Step 4 Select the interval between display updates

Using the **[▼]** or **[▲]** button select *update* in the configuration menu and press **[P]** to reveal how frequently the Rate Totaliser display is updated. Using the **[▼]** or **[▲]** push button select *0.5* (0.5 seconds i.e. 2 display updates per second). Enter the selection and return to the *update* prompt in the configuration menu by pressing the **[E]** button. See 6.8

#### Step 5 Upper display

Using the **[▼]** or **[▲]** button select *display 1* in the configuration menu and press **[P]** to select whether flow rate or total flow is shown on the upper 8 digit display. The required maximum total of 100000 with 0.01 resolution can only be accommodated on the top display. Therefore using the **[▼]** or **[▲]** button select *total* and press **[E]** to enter the selection and return to the *display 1* prompt in the configuration menu. See 6.9

#### Step 6 Lower display

Using the **[▼]** or **[▲]** button select *display 2* in the configuration menu and press **[P]** which will show if the lower display is *on* or *off*. The Rate Totaliser is required to display both total flow and the rate of flow so the lower display is required. Using the **[▼]** or **[▲]** button select *on* and press **[E]** to enter the selection and return to the *display 2* prompt in the configuration menu. See 6.10

#### Step 7 Position rate & total decimal points

Select *dp* from the configuration menu and press **[P]**. The upper display already defined as the total display by function *display 1* will be activated and identified by the Total annunciator. Using the **[▼]** or **[▲]** push button position the decimal point in front of the second least significant digit to give a total display resolution of *0.00*.

Pressing the **[P]** button will show the rate display, but in the upper display position with the Rate annunciator activated. Using the **[▼]** or **[▲]** push button position the decimal point to the right of the least significant digit so that it is not visible to give a total display resolution of 1. Finally press the **[E]** button to enter the selections and return to the *dp* prompt in the configuration menu. See 6.11

**Step 8 Enter the flowmeter K-factor**

K-factor is the number of pulses that a flowmeter produces per unit volume of flow. The Rate Totaliser pulse input is divided by  $FRC_{tor}$ , which is adjustable between 0.0001 and 99999. When set to the K-factor of the flowmeter  $FRC_{tor}$  converts the flowmeter output into engineering units ready for further scaling to produce the required rate and total flow displays.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $FRC_{tor}$  from the configuration menu and press  $\text{P}$  to show the existing value with one digit flashing. Enter 105 using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit and to position the decimal point. Finally return to the  $FRC_{tor}$  prompt in the configuration menu by pressing  $\text{E}$ . The output from  $FRC_{tor}$  will now be in litres which may be scaled to produce required rate and total displays.  
See 6.12

**Step 9 Enter the total scale factor**

The Total Scale Factor  $SCALE_{t}$  is a dividing factor adjustable between 00001 and 99999 that enables total flow to be displayed in the required engineering units. In this example the total flow display is required in cubic metres. There are 1,000 litres in a cubic metre so  $SCALE_{t}$  should be set to 1000.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $SCALE_{t}$  from the configuration menu and press  $\text{P}$  to reveal the existing value with one digit flashing. Enter 1000 using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit and to position the decimal point. Finally, return to the  $SCALE_{t}$  prompt in the configuration menu by pressing  $\text{E}$ . The total flow display is independent of the rate display. See 6.13

**Step 10 Enter the rate scale factor**

$SCALE_{r}$  is a dividing factor adjustable between 00001 and 99999 that enables the flow rate to be displayed in the required engineering units. The rate display timebase is determined by  $t_{base}$  that is adjusted in Step 11.

In this example the rate of flow display is required in imperial gallons.  $FRC_{tor}$ , which was adjusted in Step 8 of this example produces an output in Litres that must be converted to imperial gallons. There are 4.5461 Litres in an imperial gallon so  $SCALE_{r}$  should be adjusted to 4.5461

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $SCALE_{r}$  from the configuration menu and press  $\text{P}$  to reveal the existing value with one digit flashing. Enter 4.5461 using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit and to position the decimal point. Finally return to the  $SCALE_{r}$  prompt in the configuration menu by pressing  $\text{E}$ . The flow rate display is independent of the total flow display.  
See 6.14

**Step 11 Enter the rate timebase**

The rate timebase determines whether flow rate is displayed per second, per minute or per hour. In this example gallons per hour are required.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $t_{base}$  from the configuration menu and press  $\text{P}$ . Again using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $t_{base} = 3600$  from the three options which will multiply the rate display by 3600. Return to the  $t_{base}$  prompt in the configuration menu by pressing  $\text{E}$ .  
See 6.15

**Step 12 Adjust the display filter**

The digital display filter has two independent adjustable parameters enabling the rate display response to be tailored for optimum performance. The filter parameters are controlled by a two digit number. The first digit defines the amount of filtering applied to the display, for initial configuration it is recommended it is set to 2 which is a time constant of 4.3 seconds. The second digit controls jump-out following a step input change and it is recommended that this is initially set to 0.

After configuration during commissioning both parameters should be adjusted experimentally to provide a stable display with an acceptable step response.



To allow the effect of filter changes to be seen immediately, the live rate display is shown on the lower display while the filter parameters are shown and may be adjusted on the upper display.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select **FILTER** from the configuration menu and press **P**.

The first digit, which controls the filter time constant, will be flashing and should be set to 2 using the  $\blacktriangledown$  or  $\blacktriangle$  push button. The **P** button will transfer control to the second digit, which controls the step response and should be set to 0 in the same way. When entered return to the **FILTER** prompt in the configuration menu by pressing **E**.  
See 6.16

### Step 13 Define clip-off

To prevent totalisation of low flow rates clip-off defines a flow rate threshold below which totalisation is inhibited. In this example it is required that totalisation does not occur at flow rates below 10 gallons per hour.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select **CLP OFF** from the configuration menu. Press **P** which will reveal the current clip-off threshold in gallons per hour i.e. the same units already selected for the rate display. Enter 10 using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the **P** button to transfer control to the next digit. Finally, store the new clip-off threshold and return to the **CLP OFF** prompt in the configuration menu by pressing **E**.  
See 6.17

### Step 14 Local reset of total and grand total

Two separate functions in the **LOC CLR** sub-menu may be individually activated to enable the operator to reset the total and grand total displays from the totalisation mode without entering the configuration menu.

In this example the operator is required to be able to reset the total display but not the grand total display when the BA334NG Rate Totaliser is in the totalisation mode.

Using the  $\blacktriangledown$  or  $\blacktriangle$  button select **LOC CLR** in the configuration menu and press **P** which will reveal the sub-menu. Again using the  $\blacktriangledown$  or  $\blacktriangle$  button select the local total reset function **CLR Tot** and press **P**. This function is required so using the  $\blacktriangledown$  or  $\blacktriangle$  button select **on** followed by **E** to return to the **CLR Tot**

prompt in the sub-menu. Using the  $\blacktriangledown$  or  $\blacktriangle$  button select the local grand total reset function **CLR Gtot** and press **P**. This function is not required so using the  $\blacktriangledown$  or  $\blacktriangle$  button select **off**. Finally return to the **LOC CLR** prompt in the configuration menu by pressing the **E** button twice.

See 6.18, 6.19 and 6.20.

### Step 15 Reset the grand total to zero

Before completing configuration the Rate Totaliser's grand total should be reset to zero. Using the  $\blacktriangledown$  or  $\blacktriangle$  button select **CLR Gtot** in the configuration menu and press **P** which will cause **CLR no** to be displayed with **no** flashing. Again using the  $\blacktriangledown$  or  $\blacktriangle$  button select **CLR YES** with **YES** flashing. Press **P** which will result in 0000 being displayed with one digit flashing. This is a request for the instruction to be confirmed by entering **sure** using the  $\blacktriangledown$  or  $\blacktriangle$  button to set each digit and the **P** button to move control to the next digit.

Pressing **E** will then reset the grand total to zero and return the instrument to the **CLR Gtot** prompt in the configuration menu.

See 6.21.

### Step 16 Define the security code

Defining a security code prevents unauthorised access to the configuration menu. Using the  $\blacktriangledown$  or  $\blacktriangle$  buttons select **codE** from the configuration menu and press **P** which will result in 0000 being displayed with the first digit flashing. This example requires the security code to be 1209, using the  $\blacktriangledown$  or  $\blacktriangle$  buttons set the flashing digit to 1 and press **P** to transfer control to the second digit. When all the digits of the new code have been entered press **E** to store the code and return to the main configuration menu.

See 6.22.

### Step 17 Return to the totalisation mode

Configuration of the BA334NG is now complete. Pressing the **E** button will save the new configuration and return the Rate Totaliser to the totalisation mode. The BA334NG will display **drR** followed by **sure** while the new information is being stored in permanent memory.

## 9. MAINTENANCE

### 9.1 Fault finding during commissioning

If a BA334NG fails to function during commissioning the following procedure should be followed:

Symptom	Cause	Check:
No display	No power supply, or incorrect wiring. Note: Terminals 2, 6 & RS2 are interconnected within the instrument.	That there is between 10 and 30V on terminals 1 & 2 with terminal 1 positive.
Rate Totaliser is receiving power but flow indicator not rotating	No input pulses, incorrect input configuration, incorrect linking of terminals 3 & 4	Input configuration.  Linking of terminals 3 & 4.  That input signal polarity is correct.
Flow indicator rotating but incorrect rate display	Incorrect rate display calibration	FRt or SCALE.r t-bASE
Flow indicator rotating but incorrect total display	Incorrect total display calibration.  Remote reset switch contacts closed	FRt or SCALE.t  That RESET annunciator is not activated. If it is, check reset wiring and switch.
Flow indicator rotating, but zero rate display, no totalisation and HOLD annunciator activated.	CLP OFF is activated	CLP OFF and if necessary adjust threshold.
Unstable rate display	Noisy pulse input signal	Eliminate source of electrical noise. Increase debounce and/or display filter.
Unable to enter configuration menu.	Incorrect security code	That the correct security code is being used.  Contact BEKA if code is lost.
Clip-off does not function	Clip-off has automatically reset to zero following change of rate display calibration.	Reconfigure CLP OFF
Alarms do not function	Alarms have been disabled following calibration change	Re-enable both alarms.

### 9.2 Fault finding after commissioning

EN 60079-17 *Electrical installations inspection and maintenance* permits live maintenance in Zone 2 if a risk analysis demonstrates that this does not introduce an unacceptable risk. The removal of covers [opening of Ex n instrument enclosure] is permitted if this can be done without contaminating the interior of the instrument with dust or moisture. Some end-users may prefer not to permit live maintenance to minimise risk.

#### ENSURE PLANT SAFETY BEFORE STARTING MAINTENANCE

**Live maintenance within the hazardous area should only be performed when it is permitted by risk analysis, or when there is no risk of a flammable atmosphere being present.**

If a BA334NG fails after it has been functioning correctly, the following table may help to identify the cause of the failure.

Symptom	Cause	Check:
No display	No power supply.	That there is between 10 and 30V on terminals 1 & 2
Flow indicator not rotating	No input pulses	Output from flowmeter. Wiring between flowmeter and Rate Totaliser.
Flow indicator rotating, rate display is zero and totalisation. HOLD annunciator is not activated.	Input below clip-off threshold.	CLP OFF threshold and if necessary adjust.
Unstable rate display	Noisy pulse input signal	Locate source of electrical noise, or increase debounce and rate display filter.

If this procedure does not reveal the cause of the fault, it is recommended that the instrument is replaced.

### 9.3 Servicing

We recommend that faulty BA334NG rate totalisers are returned to BEKA associates or to your local BEKA agent for repair.

### 9.4 Routine maintenance

The mechanical and electrical condition of the instrument should be regularly checked. The inspection frequency should be adjusted to suit the environmental conditions.

**9.5 Guarantee**

Instruments which fail within the guarantee period should be returned to BEKA associates or our local agent. It is helpful if a brief description of the fault symptoms is provided.

**9.6 Customer comments**

BEKA associates is always pleased to receive comments from customers about our products and services. All communications are acknowledged and whenever possible, suggestions are implemented.

## 10. ACCESSORIES

### 10.1 Units of measurement & instrument identification.

New BA334NG Rate Totalisers are supplied with a printed scale card showing the units of measurement and tag information specified when the instrument was ordered. If this information was not supplied a blank scale card will be fitted which can easily be marked with a dry transfer or a permanent marker on-site.

Custom printed scale cards are available as accessories and may be easily fitted as shown in section 5.4 of this manual.

The BA334NG can also be supplied with a blank or custom laser engraved stainless steel legend plate - see Fig 7. The plate, which after installation is visible from the front of the instrument, is supplied loose with two fixing screws for securing it to the rear of the instrument's back-box. This plate can typically accommodate:

- 1 row of 5 alphanumeric characters 10mm high
- or 1 row of 6 alphanumeric characters 7mm high
- or 2 rows of 10 alphanumeric characters 5mm high

### 10.2 Backlight

The BA334NG Rate Totaliser can be supplied with a factory fitted backlight that produces green illumination enhancing display contrast and enabling it to be read at night or in poor lighting conditions. The backlight is internally powered from the instrument so that no additional wiring is required, but the instrument supply current increases to 32mA.

### 10.3 Alarms

The BA334NG can be supplied with factory fitted dual solid state single pole alarm outputs that may be independently programmed as high or low, rate or total alarms with normally open or normally closed outputs.

Configurable functions for each alarm include adjustable setpoint, alarm delay time and alarm silence time. Hysteresis may be applied to rate alarms.

#### CAUTION

**Alarm outputs should not be used for critical safety applications such as a shut down system.**

When the BA334NG power supply is turned off or disconnected, alarm outputs will open irrespective of whether normally open or normally closed outputs

have been selected. When designing a system an open output should therefore be chosen for the alarm condition.

Alarm annunciators on the instrument display indicate the status of each alarm. If an alarm delay or silence time has been selected the annunciator will flash during the delay or silence period.

The BA334NG internal counters are up-dated and compared with the alarm setpoint twice per second, irrespective of the display update time selected. This may result in an alarm being delayed for up to half a second after the rate or total has exceeded the setpoint.

#### 10.3.1 Solid state output

Each alarm has a galvanically isolated single pole solid state switch output as shown in Fig 15. The outputs are polarised and current will only flow in one direction. Terminals A1 and A3 should be connected to the positive side of the supply.

$$\begin{aligned} R_{on} &= \text{less than } 5\Omega + 0.7V \\ R_{off} &= \text{greater than } 1M\Omega \end{aligned}$$

**Note:** Because of the series protection diode some test meters may not detect a closed alarm output.




Fig 15 Equivalent circuit of each alarm output

#### 10.3.2 Ex nA certification

Each alarm output is a separate galvanically isolated Ex nA circuit with the following input parameters:

$$\begin{aligned} U_i &= 30V \text{ dc} \\ I_i &= 200mA \end{aligned}$$

This allows each alarm output to switch any dc circuit providing that in normal operation the maximum supply voltage is not greater than 30V dc and the switched current is not greater than 200mA.

Providing that the BA334NG Rate Totaliser is correctly installed in Zone 2 the two alarm outputs may be used to switch suitably protected equipment located in Zone 1 or 2 of a hazardous area, or equipment located in a safe area.

Fig 16 shows a typical application in which a BA334NG Rate Totaliser is mounted in Zone 2 is displaying the output from a Flameproof Ex d 2-wire flowmeter located in Zone 1. Alarm 1 is switching an Ex e sounder in Zone 1 and alarm 2 is switching a sounder located in the safe area.




Fig 16 Typical alarm application  
(Shown without recommended screened cables)

To comply with the requirements of EN 60079-14 *Electrical installations design, selection and erection*, each of the wires entering the hazardous area should be individually fused and contain a means of isolation. These two requirements are frequently satisfied by using fuse holders with easily removable fuses and removing the fuses to achieve isolation. This is a satisfactory method at the low voltages and currents common in instrumentation systems. Clear identification of, and easy access to the means of isolation is essential for their effective use. It is also necessary to ensure that the maintenance procedure makes sure that unauthorised re-closure of the switches does not occur. It is not considered necessary to have a means of isolation or electrical protection for the screen. Fig 2 illustrates an example of this type of fused terminal block.

For some applications Ex nA instrumentation energised by a current limited power supply or instrument that can be switched off, is often considered adequate and to comply with the requirements of the standard.

### 10.3.3 Configuration and adjustment

When a BA334NG Rate Totaliser is fitted with alarms the configuration menu is extended as shown in Fig 17. Each alarm may be configured to operate on the rate or total display.

For simplicity Fig 17 only shows the configurable functions on the rate option of alarm RL 1, the total option is identical except that total alarms do not have hysteresis. Alarm RL 2 is identical to alarm RL 1.

The following table summarises each of the alarm configuration functions and includes a cross reference to more detailed information. Again only alarm RL 1 functions are listed.

Display	Summary of function
<b>EnbL</b>	<b>Alarm enable</b> Enables or disables the alarm without changing the alarm parameters. See section 10.3.4
<b>TYPE</b>	<b>Type of alarm</b> Defines whether the alarm operates on the rate or total display. See section 10.3.5
<b>SP Ir</b> or <b>SP It</b>	<b>Alarm setpoint 1</b> Adjusts the alarm setpoint. The alarm is activated when the rate or total display equals the setpoint.  <b>Note:</b> SP Ir is displayed for a rate alarm and SP It for a total alarm. See section 10.3.6
<b>Hi.Lo</b>	<b>Alarm function</b> Defines whether the alarm has a high or low function. See section 10.3.7
<b>no.nC</b>	<b>Normally open or normally closed output.</b> Determines whether the single pole alarm output is open or closed in the non-alarm condition. See section 10.3.8
<b>HSte</b>	<b>Hysteresis</b> Adjusts the alarm hysteresis. Only available on a rate alarm. See section 10.3.9
<b>dELR</b>	<b>Alarm delay time</b> Adjusts the delay between the display equaling the setpoint and the alarm output being activated. See section 10.3.10
<b>S.L</b>	<b>Alarm silence time</b> Defines the time that the alarm output remains in the non-alarm condition following acceptance of an alarm. See section 10.3.11
<b>FLSH</b>	<b>Flash display when alarm occurs</b> When enabled, alternates the rate or total display between process value and alarm reference RL1 or RL2 when an alarm output is activated. See section 10.3.12
<b>ALSP</b>	<b>Access setpoint</b> Sub-menu that enables direct access to the alarm setpoints from the totalisation mode and defines a separate security code. See section 10.3.13

### 10.3.4 Alarm enable: EnbL

This function allows the alarm to be enabled or disabled without altering any of the alarm parameters. Using the ▼ or ▲ push button select RL1 or RL2 from the configuration menu and press [P] to access the alarm sub-menu. Press the ▼ or ▲ button until EnbL is displayed followed by [P] which will reveal if the function is on or off. The setting can be changed by pressing the ▼ or ▲ push button followed by the [E] button to return to the alarm sub-menu.

### 10.3.5 Type of alarm: TYPE

Alarm 1 and Alarm 2 are totally independent, both may be rate or total alarms, or one may be conditioned for rate and the other for total. Using the ▼ or ▲ push button select TYPE from the selected alarm sub-menu and press [P] to check or change the function. The ▼ or ▲ push button will toggle the selection between rRtE and LoRL, when set as required press the [E] button to return to the alarm sub-menu.

**Note:** When TYPE is changed, the alarm configuration is automatically reset to the default values and the alarm is disabled. It must therefore be reconfigured before use.

### 10.3.6 Setpoint adjustment: SP1 & SP2

The rate alarm setpoints SP Ir and SP2r may be positioned anywhere between 0000000 and 9999999 and the total alarm setpoint SP It and SP2t anywhere between 000000000 and 999999999.

All the setpoints are adjusted in the same way, for example to adjust the setpoint of Alarm 1 which has been configured to operate on the rate display. Using the ▼ or ▲ push button select SP Ir in the RL1 sub-menu and press [P] which will reveal the existing setpoint with one digit flashing. The required setpoint can be entered using the ▼ or ▲ push button to adjust the flashing digit and the [P] button to transfer control to the next digit. When set as required press [E] to enter the value and return to the SP Ir prompt in the alarm 1 sub-menu.

### 10.3.7 Alarm function: Hi.Lo

Alarm 1 and Alarm 2 are totally independent, both may be Hi or Lo, or one may be configured as a Hi alarm and the other as a Lo alarm. Using the ▼ or ▲ push button select Hi.Lo from the selected alarm sub-menu and press [P] to check or change the function. The ▼ or ▲ push button will toggle the alarm function between Hi and Lo, when set as required, press the [E] button to return to the Hi.Lo prompt in the alarm sub-menu.

### 10.3.8 Alarm output status: $no.n\bar{c}$

Each single pole alarm output may be open or closed in the non-alarm condition. When the BA334NG power supply is turned off or disconnected, the alarm output(s) will open irrespective of whether normally open or normally closed outputs have been selected. Therefore when designing an alarm system normally closed  $nc$  should be selected so that the output opens when an alarm occurs or if the power supply fails.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $no.n\bar{c}$  from the selected alarm sub-menu and press  $\text{P}$  to check or change the function. The  $\blacktriangledown$  or  $\blacktriangle$  push button will toggle the contact status between  $no$  and  $n\bar{c}$ , when set as required, press the  $\text{E}$  button to return to the  $no.n\bar{c}$  prompt in the alarm sub-menu.

### 10.3.9 Hysteresis: $H5\bar{c}r$

Hysteresis is only available on rate alarms so the  $H5\bar{c}r$  function only appears in the configuration sub-menu when alarm  $TYPE$  has been set to  $rate$ . During configuration hysteresis is shown in the units of rate previously configured for the rate display.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $H5\bar{c}r$  in the selected alarm sub-menu and press  $\text{P}$  which will reveal the existing hysteresis with one digit flashing. The required hysteresis can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the  $H5\bar{c}r$  prompt in the alarm sub-menu.

e.g. A Rate Totaliser configured to display a flow of 0 to 5000, with a high alarm set at 4000 and hysteresis of 100 will perform as follows:

High alarm will be activated when flow equals or exceeds 4000, but will not reset until the flow falls below 3900.

**10.3.10 Alarm delay:  $dELR$**  This function enables activation of the alarm output to be delayed for a fixed time following the alarm condition occurring. The delay can be set in 1 second increments up to 3600 seconds. If a delay is not required zero should be entered. To adjust the delay select  $dELR$  using the  $\blacktriangledown$  or  $\blacktriangle$  push button in the selected alarm sub-menu and press  $\text{P}$  which will reveal the existing delay time in seconds with one digit flashing. The required delay time can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the  $dELR$  prompt in the alarm sub-menu. The Rate Totaliser's alarm annunciator will start flashing immediately an alarm condition occurs and will continue for the delay time, after which the alarm output will be activated and the alarm annunciator will be permanently activated.

### 10.3.11 Alarm silence time: $S, L$

The alarm silence function is primarily intended for use in small installations where the alarm output directly operates an annunciator such as a sounder. When the alarm silence time is set to any figure other than zero, the  $\text{P}$  push button becomes an alarm accept button.

After an alarm has occurred, operating the  $\text{P}$  button will cause the alarm output to revert to the non-alarm condition for the programmed alarm silence time. When an alarm is silenced by operating the  $\text{P}$  push button, the Rate Totaliser's alarm annunciator will flash until the silence time expires.

To adjust the alarm silence time select  $S, L$  using the  $\blacktriangledown$  or  $\blacktriangle$  push button in the selected alarm sub-menu and press  $\text{P}$  which will reveal the existing alarm silence time in seconds with one digit flashing. The required silence time can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the  $S, L$  prompt in the alarm sub-menu.




Fig 17 Alarm menu structure

**10.3.12 Flash display when alarm occurs: FLSH**  
In addition to the two alarm annunciators on the left hand side of the Rate Totaliser display which show the status of both alarms, this function provides an even more conspicuous indication that an alarm condition has occurred.

When enabled, this function alternates the rate or total display between the numerical value and the alarm identification RL1 or RL2 when an alarm occurs.

Using the ▼ or ▲ push button select FLSH from the selected alarm sub-menu and press P to check or change the function. The ▼ or ▲ push button

will toggle the function between oFF and on, when set as required, press the E button to return to the FLSH prompt in the alarm sub-menu.

### 10.3.13 Access Setpoint: RCSP

This function activates a separate menu that provides direct access to the alarm setpoints from the totalisation mode by simultaneously operating the P and ▲ buttons. An operator can therefore adjust the alarm setpoints without having access to the configuration and alarm sub-menus. Protection against unauthorised or accidental adjustment is provided by a separate security access code.



Using the ▼ or ▲ push button select **RESP** from the configuration menu and press **P** to reach the enable function **ENBL**. Pressing **P** will reveal the existing setting which can be toggled between **on** and **off** by pressing the ▼ or ▲ push button. When set as required, press the **E** button to return to the **ENBL** prompt from which a separate security access code can be entered using the **REEd** function which can be selected using the ▼ or ▲ push button.

To enter a new security code select **REEd** from the **RESP** sub-menu and press **P** which will cause the Rate Totaliser to display **0000** with one digit flashing. The flashing digit may be adjusted using the ▼ or ▲ push button, when set as required operating the **P** button will transfer control to the next digit. When all the digits have been adjusted press **E** twice to return to the **RESP** prompt in the configuration menu. The revised security code will be activated when the Rate Totaliser is returned to the totalisation mode. Default security access code **0000** will disable the security code allowing direct access to the setpoints from the totalisation mode by pressing the **P** and ▲ buttons simultaneously.

Please contact BEKA associates sales department if the security code is lost.

#### 10.3.14 Adjusting alarm setpoints from the totalisation mode

Access to the two alarm setpoints from the Rate Totaliser totalisation mode is obtained by operating the **P** and ▲ push buttons simultaneously as shown in Fig 18. If the setpoints are not protected by a security code the alarm setpoint prompt **SP 1r** or **SP 1t** will be displayed depending upon whether a rate or total alarm has been conditioned. If access to the setpoints is protected by a security code, **Code** will be displayed first. Pressing **P** again will allow the alarm setpoint security code to be entered digit by digit using the ▼ or ▲ button to change the flashing digit and the **P** push button to move control to the next digit. If the correct code is entered pressing **E** will result in the alarm setpoint prompt **SP 1x** being displayed. If an incorrect security code is entered, or a button is not pressed within ten seconds, the instrument will automatically return to the totalisation mode.

Once within the menu pressing the ▼ or ▲ button will toggle the display between the two alarm setpoint prompts **SP 1x** and **SP 2x**.




Fig 18 Setpoint adjustment from the totalisation mode.

To adjust an alarm setpoint select **SP 1x** or **SP 2x** and press **P** which will reveal the existing value. The flashing digit of the setpoint may be adjusted using the ▼ or ▲ push button and the **P** button to move control to the next digit. When the required setpoint has been entered, pressing **E** will return the display to the **SP 1x** or **SP 2x** prompt from which the other setpoint may be selected, or the instrument may be returned to the totalisation mode by pressing **E** again.

**Note:** Direct access to the alarm setpoints is only available when the menu is enabled - see section 10.3.13

## 10.4 4/20mA output

The BA334NG Rate Totaliser can be supplied with a factory fitted galvanically isolated 4/20mA current sink output which may be configured to represent the rate or total display.

### 10.4.1 Ex nA certification

The optional 4/20mA output is a separate galvanically isolated Ex nA circuit with the following input parameters:

$$U_i = 30V \text{ dc}$$

This allows the 4/20mA output to be connected to any dc circuit providing that in normal operation the maximum supply voltage is not greater than 30V dc.

Providing that the BA334NG Rate Totaliser is correctly installed in Zone 2 the 4/20mA current output may be used to transmit to suitably protected equipment located in Zone 1 or 2 of a hazardous area, or to equipment located in a safe area.




Fig 19 Application of 4/20mA output  
(Shown without recommended screened cables)

Fig 19 shows a typical application in which a Zone 2 mounted BA334NG Rate Totaliser is transmitting a 4/20mA current to the safe area.

To comply with the requirements of EN 60079-14 *Electrical installations design, selection and erection*, each of the wires entering the hazardous area should be individually fused and contain a means of isolation. These two requirements may be satisfied by installing DIN rail mounted terminals incorporating a fuse which can easily be opened as shown in Fig 2 to provide isolation. Clear identification of, and easy access to the means of isolation is essential for their effective use. It is also necessary to ensure that the maintenance procedure makes sure that unauthorised re-closure of the switches does not occur. It is not considered necessary to have a means of isolation or electrical protection for cable screens.

For some applications Ex nA instrumentation energised by a current limited power supply or instrument that can be switched off, is often considered adequate and to comply with the requirements of the standard.

### 10.4.2 Configuration

When a Rate Totaliser is supplied with an optional 4/20mA output the configuration menu is extended as shown in Fig 20. The 4/20mA output sub-menu is accessed via the 4-20 mA P function.

The 4/20mA output sub-menu allows the 4/20mA output to be controlled by the rate or the total display and to be scaled.

### 10.4.3 4/20mA output: 4-20 mA P

Access the Rate Totaliser's configuration menu as described in section 6.2. Using the  $\nabla$  or  $\blacktriangle$  push buttons scroll through the menu until 4-20 mA P is displayed, pressing  $\text{P}$  will then access the 4/20mA output sub-menu which is shown in Fig 20.

### 10.4.4 Enable 4/20mA output: EnbL

This function allows the 4/20mA current output to be disabled or enabled without altering the calibration. Using the  $\nabla$  or  $\blacktriangle$  push button select EnbL in the 4-20 mA P sub-menu and press  $\text{P}$  to reveal the existing setting on or off. The function can be changed by pressing the  $\nabla$  or  $\blacktriangle$  push button followed by the  $\text{E}$  button to return to EnbL prompt in the sub-menu.




Fig 20 4/20mA output configuration sub-menu

#### 10.4.5 Select rate or total source: 4-20mA P/E

The 4/20mA output current can represent the Rate Totaliser's rate or total display, this should be defined before any other current output functions are adjusted.

Using the **▼** or **▲** push button select **4-20mA P/E** in the **4-20mA P** output sub-menu and press **P** to reveal the existing setting **Rate** or **Total**. The function can be changed by pressing the **▼** or **▲** push button followed by the **E** button to return to the **4-20mA P/E** prompt in the sub-menu.

#### 10.4.6 Display which corresponds to 4mA output: 4.000

The Rate Totaliser display which corresponds to a 4.000mA output current is defined by this function. Using the **▼** or **▲** push button select **4.000** in the 4/20mA output sub-menu and press **P** which will reveal the existing rate or total display with one digit flashing. The required display can be entered using the **▼** or **▲** push button to adjust the flashing digit and the **P** button to transfer control to the next digit. When set as required press **E** to enter the value and return to the **4.000** prompt in the 4/20mA output sub-menu.

#### 10.4.7 Display which corresponds to 20mA output: 20.000

The Rate Totaliser display which corresponds to a 20.000mA output current is defined by this function. Using the **▼** or **▲** push button select **20.000** in the 4/20mA output sub-menu and press **P** which will reveal the existing rate or total display with one digit flashing. The required display can be entered using the **▼** or **▲** push button to adjust the flashing digit and the **P** button to transfer control to the next digit. When set as required press **E** to enter the value and return to the **20.000** prompt in the 4/20mA output sub-menu **4-20mA P**.

#### Notes:

1. If the calibration of the rate or total display defined as the source for the 4/20mA output is changed, the 4/20mA output will automatically be set to give a constant 3.5mA output irrespective of the display. The 4/20mA output should always be reconfigured following reconfiguration of the source display.
2. If the Rate Totaliser and the 4/20mA current sink output are powered from separate supplies, the 4/20mA output current will continue to flow when the Rate Totaliser supply fails or is turned off. Powering both from a common supply eliminates this effect.

## APPENDIX 1

### A1.0 ATEX dust certification

In addition to ATEX Ex nA certification permitting installation in explosive gas atmospheres, which is described in the main section of this instruction manual, the BA334NG Rate Totaliser has ATEX Ex tc dust ignition protection by enclosure certification permitting installation in combustible dust atmospheres. The front panel push button switches are non incendive and have been certified intrinsically safe Ex ic without the need for Zener barriers or galvanic isolators.

This appendix describes ATEX installations in explosive dust atmospheres conforming with EN 60079-14 *Electrical installations design, selection and erection*. When designing systems for installation outside the UK the local Code of Practice should be consulted.

The Rate Totaliser's Ex tc dust input and output safety parameters are identical to the Ex nA gas parameters, therefore all the electrical circuits shown in the main section of this manual may also be used for Ex tc dust applications.

### A1.1 Zones, and Maximum Surface Temperature

The BA334NG has been ATEX dust certified

Group II, Category 3D  
Ex ic tc IIIC T80°C Dc  $-40 \leq Ta \leq 60^{\circ}\text{C}$

When connected to a suitable system the Rate Totaliser may be installed in:

Zone 22 explosive atmosphere in the form of a cloud of combustible dust in air is not likely to occur in normal operation, but if it does occur, will only persist for a short period.

Be used with dust in subdivisions:

IIIA	combustible flyings
IIIB	non-conductive dust
IIIC	conductive dust

Having a Minimum Ignition Temperature of:

Dust cloud	120°C
Dust layer on indicator up to 5mm thick	155°C
Dust layer on indicator over 5mm thick.	Refer to EN 60079-14

At an ambient temperature between -40 and +60°C

### A1.2 Special conditions for safe use in dust atmospheres.

Special conditions for safe use are specified by the Ex ic tc certificate indicated by the certificate number's 'X' suffix. These state that the BA334NG Rate Totaliser should be:

- Supplied from a *limited energy* circuit with output parameters in normal operation equal to, or less than the instrument's input parameters. The certificate states that It is **not** necessary to power the instrument from an intrinsically safe interface, such as a certified shunt diode safety barrier or a galvanic isolator to comply with this requirement.
- Fitted with cable entry glands or conduit fittings which maintain the impact and ingress protection of the enclosure. Certified Ex e or Ex n components satisfy these requirements.

The BA334NG is supplied fitted with one certified M20 stopping plug and one temporary hole plug which should be replaced with the required gland or conduit fitting.

### A1.3 Maintenance

The IEC guidance on maintenance procedures EN 60079-17 permits live maintenance in Zone 22 if a risk analysis demonstrates that this does not introduce an unacceptable risk. The removal of covers [opening of Ex tc enclosure] is permitted if this can be done without contaminating the interior of the enclosure and instrument with dust or moisture. Some end-users may prefer not to permit live maintenance to minimise risk.

#### ENSURE PLANT SAFETY BEFORE STARTING MAINTENANCE

**Live maintenance within the hazardous area should only be performed when it is permitted by risk analysis or when there is no risk of a flammable atmosphere being present.**

The instrument assembly should only be removed from the enclosure back-box when dust can not enter the instrument enclosure. Before replacing the instrument assembly the sealing gasket should be inspected to ensure that it is undamaged and free from foreign bodies.

Inspection of the Rate Totalisers mechanical condition and removal of accumulated dust from the front of the instrument and the outside of the enclosure should be regularly performed. The interval between inspections depends upon environmental conditions. Removal of flammable dust should be performed with care to avoid creating a dust cloud.

## APPENDIX 2

### IECEX certification

#### A2.0 The IECEX Certification Scheme

IECEX is a global certification scheme for explosion protected products which aims to harmonise international certification standards. For additional information about the IECEX certification scheme and to view the BEKA associate certificates, please visit [www.iecex.com](http://www.iecex.com)

#### A2.1 IECEX Certificate of Conformity

The BA334NG Rate Totaliser and the optional accessories have been issued with an IECEX Certificate of Conformity number IECEX ITS 16.0005X which specifies the following certification codes:

Ex nA ic IIC T5 Gc  
Ex ic tc IIIC T80°C Dc IP66  
Ta = -40°C to 60°C

The specified IECEX gas and dust intrinsic safety parameters are identical to the ATEX safety parameters described in the main section and Appendix 1 of this manual.

The IECEX certificate may be downloaded from the BEKA associates or the IECEX website, or may be requested from the BEKA sales office.

#### A2.2 Installation

The IECEX and ATEX certificates specify identical safety parameters and installation requirements for both gas and dust approvals as defined by IEC 60079-14. The ATEX installation requirements specified in the main section and Appendix 1 of this manual may therefore be used for IECEX installations, but the local code of practice should also be consulted.

#### A2.3 Special conditions for safe use

The IECEX certificate number has an 'X' suffix indicating that special conditions apply for safe use. These conditions are identical to the ATEX special conditions for safe use specified in the main sections and in Appendix 1 of this manual.

## APPENDIX 3

### ETL & cETL certification for installations in USA and Canada.

#### A3.0 cETL Mark

For installations in the USA and Canada, the BA334NG Rate Totaliser has ETL and cETL Ex nA and Ex tc approval, Control Number 4008610. Copies of the Authorisation to Mark may be downloaded from the BEKA associates website [www.beka.co.uk](http://www.beka.co.uk) or requested from the BEKA associates sales office.

#### A3.1 ETL and cETL certification

The US and Canadian standards used for assessment and certification of the BA334NG are listed on the cETL Authorisation to Mark.

##### ETL codes for USA

Class I Zone 2 AEx nA ic IIC T5 Gc  
 Zone 22 AEx ic tc IIIC T80°C Dc  
 Ta = -40°C to 60°C

##### cETL codes for Canada

Ex nA ic IIC T5 Gc  
 Ex n IIC T5 Gc  
 Ex ic tc IIIC T80°C Dc  
 Class III Div 2 Class II Div 2 Gp F G  
 Ta = -40°C to 60°C

The ETL and cETL safety parameters are the same as ATEX and IECEx parameters, therefore the systems shown in the main section of this manual and in Appendix 1 may be used for US and Canadian installations subject to complying with the local codes of practice.

The Rate Totaliser's front panel push button contacts are non incandive and have been certified intrinsically safe Ex ic, without the need for an external Zener barrier or galvanic isolator, as shown on the ETL Authorisation to Mark. This allows the Rate Totaliser to be adjusted and configured live when installed in Zone 2 or 22 hazardous areas.