

BA524C
loop-powered
4½ digit field
mounting indicator

Issue: 1
1st December 1997

CONTENTS

- 1. Description**
- 2. Operation**
 - 2.1 Controls
- 3. Applications**
 - 3.1 Transmitter loops
 - 3.2 Remote indication
- 4. Installation**
 - 4.1 Location
 - 4.2 Installation procedure
 - 4.3 EMC
- 5. Programming and Calibration**
 - 5.1 Summary of programmable functions
 - 5.2 Root extractor
 - 5.3 Resolution
 - 5.4 Position of decimal point
 - 5.5 Calibration using an external current source.
 - 5.6 Calibration using internal references
 - 5.7 Conditioning sub-menu
 - 5.7.1 AC rejection
 - 5.7.2 Calibration of internal references.
 - 5.8 Function of the *P* push-button
 - 5.9 Security code
 - 5.10 Over and under-range
- 6. Calibration Examples**
 - 6.1 Using an external current source
 - 6.2 Using the internal references
- 7. Maintenance**
 - 7.1 Fault finding during commissioning
 - 7.2 Fault finding after commissioning
 - 7.3 Servicing
 - 7.4 Routine maintenance
 - 7.5 Guarantee
 - 7.6 Customer comments
- 8. Accessories**
 - 8.1 Engraved scale and tag plates
 - 8.2 Alarms
 - 8.2.1 Solid state output
 - 8.2.2 Programming and adjustment
 - 8.2.3 Alarm enable
 - 8.2.4 Setpoint adjustment
 - 8.2.5 Alarm function
 - 8.2.6 Alarm output status
 - 8.2.7 Hysteresis
 - 8.2.8 Alarm delay
 - 8.2.9 Alarm silence time
 - 8.2.10 Access setpoint
 - 8.2.11 Adjusting alarm setpoints from display mode.
 - 8.3 Lineariser
 - 8.3.1 Calibration using an external current source.
 - 8.3.2 Calibration using internal references.
 - 8.4 Tare function
 - 8.5 Display backlight
 - 8.6 Pipe mounting kits
 - 8.7 Panel mounting kit

1. Description

The BA524C is a $4\frac{1}{2}$ digit loop powered digital indicator which displays the current flowing in a $4/20\text{mA}$ loop in engineering units. The indicator only introduces a 1.1V drop which allows it to be installed into almost any $4/20\text{mA}$ current loop. No additional power supply or battery is required.

The BA524C is a second generation instrument which, although providing additional functions, remains compatible with the original BA524.

The main application of the BA524C is to display a measured variable or control signal in a process area. The zero and span of the display are independently adjustable so that the indicator can be calibrated to display any variable represented by the $4/20\text{mA}$ current, e.g. temperature, flow, pressure or level.

The indicator is available in a glass reinforced polyester (GRP), or an epoxy painted aluminium enclosure. Both provide IP66 protection.

2. Operation

Fig 1 shows a simplified block diagram of a BA524C. The $4/20\text{mA}$ input current flows through resistor R1 and forward biased diode D1. The voltage developed across D1, which is relatively constant, is multiplied by a switch mode power supply and used to power the instrument. The voltage developed across R1, which is proportional to the $4/20\text{mA}$ input current, provides the input signal for the analogue to digital converter.




Fig 1 Simplified block diagram of BA524C

Each time a $4/20\text{mA}$ current is applied to the instrument, initialisation is performed. After a short delay the following display sequence occurs:

-1.8.8.8.8 Display test in which all segments of the display are activated for 0.5 seconds.

Blank display For 0.5 seconds.

Decimal points For 3 seconds. cycled

Input current display in engineering units. Using calibration information stored in instrument memory.

2.1 Controls

The BA524C is controlled and calibrated via four push-button switches which are located behind the enclosure cover. In the display mode these switches have the following functions:

P While this button is pushed the indicator will display the input current in mA, or as a percentage of the instrument span depending upon how the indicator has been programmed. When the button is released the normal display in engineering units will return. The function of this push-button is modified when alarms or a tare function are fitted to the indicator.

Down While this button is pushed the indicator will display the number which the indicator has been calibrated to display with a 4mA input. When released the normal display in engineering units will return.

Up While this button is pushed the indicator will display the number which the indicator has been calibrated to display with a 20mA input. When released the normal display in engineering units will return.

E No function in the display mode.

3. Applications

3.1 Transmitter loops

The BA524C indicator may be connected in series with almost any 4/20mA current loop and calibrated to display the measured variable or control signal in engineering units. Fig 2 illustrates a typical application in which an indicator is connected in series with a 2-wire transmitter.




Fig 2 BA524C in a transmitter loop

The sum of the maximum voltage drop of all the components must be less than the minimum power supply voltage.

Minimum operating voltage of 2-wire Tx	10.0
Maximum voltage drop caused by controller	5.0
Maximum voltage drop caused by BA524C	1.1
Maximum voltage drop caused by cables	0.4
	<hr/> 16.5V

Therefore at 20mA the power supply in this example must have an output greater than 16.5V

3.2 Remote indication

A BA524C may be driven from any 4/20mA signal to provide a remote indication. Fig 3 shows a typical application in which the output from a gas analyser drives a BA524C. Again it is necessary to ensure that the voltage capability of the 4/20mA output is greater than the sum of the voltage drops caused by the BA524C and the cable resistance.




Fig 3 Remote indication

4. Installation

4.1 Location

The BA524C indicator can be supplied in either a glass reinforced polyester (GRP), or an epoxy painted aluminium enclosure. Both provide IP66 protection and have a toughened glass window and stainless steel fittings. The GRP enclosure is suitable for most industrial installations including off-shore and waste water treatment applications. For installations where solvents may be present, the aluminium enclosure provides maximum protection.

Both enclosures are surface mounting, but may be pipe or panel mounted using the accessory kits described in sections 8.6 and 8.7 of this manual.

To simplify installation, the enclosure can be installed and the field wiring terminated prior to the indicator assembly being fitted. The enclosure contains diodes to maintain continuity of the 4/20mA loop when the indicator assembly is removed. Terminals 2 and 4 are internally joined and may be used for linking the return 4/20mA wire - see Fig 2. Similarly terminals 5 and 6 are internally joined and may be used for linking the cable screens.

4.2 Installation Procedure

Fig 4 illustrates the instrument installation procedure.

- Remove the enclosure cover by unscrewing the four captive 'A' screws.
- Remove the indicator assembly from the enclosure by unscrewing the three captive 'B' screws.
- Mount the enclosure on a flat surface and secure with screws or bolts through the four corner 'C' holes.
- Remove the factory fitted seals from the cable entries and install the required glands, or conduit fittings.
- Connect the field wiring to the terminals as shown in Fig 5.
- Replace the indicator assembly and evenly tighten the three 'B' screws.
- Replace the enclosure cover and evenly tighten the four 'A' screws.




Fig 4 BA524C installation procedure




Fig 5 Dimensions and terminal connections

4.3 EMC

The BA524C complies with the requirements of the European EMC Directive 89/336/EEC. For specified immunity all wiring should be in screened twisted pairs.

5. Programming and Calibration

The BA524C is programmed and calibrated via four push-buttons which are located behind the enclosure cover. All the functions are contained in an easy to use menu which is shown diagrammatically in Fig 6. Each function is summarised in section 5.1 which includes references to more detailed information. Although this simple menu driven system enables most adjustments to be made without repeated reference to this manual, we recommend that at least the summary of programmable functions in section 5.1 be read before starting recalibration.

When the indicator is fitted with alarms, linearisation or a tare function, additional functions are added to the menu. These accessories are described in section 8 of this manual.

Throughout this manual push-buttons are shown in *italics* e.g. *P* or *Up* push-button, and legends displayed by the indicator are shown within inverted commas e.g. 'CAL' and 'ALr2'.

Access to the programme menu is obtained by operating the *P* and *E* push-buttons simultaneously. If the instrument is not protected by a security code the first parameter 'root' will be displayed. If a security code other than the default code 0000 has already been entered, the indicator will display 'COdE'. Press *P* to clear this prompt and enter the security code for the instrument using the *Up*, *Down* and *P* push-buttons. If the correct code has been entered pressing *E* will cause the first parameter 'root' to be displayed. If an incorrect code is entered the indicator will return to the display mode.

Once within the menu the required parameter can be reached by scrolling through the main menu using the *Up* and *Down* push-buttons as shown in Fig 6. When returning to the display mode following recalibration or changes to any parameters, the indicator will display circulating decimal points for a few seconds while the new information is stored in permanent memory.

All new BA524C indicators are supplied calibrated as requested at the time of ordering. If calibration is not requested, the indicator will be set to display 0.00 with 4mA input, and 100.00 with 20mA input, but can easily be re-calibrated on-site.

5.1 Summary of programmable functions

This section summarises each of the main programmable functions and includes a cross reference to more detailed information. Fig 6 illustrates the location of each function within the menu.

Display	Description of function
'root'	Square root extractor Turns the square root extractor for linearising the output from differential flowmeters on or off. This function is omitted when a lineariser is installed. See section 5.2
'rESn'	Display resolution Selects the resolution of the least significant display digit. May be set to 1, 2, 5 or 10 digits. See section 5.3

'd.P.'	Decimal point Positions the dummy decimal point between any of the digits or turns it off. See section 5.4
'CAL'	Calibration of display using external current source. Enables the zero and span of the indicator to be adjusted using an external current source such as a calibrator. Also enables a complete loop to be calibrated from primary element to the indicator display. When used with an accurate traceable current source this is the preferred method of calibration. See section 5.5
'SEt'	Calibration of display using internal references. Enables the zero and span of the indicator to be adjusted without the need for an accurate input current or disconnection from the 4/20mA loop. See section 5.6
'Cond'	Indicator conditioning This function provides access to a sub-menu enabling the internal references to be calibrated, and the mains (line) frequency rejection to be selected. Because these parameters will alter the indicator display, they are contained in a sub-menu to prevent inadvertent adjustment. See section 5.7
'FrE'	Frequency rejection Defines the mains (line) frequency at which the indicator has maximum ac rejection. 50 or 60Hz may be selected. This function must be set before the instrument is calibrated as it affects the indicator display. See section 5.7.1

'rEF' **Calibration of internal references**
The indicator contains two references representing 4 and 20mA. These internal references are used when the indicator display is calibrated without an external current calibrator, and when the input current is displayed in milliamps. See the SEt and C--P functions. If either of these functions is to be used, the internal references should be periodically calibrated. See section 5.7.2

'C - - P' **Function of *P* push-button**
The *P* push-button may be programmed to display the input current in milliamps or the input current as a percentage of the displayed span. See section 5.8

'COdE' **Security code**
Defines a four digit numeric code which must be entered to gain access to programmable functions. Default code 0000 disables the security function and allows unrestricted access to all programmable functions. See section 5.9

5.2 Root extractor: root

This function is primarily intended for use with differential flowmeters which have a square law 4/20mA output. To activate the square root extractor select 'root' from the menu and press *P* which will reveal if the function is 'On' or 'OFF'. If the function is set as required, press *E* to return to the menu, or press the *Up* or *Down* button to change the setting, followed by the *E* button to return to the main menu.

For reference, the following table shows the output current from a non-linearised differential flowmeter.

% of full flow	Current output mA
2.5	4.01
10.0	4.16
25.0	5.00
50.0	8.00
75.0	13.00
100.0	20.00

5.3 Resolution: rESn

This function defines the resolution of the least significant display digit. Decreasing the display resolution can improve the readability of a noisy signal. Select 'rESn' from the menu and press *P* which will reveal the current display resolution. To change the resolution press the *Up* or *Down* button to select 1, 2, 5 or 10 digits, followed by the *E* button to return to the menu.

5.4 Position of the decimal point: d.P.

A dummy decimal point can be positioned between any of the digits or may be absent. To position the decimal point select 'd.P.' from the menu and press *P*. The decimal point can then be moved or turned off by pressing the *Up* or *Down* push-button, followed by *E* to return to the menu.

5.5 Calibration using an external current source: CAL

This function enables the zero and span of the indicator to be adjusted using an external calibrated current source. When used with an accurate traceable current source this is the preferred method of calibration.

To calibrate the indicator select 'CAL' from the main menu and press *P*. The indicator will display 'ZEro' which is a request for a 4mA input current. Adjust the external current calibrator to 4.000mA and again press *P* which will reveal the current zero display. Each digit of the indicator display can be changed by pressing the *Up* or *Down* buttons. When the first digit is correct

pressing *P* will transfer control to the next digit. When all the digits have been adjusted, press *E* to enter the new zero. The indicator will display 'Ent' for a few seconds while the information is being stored in memory, and will then return to the 'ZEro' prompt.

To adjust the display at 20mA, press the *Up* button which will cause the indicator to display 'SPAn'. Adjust the external current calibrator to 20.000mA and again press *P* which will reveal the existing full scale display. Each digit of the indicator display can be changed by pressing the *Up* or *Down* buttons. When the first digit is correct pressing *P* will transfer control to the next digit. When all the digits have been adjusted press *E* to enter the new span. The indicator will display 'Ent' for a few seconds while the information is being stored in memory, and will then return to the 'SPAn' prompt. Finally press *E* again to return to the main menu.

This function may also be used when calibrating a complete loop from primary element to indicator display e.g. when the indicator is displaying the output from a resistance thermometer to current converter.

5.6 Calibration using internal references: SEt

This function enables the zero and span of the indicator to be adjusted without the need for an accurate external current source, or for disconnection from the 4/20mA loop.

The accuracy of this method depends upon the accuracy of the internal references which should be regularly calibrated as described in section 5.7.2

To calibrate the indicator select 'SEt' from the main menu and press *P*. The indicator will display 'ZEro', pressing *P* again will reveal the current display at 4mA. Each digit of the indicator display can be changed by pressing the *Up* or *Down* buttons. When the first digit is correct pressing *P* will transfer control to the next digit. When the least significant digit has been adjusted, press *E* to return to the 'ZEro' prompt which completes the adjustment.

To adjust the display at 20mA, press the *Up* button which will cause the indicator to display 'SPAn'. pressing *P* again will reveal the indicator display. Each digit can be changed by pressing the *Up* or *Down* buttons. When the first digit is correct, pressing *P* will transfer control to the next digit. When the least significant digit has been adjusted press *E* to return to the 'SPAn' prompt followed by *E* to return to the menu.

5.7 Conditioning sub-menu: Cond

This sub-menu allows the mains (line) frequency at which the indicator has maximum ac rejection to be selected and the two internal references to be calibrated. These functions are contained in a sub-menu to minimise the possibility of inadvertent adjustment. To gain access to the sub-menu select 'Cond' from the main menu and press *P*. The indicator will display 'SurE' to warn that changing the parameters in the sub-menu will change the indicator display. Pressing *P* again will give access to the sub-menu, or pressing *E* will return the indicator to the main menu.

5.7.1 AC rejection: FrE

Caution

If the mains filter frequency is changed, the indicator display and internal references (if used) must be recalibrated.

To provide maximum low frequency rejection the internal digital filter may be set to operate at 50 or 60Hz to correspond with the local mains (line) frequency. To change the frequency select 'FrE' from the 'Cond' sub-menu and press *P* which will reveal the current setting. The setting can be changed by pressing the *Up* or *Down* buttons followed by the *E* button to return to the sub-menu.

5.7.2 Calibration of internal references: rEF

The indicator contains two references representing 4 and 20mA. These references are used in the 'SEt' function which enables the indicator display to be calibrated without an external current calibrator. They are also used in the 'C--P' function when the *P* push-button is programmed to display the input current in the display mode. If neither of these functions is to be used, it is not necessary to calibrate the internal references.

To calibrate the references select 'rEF' from the 'Cond' sub-menu and press *P* which will result in a '0.004A' prompt being displayed. Adjust the external current calibrator to 4.000mA and again press *P*. The indicator will display 'Ent' when the 4mA reference has been updated and will then return to the '0.004A' prompt.

To re-calibrate the 20mA internal reference, press the *Up* button which will cause the indicator to display '0.020A'. Adjust the external current calibrator to 20.000mA and again press *P*. The indicator will display 'Ent' when the 20mA

reference has been updated and will then return to the '0.020A' prompt. Two operations of the *E* button will return the indicator to the main menu.

The accuracy of the internal references, and hence the display accuracy, will depend upon the accuracy of the external current source. With a maximum specified span of 19999 the BA524C has a display resolution of 0.8µA. We therefore recommend that the accuracy of the external current source used for calibration is greater than 0.4µA.

5.8 Function of the *P* push-button: C -- P

This parameter defines the function of the *P* push-button when the indicator is in the display mode. While the button is operated the indicator will display the input current in millamps, or the input current as a percentage of the span.

To check or change the parameter, select 'C -- P' from the main menu and press *P* to reveal the current setting. Pressing the *Up* or *Down* button will toggle the setting between '4-20' the current display and 'PC' the percentage display. When set as required press *E* to return to the main menu.

Accuracy of the current display depends upon the accuracy of the internal references which should be periodically calibrated - see section 5.7.2

5.9 Security code: COdE

The calibration and conditioning of the instrument may be protected by a four digit security code which must be entered before access to the programme menu is granted. New instruments are programmed with the default security code 0000 which allows unrestricted access to all programming functions.

To enter a new security code select 'COdE' from the menu and press *P* which will cause the indicator to display the current security code. Each digit of the code can be changed using the *Up* and *Down* push-buttons, and the *P* button to move to the next digit. When the required code has been entered press *E* to return to the main menu. The revised security code will be activated when the indicator is returned to the operating mode.

If the security code is lost, access to the programmable functions can be obtained by moving the internal security link to the override position. The original security code can then be viewed by selecting 'COdE' from the main menu and pressing *P*.

To gain access to the security code link, remove the indicator assembly from the enclosure as shown in Fig 4. The insulating shell can be removed from the assembly by compressing the ends of the four plastic pillars to reveal the security code override link as shown in Fig 7.




Fig 7 Location of security code override link

5.10. Over and under-range

If the indicator display range is exceeded, the four least significant digits will be blanked. Under-range is indicated by '-1' and over-range by '1'. Under and over-range are also indicated if the input current falls below approximately 3.5mA or rises above approximately 21mA.

If the input current falls below 3mA the instrument initialisation sequence is performed as described in section 2.

6. Calibration Examples

The following examples illustrate the two ways in which a BA524C indicator may be calibrated.

6.1 Using an external current source

A BA524C is required to display:

-50.0	with a 4mA input
1050.0	with a 20mA input

from a linear transducer. Maximum display resolution is required, the frequency of the mains supply is 50Hz and the existing security code is 1209. In the operating mode the indicator is required to display the input current as a percentage of span when the *P* push-button is operated.

Step 1 Connect indicator to calibrator

Connect the indicator to an accurate external current source. Terminal 1 positive. The indicator will automatically perform the initialisation routine described in section 2, and then display the input current using the existing calibration information.

Step 2 Enter programming mode

With an input current between 4 and 20mA put the indicator in the programming mode by simultaneously pressing *P* and *E*. The indicator will respond by displaying 'COdE'. Press *P* to clear this prompt and set the display to the security code 1209 using the *Up*, *Down* and *P* push-buttons. Pressing *E* will enter the code, and after a few seconds during which the decimal points will be scrolled, the first parameter 'root' in the main menu will be displayed.

Step 3 Square root extraction

With 'root' displayed, press *P* which will reveal the root extractor status. The root extractor can be turned on or off by the *Up* or *Down* buttons. Select 'OFF', and press *E* to return to the main menu.

Step 4 Select frequency of max rejection

Scroll through the main menu until 'Cond' is displayed. Enter the sub-menu by pressing *P* twice and select the 'FrE' function. Using the *Up* or *Down* buttons select '50', and then press *E* twice to return to the main menu.

- Step 5 Define function of P push-button**
Select 'C--P' from the main menu and press *P* to reveal the function of the *P* button in the display mode. Select percentage 'PC' and return to the main menu by pressing *E*

Note: Because an input current display in milliamps is not required, it is not necessary to calibrate the two internal references.

- Step 6 Position dummy decimal point**
Scroll through the main menu until 'd.P.' is displayed and then press *P*. Using the *Up* and *Down* push-buttons position the dummy decimal point in front of the least significant digit. Press *E* to return to the main menu.

- Step 7 Calibrate the display**
Scroll through the main menu until 'CAL' is displayed. Press *P* and the indicator will request a 4mA input by displaying 'ZEro'. Set the input current to $4.0000 \pm 0.0004\text{mA}$ and press *P* again which will reveal the existing zero display. Using the *Up*, *Down* and *P* push-buttons enter the required zero display of -50.0 Press *E* to return to the 'ZEro' prompt.

Press the *Up* push-button and the indicator will request a 20mA input by displaying 'SPAn'. Set the input current to $20.0000 \pm 0.0004\text{mA}$ and again press *P* which will reveal the existing span display. Using the *Up*, *Down* and *P* push-buttons enter the required display of 1050.0 Press *E* twice to return to the main menu.

- Step 8 Return to the display mode**
Return to the display mode by pressing *E*.

6.2 Using the internal references

As in 7.1 the BA524C is required to display:

-50.0	with a 4mA input
1050.0	with a 20mA input

from a linear transducer. Maximum display resolution is required, the frequency of the mains supply is 50Hz and the existing security code is 1209. In the operating mode the indicator is required to display the input current in milliamps when the *P* push-button is operated.

This example assumes that the internal references have been routinely calibrated.

Step1 Enter the programming mode

With an input current between 4 and 20mA put the indicator in the programming mode by simultaneously pressing *P* and *E*. The indicator will respond by displaying 'COdE'. Press *P* to clear this prompt and set the display to the security code 1209 using the *Up*, *Down* and *P* push-buttons. Pressing *E* will enter the code, and after a few seconds during which the decimal points will be scrolled, the first parameter 'root' in the main menu will be displayed.

Step 2 Square root extraction

With 'root' displayed, press *P* which will reveal the root extractor status. The root extractor can be turned on or off by the *Up* or *Down* buttons. Select 'OFF', and press *E* to return to the main menu.

Step 3 Select frequency of max rejection

Scroll through the main menu until 'Cond' is displayed. Enter the sub-menu by pressing *P* twice and select the 'FrE' function. Using the *Up* or *Down* buttons select '50', and then press *E* twice to return to the main menu.

Step 4 Define function of P push-button

Select 'C--P' from the main menu and press *P* to reveal the function of the *P* button in the display mode. Select '4-20' and return to the main menu by pressing *E*.

Step 5 Position dummy decimal point

Select 'd.P' from the main menu and then press *P*. Using the *Up* and *Down* push-buttons position the dummy decimal point in front of the least significant digit.

Press *E* to return to the main menu.

Step 6 Calibrate display

With any input current between 4 and 20mA select 'SET' from the main menu and press *P*. The indicator will display 'ZEro' in the sub-menu; press *P* to reveal the existing zero display. Using the *Up*, *Down* and *P* push-buttons enter the required zero display of -50.0. Press *E* to return to the 'ZEro' prompt.

With any input current between 4 and 20mA press the *Up* push-button and the indicator will display 'SPAn'. Press *P* to reveal the existing span display. Using the *Up*, *Down* and *P* push-buttons enter the required span display of 1050.0. Press *E* to return to the 'SPAn' prompt. Press *E* again to return to the main menu.

Step 7 Return to display mode

Return to the display mode by pressing *E*.

7. Maintenance**7.1 Fault finding during commissioning**

If a BA524C fails to function during commissioning the following procedure should be followed:

Symptom	Cause	Solution
No display	Incorrect wiring	There should be 1V between terminals 1 & 3 with terminal 1 positive.
No display and 0V between terminals 1 and 3.	Incorrect wiring or no power supply.	Check that a current is flowing in the loop.
	Insufficient loop voltage to operate indicator	Check supply voltage and voltage drops caused by all components in the loop.
No display and 4V between terminals 1 and 3.	Indicator assembly not correctly installed in enclosure.	Check that the three screws securing the indicator assembly are tightened.
Indicator displays 1	Positive over-range	The indicator has been incorrectly calibrated, & is trying to display a number greater than 19999.
Indicator displays -1	Negative Over-range	The indicator has been incorrectly calibrated & is trying to display a number less than -19999.
Unstable display	4/20mA input has a large ripple content.	Check loop supply voltage.
Unable to enter the programme mode	Incorrect security code entered.	Enter correct security code or fit security link in override position. See Fig 7.

7.2 Fault finding after commissioning

ENSURE PLANT SAFETY BEFORE STARTING MAINTENANCE

If a BA524C fails after it has been functioning correctly, the following procedure should be followed:

Symptom	Cause	Solution
No display, 0V between terminals 1 and 3.	No power supply	Check that a current is flowing in the loop.
Unstable display	4/20mA input has a large ripple.	Check loop supply voltage.
No display, 4V between terminals 1 and 3.	Indicator assembly not correctly installed in enclosure.	Check that the three screws securing the indicator assembly are tightened.
Incorrect calibration	Digital filter FrE has been changed after indicator was calibrated.	Recalibrate

If this procedure does not reveal the cause of the fault, it is recommended that the instrument is replaced. This can be done without disconnecting power, but while the indicator is disconnected the 4/20mA loop will be open circuit.

7.3 Servicing

BA524C indicators are difficult to service to component level on-site. All standard BA524C indicators are interchangeable, so a single spare indicator assembly may be used to replace any instrument which fails.

We recommend that, except under exceptional circumstances, suspect instruments are returned to BEKA associates or our local agent for repair.

7.4 Routine maintenance

The mechanical condition of the instrument and electrical calibration should be regularly checked. The interval between inspections depends upon environmental conditions. We recommend that initially instrument calibration should be checked annually.

7.5 Guarantee

Indicators which fail within the guarantee period should be returned to BEKA associates or our local agent. It is helpful if a brief description of the fault symptoms is provided.

7.6 Customer comments

BEKA associates is always pleased to receive comments from customers about our products and services. All communications are acknowledged and whenever possible, suggestions are implemented.

8. Accessories

8.1 Engraved scale and tag plates

All BA524C indicators are fitted with blank stainless steel scale and tag plates above and below the display. These can easily be removed for engraving, or if requested they can be supplied engraved with any units of measurement and tag information. Each plate can accommodate:

- 1 row of 9 alphanumeric characters 10mm high
- or 1 row of 11 alphanumeric characters 7mm high
- or 2 rows of 18 alphanumeric characters 5mm high

8.2 Alarms

The BA524C can be supplied with two solid state single pole alarm outputs which may be independently programmed as high or low alarms with normally open or normally closed outputs. Fig 8 illustrates the conditions available and shows which are fail safe, i.e. output is in the alarm condition (open) when the 4/20mA input current is zero. When an alarm is activated the indicator display alternates between the measured value and an alarm identification.




Fig 8 Alarm outputs

Programmable functions for each alarm include adjustable setpoint, hysteresis, alarm delay and alarm accept.

8.2.1 Solid state output

Each alarm has a galvanically isolated single pole solid state switch output which is shown in Fig 9. The output is polarised and current will only flow in one direction.




Fig 9 Equivalent circuit of each alarm output

8.2.2 Programming and adjustment

When an alarm card is added to a BA524C the main programme menu is extended as shown in Fig 11. The additional functions appear between 'Cond' and 'C--P' in the main menu. For simplicity Fig 11 only shows the additional functions available on alarm 1, but alarm 2 has identical facilities.

The following table summaries each of the alarm programme functions and includes a cross reference to more detailed information. Again only the functions on alarm 1 are listed, but alarm 2 has identical facilities




Fig 10 Typical alarm application

Summary of programmable alarm functions

Display	Description of function
'EnbL'	Alarm enable Enables or disables the alarm function without changing the alarm parameters. See section 8.2.3
'SP1'	Alarm setpoint 1 Adjusts the alarm setpoint. The alarm is activated when the indicator display equals the setpoint See section 8.2.4
'HI.LO'	Alarm function Defines whether the alarm has a high or low function See section 8.2.5
'no.nc'	Normally open or normally closed output Determines whether the single pole alarm output is open or closed in the alarm condition. See section 8.2.6
'HStr'	Hysteresis Adjusts the alarm hysteresis. See section 8.2.7
'dELA'	Alarm delay time Adjusts the delay between the display equalling the setpoint and the alarm output being activated. See section 8.2.8
'SIL'	Alarm silence time Defines the time that the alarm output remains in the non-alarm condition following acceptance of an alarm. See section 8.2.9
'AcSP'	Access setpoint Sub-menu which enables direct access to the alarm setpoints from the indicator display mode, and defines a separate security code. See section 8.2.10

8.2.3 Alarm enable: EnbL

This function allows the alarm to be enabled or disabled without altering any of the alarm parameters. To check or change the function select 'EnbL' from the alarm menu and press *P* which will reveal the current setting. The function can be changed by pressing the *Up* or *Down* button followed by the *E* button to return to the alarm menu.

8.2.4 Setpoint adjustment: SP1 and SP2

The setpoint of each alarm may be positioned anywhere between -19999 and 19999 providing this corresponds to an input current between 3.8 and 20.2mA. e.g. If the indicator has been calibrated to display 0 with 4mA input and 10000 with 20mA input, the two alarm setpoints may be positioned anywhere between -125 and 10125.

To adjust the setpoint select 'SP1' or 'SP2' from the alarm menu and press *P* which will reveal the existing alarm setpoint. Each digit of the setpoint can be adjusted using the *Up* and *Down* push-buttons, and the *P* button to move to the next digit. When the required setpoint has been entered press *E* to return to the alarm menu.

8.2.5 Alarm function: HI.LO

Each alarm can be conditioned as a high or low alarm. To check or change the alarm function select 'HI.LO' from the alarm menu and press *P* to reveal the current setting. The function can be changed by pressing the *Up* or *Down* buttons followed by the *E* button to return to the alarm menu.

8.2.6 Alarm output status: no.nc

This function allows the alarm output to be open or closed in the alarm condition. When deciding which is required, care must be taken to ensure that the alarm output is fail safe.

See Fig 8.

WARNING

When the 4/20mA supply is removed both alarm outputs will open irrespective of conditioning. Therefore for fail safe operation both alarm outputs should be programmed to be open in the alarm condition.

To check or change the alarm output status select 'no.nc' from the alarm menu and press *P* reveal the current setting. The function can be changed by pressing the *Up* or *Down* button followed by the *E* button to return to the alarm menu.

8.2.7 Hysteresis: HStr

During programming hysteresis is shown in the units the indicator has been calibrated to display. To adjust the hysteresis, select 'HStr' from the alarm menu and press *P* which will reveal the existing figure. Each digit can be adjusted using the *Up* and *Down* push-buttons, and the *P* button to move to the next digit. When the required hysteresis has been entered, press *E* to return to the alarm menu.

e.g. An indicator calibrated to display 0 to 10000, with a high alarm set at 9000 and hysteresis of 200 will perform as follows:

High alarm will be activated when display equals or exceeds 9000, but will not reset until the display falls below 8800.

8.2.8 Alarm delay: dELA

This function enables activation of the alarm output to be delayed for a fixed time following the alarm condition occurring. The delay can be programmed in 1 second increments up to 3600 seconds. If a delay is not required zero should be entered. To adjust the delay select 'dELA' from the alarm menu and press *P* which will reveal the existing delay. Each digit of the delay can be adjusted using the *Up* and *Down* push-buttons, and the *P* button to move to the next digit. When the required delay has been entered, press *E* to return to the alarm menu.

8.2.9 Alarm silence time: SIL

This function is primarily intended for use in small installations where the alarm output directly operates an annunciator such as a sounder. When the alarm silence time is set to any figure other than zero, the *P* push-button becomes an alarm accept button. After an alarm has occurred, operating the *P* button will cause the alarm output to revert to the non-alarm condition for the programmed alarm silence time. The display will continue to indicate an alarm after it has been accepted and silenced. The alarm silence time may be adjusted between 0 and 3600 seconds in 1 second increments.

To adjust the alarm silence time select 'SIL' from the alarm menu and press *P* which will reveal the existing time. Each digit can be adjusted using the *Up* and *Down* push-buttons, and the *P* button to move to the next digit. When the required time has been entered press *E* to return to the alarm menu.

8.2.10 Access Setpoint: AcSP

This function controls a separate menu which provides direct access to the alarm setpoints when the indicator is in the display mode. See section 8.2.11 for a full description. An operator may therefore adjust the alarm setpoints without having access to the programme and alarm menus. Further protection is provided by a separate security code.

This direct access menu is enabled and a separate security code entered from the 'AcSP' function in the programme menu as shown in Fig 11. To change the menu parameters select 'AcSP' from the programme menu and press *P* which will display the enable prompt 'Enbl'. Press *P* again to reveal if the direct access menu is 'On' or 'OFF'. The *Up* or *Down* buttons will toggle the display between the two conditions.

If 'OFF' is selected, the operator will not have access to the setpoints from the display mode. Return to the 'AcSP' prompt in the main menu by pressing *E* twice.

If 'On' is selected, the operator will have direct access to the alarm setpoints from the display mode via a separate optional security code. To define the four digit numerical code press *P* to return to the 'Enbl' prompt followed by the *Up* or *Down* button to select the access code prompt 'AcCd'. Pressing *P* will reveal the current security code. Each digit of the code may be changed by operating the *Up* and *Down* push-buttons, and the *P* button to move to the next digit. When the required code has been entered, press *E* twice to return to the 'AcSP' prompt in the Programme Menu.

Code 0000 will disable the security code allowing direct access to the setpoints by pressing the *P* and *Up* buttons simultaneously.

New instruments with alarms are supplied with this function disabled and the security code set to 0000

8.2.11 Adjusting alarm setpoints from the display mode

Access to the alarm setpoints from the indicator display mode is obtained by operating the *P* and *Up* push-buttons simultaneously as shown in Fig 12. If the setpoints are not protected by a security code the alarm setpoint prompt 'SP1' will be displayed. If the setpoints are protected by a security code, 'CCode' will be displayed first. Pressing *P* again will enable the alarm security




Fig 11 Alarm programme menu

code to be entered digit by digit using the *Up* and *Down* buttons to change the flashing digit, and the *P* push-button to move to the next digit. If the correct code is entered pressing *E* will cause alarm setpoint prompt 'SP1' to be displayed. Pressing the *Up* or *Down* button will toggle the display between the two alarm setpoint prompts 'SP1' and 'SP2'.

If an incorrect security code is entered, or a button is not pressed, after ten seconds the indicator will automatically return to the display mode.




Fig 12 Setpoint adjustment from the display mode

To adjust an alarm setpoint select 'SP1' or 'SP2' and press *P* which will reveal the current setting. Each digit of the setpoint may be adjusted using the *Up* and *Down* push-buttons, and the *P* button to move to the next digit. When the required setpoint has been entered, pressing *E* will return the display to the 'SP1' or 'SP2' prompt from which the other setpoint may be selected, or the indicator may be returned to the display mode by pressing *E* again.

Direct access to the alarm setpoints is only available when the menu is enabled - see section 8.2.10

8.3 Lineariser

The indicator can be supplied with a sixteen point lineariser which may be adjusted to compensate for almost any non linear variable. For example, a level signal from a horizontal cylindrical tank may be linearised by the indicator to display the tank contents in linear volumetric units.

Fig 13 shows a typical linearising characteristic. Up to sixteen break-points may be programmed to occur at any input current between 4 and 20mA. The slope between adjacent break-points may be set anywhere between -1250 and +1250 display counts per milliamp. Greater slopes may be programmed, but the indicator performance will be degraded. A linear characteristic can be obtained by programming just two points, one at 4mA and the other at 20mA.




Fig 13 Typical indicator characteristic

The lineariser software does not change the main programme menu, but the 'CAL' and 'SE' functions are extended as shown in Fig 14. As with a linear indicator, calibration may be performed with an external calibrator using the 'CAL' function, or from the internal references using the 'Set' function.

8.3.1 Calibration using an external current source

This method allows direct calibration with a current source, and is preferred when traceability is required. If the exact system non-linearity is unknown, the method also allows direct calibration from the variable to be displayed, e.g. The output from a level sensor in an irregular tank may be displayed in linear volumetric units by filling the tank with known incremental volumes and calibrating the indicator to display the sum of the increments at each break-point.

The number of break-points required should first be entered using the Add and dEL functions. In both these functions the indicator initially displays the current break-point and the total number of break-points being used. e.g.

5	13
current break-point	total number of break-points

'Add' Add a break-point

Adds a new break-point before the displayed break-point. The calibration of existing break-points is not changed, but the identification number of all subsequent break-points is increased by one.

'dEL' Remove a break-point

Removes the displayed break-point and joins the preceding break-point to the following break-point with a straight line. The identification number of all subsequent break-points is decreased by one.

To add a break-point select 'CAL' from the main menu and press *P* to enter the 'Add' function; press *P* again to reveal the current and total number of break-points. Each subsequent operation of the *P* push-button will introduce an additional break-point. When adding a break-point to a calibrated indicator, the insertion position can be selected using the *Up* and *Down* push-buttons.

The delete break-point function dEL operates in a similar manner to the Add function described above.

When the required number of break-points has been entered, return to the sub-menu by pressing *E*. The indicator will display 'Add' or 'dEL' depending upon the last function used. Each break-point can now be programmed.

Select 'PtS' from the sub-menu and press *P* which will select the first break-point '0 n', where n is the total number of break-points entered. The selected break-point can be changed using the *Up* and *Down* buttons. When the required break-point has been selected press *P*. Set the indicator input current to the exact value at which the break-point is to occur, and adjust the indicator display using the *Up* and *Down* buttons and *P* to move between digits. When the

required display has been set, press *E* to enter the information and return to the sub-menu from which another break-point can be selected.

Repeat this procedure for each break-point, and then return to the main menu by pressing *E* twice.

8.3.2 Calibration using internal references

This function enables the break-points to be adjusted without the need for an accurate external current source. Throughout calibration the indicator input current may be any value between 4 and 20mA.

The accuracy of this method depends upon the accuracy of the internal references which should be calibrated periodically against a traceable external current source with a resolution of at least 0.4µA. See section 5.7.2

The number of break-points required should first be entered using the Add and dEL functions. In both these functions the indicator initially displays the current break-point and the total number of break-points being used. e.g.

5	13
current break-point	total number of break-points

'Add' Add a break-point

Adds a new break-point before the displayed break-point. The calibration of existing break-points is not changed, but the identification number of subsequent break-points is incremented.

'dEL' Remove a break-point

Removes the displayed break-point and joins the preceding break-point to the following break-point with a straight line. The identification of subsequent break-points is decremented.

'inPut' Defines the current at which break-point occurs

Enables the required current at each break-point to be defined without having to input an accurate input current to the indicator.

'disP' Defines display at break-point

Enables the indicator display at each break-point to be defined.

Select 'SET' from the main menu and press *P* once to enter the 'Add' function, and again to reveal the current and total number of break-points. Each subsequent operation of the *P* push-button will introduce an additional break-point. When adding a break-point to a calibrated indicator, the insertion position can be selected using the *Up* and *Down* push-buttons.

The delete break-point function 'dEL' operates in a similar manner to the 'Add' function described above.

When the required number of break-points has been entered, return to the sub-menu by pressing *E*. The indicator will display 'Add' or 'dEL' depending upon the last function used. The required indicator display at each break-point can now be entered, followed by the input current at which each break-point occurs.

To enter the required display at any break-point select 'diSP' from the sub-menu and press *P* which will select the first break-point '0 n'. The selected break-point can be changed using the *Up* and *Down* buttons. When the required break-point has been selected, press *P* to reveal the existing display. Using the *Up* and *Down* buttons and *P* to move between digits set the revised display. Press *E* to return to the sub-menu from which another break-point can be selected. Repeat this procedure for all the break-point displays to be changed, and then return to the 'diSP' prompt in the sub-menu by pressing *E*.

To enter the input current at which each break-point occurs select 'InPut' from the sub-menu and press *P* which will select the first break-point '0 n'. The selected break-point can be changed using the *Up* and *Down* buttons. When the required break-point has been selected, press *P* to reveal the input current at which the break-point occurs. Using the *Up* and *Down* buttons and *P* to move between digits set the revised input current. Press *E* to return to the sub-menu from which another break-point can be selected.

Repeat this procedure for all the break-point input currents to be changed, and then return to the 'InPut' prompt in the sub-menu by pressing *E*.




Fig 14 Lineariser programme structure

8.4 Tare function

The tare function is a factory fitted software accessory, primarily intended for use with weighing systems.

When the tare software is installed, pushing and holding the *P* button for more than approximately 3 seconds sets the indicator display to zero, irrespective of the input current, and activates the tare annunciator on the indicator display. Subsequent operation of the *P* push-button for less than 3 seconds will toggle the indicator between the normal gross display and the net display with the tare annunciator activated.

The tare function allows an operator to quickly zero the indicator display at any input current so that subsequent readings only show the change in input since the *P* push-button was operated. When used with a weighing system, it allows the weight of a container to be automatically subtracted from the total gross weight so that only the net weight of the contents is displayed.

8.5 Display backlight

The BA524C can be supplied with LED backlighting to improve display contrast when the indicator is installed in poorly illuminated areas. The backlight is electrically isolated from the 4/20mA display circuit and may be powered from any 18 to 30V dc supply.

8.6 Pipe mounting kits

Three pipe mounting kits are available for securing the BA524C to a horizontal or vertical pipe.

- BA391 Zinc plated steel bracket secured by two worm drive hose clips. Versions available for 40 to 60mm and 60 to 80mm outside diameter pipes.
- BA392 As BA391 but in stainless steel.
- BA393 Heavy duty stainless steel bracket secured by a single 'V' bolt. Will clamp to any pipe with an outside diameter between 40 and 80mm.

8.7 Panel mounting kit

The BA394 stainless steel panel mounting kit will secure a BA524C indicator into a panel aperture, but it does not seal the joint between the indicator enclosure and the instrument panel.




Fig 15 Backlight power supply

The brilliance of the backlight may be reduced by using a supply voltage below the recommended minimum, or by fitting a current limiting resistor in series with the supply.