


# BA364G and BA364E

## Two Input Intrinsically safe Counter

Issue 7



## CONTENTS

1. **Description**
2. **Operation**
  - 2.1 Initialisation
  - 2.2 Controls
  - 2.3 Displays
3. **Intrinsic Safety Certification**
  - 3.1 ATEX & UKEX gas certification
  - 3.2 Zones, gas groups & T rating
  - 3.3 Special conditions for safe use
  - 3.4 Power supply
  - 3.5 Pulse input terminals
    - 3.5.1 Sensors that do not require energising.
    - 3.5.2 Sensors that do require energising.
  - 3.6 Remote reset terminals
  - 3.7 Certification label information
4. **System Design for Hazardous Areas**
  - 4.1 Use with Zener barriers
    - 4.1.1 Power supply
    - 4.1.2 Pulse input
    - 4.1.3 Switch contact input
    - 4.1.4 2-wire proximity detector input
    - 4.1.5 Open collector
    - 4.1.6 Magnetic pick-off input
    - 4.1.7 Voltage pulse input
    - 4.1.8 Remote reset
  - 4.2 Use with galvanic isolators
    - 4.2.1 Power supply
    - 4.2.2 Pulse input
    - 4.2.3 Switch contact input
    - 4.2.4 2-wire proximity detector input
    - 4.2.5 Open collector
    - 4.2.6 Magnetic pick-off input
    - 4.2.7 Voltage pulse input
    - 4.2.8 Remote reset
5. **Installation**
  - 5.1 Location
  - 5.2 Installation procedure
  - 5.3 EMC
  - 5.4 Units of measurement and tag marking on scale card.
6. **Configuration and Calibration**
  - 6.1 Calibration structure
  - 6.2 Accessing configuration functions
  - 6.3 Summary of configuration functions
  - 6.4 Input A: , nPUL-R
  - 6.5 Input A type: , nPULSE
  - 6.6 Input A debounce: dEBOUN[E
  - 6.7 Input b: , nPUL-b
  - 6.8 Input b type: , nPULSE
  - 6.9 Input b debounce: dEBOUN[E
  - 6.10 Input A pulse counting edge: [nLEDG-R
  - 6.11 Input b pulse counting edge: [nLEDG-b
  - 6.12 Display update interval: uPDRLE
  - 6.13 Counting function: [count
  - 6.14 Upper display: d, SP-1
  - 6.15 Lower display: d, SP-2
  - 6.16 Position of the decimal points: dP
  - 6.17 Total scale factor: SCAL.E.L
  - 6.18 Rate scale factor: SCAL.E.r
  - 6.19 Timebase: t-bRSE
  - 6.20 Display filter: F, LLEr
  - 6.21 Direction of count: uP or dn
  - 6.22 Reset value: [Lr URl
  - 6.23 Local reset: Lr [Lr
  - 6.24 Local total reset: [Lr tOt
  - 6.25 Local grand total reset: [Lr GtOt
  - 6.26 Reset grand total from configuration menu: [Lr GtOt
  - 6.27 Security code: [odE
  - 6.28 Reset configuration to factory defaults: rSEt dEF
  - 6.29 Display overflow
7. **Pulse Output**
  - 7.1 Intrinsic safety
  - 7.2 System design
  - 7.3 Configuration
  - 7.4 Access Pulse output sub-menu: PULSE oP
  - 7.5 Enable pulse output: Enbl
  - 7.6 Source of output pulse: Source[E
  - 7.7 Divide output pulse frequency: d, U, dE
  - 7.8 Output pulse width: durRt, on
8. **Configuration example**

The BA364G and BA364E are CE marked to show compliance with the European Explosive Atmospheres Directive 2014/34/EU and the European EMC Directive 2014/30/EU.

They are also UKCA marked to show compliance with UK statutory requirements Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres Regulations UKSI 2016:1107 (as amended) and with the Electromagnetic Compatibility Regulations UKSI 2016:1091 (as amended).

## 9. Maintenance

- 9.1 Fault finding during commissioning
- 9.2 Fault finding after commissioning
- 9.3 Servicing
- 9.4 Routine maintenance
- 9.5 Guarantee
- 9.6 Customer comments

## Appendix 1

ATEX & UKEX Dust certification

## Appendix 2

IECEX certification

## Appendix 3

ETL & cETL certification gas and dust certification.

## Appendix 4

BA364E Two input Counter

## 10. Accessories

- 10.1 Units of measurement and instrument identification.

### 10.2 Backlight

### 10.3 Alarms

- 10.3.1 Solid state output
- 10.3.2 Intrinsic safety
- 10.3.3 Summary of configuration functions.
- 10.3.4 Alarm enable: `ENBL`
- 10.3.5 Type of alarm: `TYPE`
- 10.3.6 Setpoint adjustment: `SP1x & SP2x`
- 10.3.7 Alarm function: `HLA`
- 10.3.8 Alarm output status: `NO.NC`
- 10.3.9 Hysteresis: `HSTr`
- 10.3.10 Alarm delay: `DELt`
- 10.3.11 Alarm silence time: `StL`
- 10.3.12 Flash display when alarm occurs: `FLSH`
- 10.3.13 Access Setpoint: `RESP`
- 10.3.14 Adjusting alarm setpoints from display mode.

### 10.4 4/20mA output

- 10.4.1 Intrinsic safety
- 10.4.2 System design
- 10.4.3 Configuration and calibration
- 10.4.4 Access 4/20mA output sub-menu: `4-20 oP`
- 10.4.5 Enable 4/20mA output: `ENBL`
- 10.4.6 Select rate or total source: `4-20tYPE`
- 10.4.7 Display which corresponds to 4mA output: `4.000`
- 10.4.8 Define display for 20mA output

## 1. DESCRIPTION

The BA364G and BA364E are field mounting, intrinsically safe two input Counters which will accept pulses on one or both inputs. Both may be configured to show one of the following totals in engineering units on their eight digit displays:

Input A + Input b

Input A - Input b

Input A direction controlled by Input b

Quadrature input  
(Input A and Input b electrically 90° apart)

A smaller six digit display may be activated to show the composite pulse rate in engineering units per second, minute or per hour.

In addition to simple counting applications, the quadrature input decoder allows the direction of movement and position of a shaft or cable to be displayed.

The optically-isolated pulse output may be configured to synchronously retransmit either of the two inputs or a scaled output when least significant digit of the total display is incremented.

This instruction manual supplements the abbreviated instruction sheet supplied with each instrument.

The BA364G and the BA364E are functionally identical and have similar certifications, but differ in mechanical construction and options. The differences are summarised in the following table.

	BA364G	BA364E
Separate terminal compartment.	No	Yes
Pulse output	Yes	Yes
Backlight	Option	Yes
4/20mA output.	Option	Yes
Dual alarms	Option	Yes
<b>Certification</b>		
IECEX	Gas & dust	Gas
ATEX & UKEX	Gas & dust	Gas
ETL & cETL	Gas & dust	Gas & dust

The main sections of this instruction manual describe the BA364G, but also apply to the BA364E. Details of the BA364E mounting and terminals are contained in Appendix 4.

The BA364G and BA364E have ATEX & UKEC intrinsic safety certification and comply with the European ATEX Directive and the UK statutory requirements. The BA364G has gas and dust certification, but the BA364E only has ATEX & UKEX gas certification.

The main sections of this manual describe ATEX & UKEX gas certification. ATEX & UKEX dust certification of the BA364G is described in Appendix 1.

For international applications the BA364G and BA364E also have IECEx certification which is described in Appendix 2. The BA364E does not have IECEx dust certification.

For applications in the USA and Canada the BA364G and BA364E Counters have ETL & cETL certification which is described in Appendix 3.

## 2. OPERATION

Fig 1 shows a simplified block diagram of the BA364G Counter. The instrument has two inputs, A and b, which can be individually configured to accept pulses from most types of sensor. The BA364G can display the total number of pulses received from each input, or their sum or difference, together with associated rates on a separate display.




Fig 1 BA364G block diagram

The BA364G can be supplied with any of the following factory fitted accessories:

Internally powered display backlight

Dual isolated alarms

Isolated 4/20mA output



## 2.1 Initialisation

Each time power is applied to a BA364G Counter initialisation is performed. After a short delay the following display sequence occurs:

All segments of the display are activated

Counter starts functioning, using the configuration information stored in the instrument's permanent memory. Unless total and grand total displays have been reset, new pulses will be added to the existing totals.

## 2.2 Controls

The BA364G Counter is controlled and configured via four front panel push buttons. In the display mode i.e. when the instrument is counting the push button functions are:

### Push Button Functions

**[E] + [▼]** Grand total - shows Ld followed by least significant 8 digits of the 16 digit grand total.

**[E] + [▲]** Grand total - shows H, followed by the most significant 8 digits of the 16 digit grand total.  
If Local Grand Total Reset [Lr] [tst] in the instrument configuration menu has been activated, operating the **[E]** and **[▲]** buttons simultaneously for ten seconds will result in [Lr.no] being displayed with the no flashing. Operating the **[▲]** or **[▼]** button will change the display to [Lr.yE5], the **[E]** button will then reset the grand total to zero which will be confirmed by a brief display of [Lr.d]. See 6.25

**[▼] + [▲]** If Local Total Reset [Lr] [tst] in the instrument configuration menu has been activated, operating the **[▼]** and **[▲]** buttons simultaneously for three seconds will reset the total display to zero and clear any pulses stored in the optional pulse output.  
See 6.24

**[P] + [▼]** Shows in succession firmware version number, instrument function ZCH [ntr] and any output accessories that are fitted:

- A Dual alarm outputs
- P Pulse output (always fitted)
- C 4/20mA output

**[P] + [E]** Access to configuration menu

**Note:** When optional alarms are fitted, the BA364G Counter may be configured to provide direct access to the alarm setpoints from the display mode when the **[P]** and **[▲]** buttons are operated simultaneously. See 10.3.13 and 10.3.14

## 2.3 Displays

The BA364G Counter has two digital displays and associated annunciators, plus a pulse input indicator as shown on the front cover of this manual.

**Total display** Shows the total pulse count on the upper eight digit display. May be reset via front panel push buttons or by a remote reset switch.

**Rate display** Shows the pulse rate on the lower six digit display. Total and rate displays may be reversed.

**Pulse input indicator.** This disc in the lower left hand corner of the display 'rotates' for two seconds each time an input pulse is received on either input. Appears to rotate continuously when combined input frequency on both inputs exceeds 0.5Hz.

**Reset annunciator** Activated while the total display is being reset via the front panel push buttons, or the external reset terminals.

**Rate annunciator** Identifies rate display

**Total annunciator** Identifies total display

**RTx annunciator** Retransmitted pulse annunciator.  
Depends upon the setting of Source in the pulse output configuration menu.

### **SCALE#**

Annunciator activated each time pulse output open collector is on, i.e. Ron is less than 60Ω + 3V.

### **dr EE:**

Annunciator continuously activated.

### 3. INTRINSIC SAFETY CERTIFICATION

The BA364G Counter has IECEx, ATEX, UKEX and ETL gas and dust certification. This section of the instruction manual describes ATEX & UKEX gas certification. Dust, IECEx and other approvals are each described in separate appendixes to this manual.

#### 3.1 ATEX & UKEX gas certification

The BA364G has ATEX & UKEX Ex ia certification for use in gas and dust atmospheres. The Counter carries both the EU community CE and the UKCA marks, subject to local codes of practice, it may be installed in any of the European Economic Area (EEA) member countries and in the UK.

This section of the instruction manual describes ATEX & UKEX installations in explosive gas atmospheres conforming with EN 60079-14 *Electrical installations design, selection and erection*. When designing systems the local Code of Practice should be consulted.

#### 3.2 Zones, gas groups and T rating

The BA364G Counter has been certified Ex ia IIC T5 Ga  $-40^{\circ}\text{C} \leq T_a \leq +70^{\circ}\text{C}$ . When connected to a suitable system it may be installed in:

Zone 0	explosive gas air mixture continuously present.
Zone 1	explosive gas air mixture likely to occur in normal operation.
Zone 2	explosive gas air mixture not likely to occur, and if it does will only exist for a short time.

Be used with gases in groups:

Group	A	propane
Group	B	ethylene
Group	C	hydrogen

Having a temperature classification of:

T1	450°C
T2	300°C
T3	200°C
T4	135°C
T5	100°C

At ambient temperatures between  $-40$  and  $+70^{\circ}\text{C}$ .

The specified operating temperature of the BA364G Counter is  $-40$  to  $+70^{\circ}\text{C}$ . At temperatures below  $-20^{\circ}\text{C}$  the instrument will continue to count, but the display digits will change increasingly slowly and the contrast will be reduced.

This allows the BA364G Counter to be installed in all gas Zones and to be used with most common industrial gases except carbon disulphide and ethyl nitrite which have an ignition temperature of  $95^{\circ}\text{C}$ .

#### 3.3 Special conditions for safe use

The ATEX certificate has an 'X' suffix indicating that special conditions apply for installation in Zone 0.

**When installed in a Zone 0 potentially explosive atmosphere requiring EPL Ga apparatus, the instrument shall be installed such that even in the event of rare incidents, an ignition source due to impact or friction between the aluminium label and iron/steel is excluded.**

No special conditions apply when the BA364G Counter is installed in Zone 1 or in Zone 2.

#### 3.4 Power supply

When installed in a hazardous area the BA364G Counter should be powered via a certified Zener barrier or galvanic isolator from a dc supply located in the safe area, or from associated apparatus with an intrinsically safe output.

The input safety parameters of terminals 1 and 2 are:

U <sub>i</sub>	=	28V dc
I <sub>i</sub>	=	200mA dc
P <sub>i</sub>	=	0.84W

Any certified Zener barrier or galvanic isolator with output safety parameters equal to or less than these limits may be used.

The maximum equivalent capacitance and inductance between terminals 1 and 2 is:

C <sub>i</sub>	=	2nF
L <sub>i</sub>	=	4μH

To determine the maximum permissible cable parameters the above figures, which are small and may be ignored in many applications, should be subtracted from the maximum permitted cable parameters specified for the Zener barrier or galvanic isolator powering the BA364G Counter.

### 3.5 Pulse input terminals

The BA364G Counter has two pulse inputs, A and b, that may be individually configured for use with most types of sensor. Each input is a separate intrinsically safe circuit, although the negative side of each input is internally connected to the negative side of the power supply and reset terminal RS2. See Fig 1. The two inputs should not be connected in parallel.

Some types of sensor that may be connected to the BA364G inputs, such as a switch contact or a 2-wire proximity detector, require energising to determine their state. For sensors requiring energising fitting an external link between terminals 3 & 4 of the BA364G for input A and between terminals 7 & 8 for input b, connects an internal 7V, 6mA supply to the respective input. Energising is not required when a BA364G input is connected to a voltage pulse source.

Fitting an energising link changes the output safety parameters of each BA364G input as shown in the following table which also shows the types of sensor requiring energising (link fitting).

Type of input	Link*	Output safety parameters of each input.		
		Uo	Io	Po
Switch contact	Yes	10.5V	9.2mA	24mW
Proximity detector	Yes	10.5V	9.2mA	24mW
Open collector	Yes	10.5V	9.2mA	24mW
Magnetic pick-off	No	1.1V	0.5mA	0.2mW
Voltage input (low)	No	1.1V	0.5mA	0.2mW
Voltage input (high)	No	1.1V	0.5mA	0.2mW

\*For input A link terminals 3 and 4

\*For input b link terminals 7 and 8

#### 3.5.1 Sensors that do not require energising

Magnetic pick-offs and voltage pulse inputs do not require energising, see section 3.5. For intrinsic safety purposes, sources of energy with output parameters less than 1.5V; 100mA and 25mW are considered to be *simple apparatus* as defined by EN 60079-11.

When terminals 3 & 4 and terminals 7 & 8 are not linked, the associated BA364G Counter input complies with the requirements for *simple apparatus*. This allows the output parameters of the Counter pulse input to be ignored when assessing the safety of the sensor connected to the Counter input.

This allows almost any certified intrinsically safe voltage pulse or certified magnetic pick-off to be directly connected to one of the BA364G Counter inputs.

The BA364G ATEX & UKEX certificates specify that the equivalent capacitance and inductance of each BA364G Counter input are:

$$\begin{aligned} C_i &= 2\text{nF} \\ L_i &= 4\mu\text{H} \end{aligned}$$

To determine the maximum permissible cable parameters these figures should be subtracted from the maximum permitted cable parameters specified for the sensor connected to the input terminals of the Counter. However, the Counter input parameters are very small and they are unlikely to make any significant difference to the allowable cable parameters.

#### 3.5.2 Sensors that require energising

Switch contacts, proximity detectors and open collector inputs require energising as described in section 3.5. When energised, the output parameters of each BA364G Counter input are:

$$\begin{aligned} U_o &= 10.5\text{V} \\ I_o &= 9.2\text{mA} \\ P_o &= 24\text{mW} \end{aligned}$$

These parameters do not comply with the requirements for *simple apparatus* and should be included when assessing the safety of the circuits connected to the inputs of the BA364G Counter.

Any certified intrinsically safe sensor or *simple apparatus* may be connected to an energised BA364G Counter input providing that the sensor's input parameters are equal to, or greater than, the output safety parameters of the BA364G Counter input which are shown above. This is not restrictive and most sensors will comply.

This allows most mechanically operated switch contacts, certified open collector transistors and intrinsically safe NAMUR proximity detectors to be directly connected to a BA364G Counter input. The sensor should be located within the same hazardous area as the Counter and, together with associated wiring, be able to withstand a 500V rms insulation test to earth.

The maximum capacitance and inductance that may be safely connected to each Counter input when energised (link connected) is:

$$\begin{aligned} C_o &= 2.4\mu\text{F} \\ L_o &= 200\text{mH} \end{aligned}$$

Again this is not restrictive and most sensors will comply.

### 3.6 Remote reset terminals

The BA364G Counter may be reset to zero by connecting the reset terminals RS1 and RS2 together for more than one second. These two terminals have the following input and output safety parameters:

Uo	=	3.8V
Io	=	1mA
Po	=	1mW
Ui	=	28V dc
Ii	=	200mA dc
Pi	=	0.84W

The equivalent capacitance and inductance between them is:

Ci	=	0nF
Li	=	0μH

The maximum capacitance and inductance that may be safely connected between the reset terminals RS1 and RS2 is:


Co	=	40μF
Lo	=	1H

The total Counter display may be reset to zero from within the hazardous area by any mechanically operated switch contact connected directly to terminals RS1 and RS2. To reset the total display from the safe area a Zener barrier or intrinsically safe relay is required to transfer the contact closure into the hazardous area. Almost any intrinsically safe relay with certification permitting the contacts to be connected to equipment in the hazardous area may be used. A positive diode return Zener barrier is not suitable for this application.

Alternatively, the BA364G Counter may be configured so that the total display is reset to zero when the ▼ and ▲ push buttons are operated simultaneously for more than three seconds. See 6.24.

### 3.7 Certification label information

The certification information label is fitted in a recess on the top outer surface of the instrument enclosure. It shows the IECEx, ATEX and UKEX certification information, plus BEKA associates name and location and the instrument model number. Non European certification information may also be included.



BA364G Certification information label

## 4. SYSTEM DESIGN FOR HAZARDOUS AREAS

### 4.1 Use with Zener barriers

Zener barriers are the least expensive intrinsically safe interface between a safe and hazardous area. However they require a high integrity earth connection that may be expensive to install and they do not provide isolation. When a high integrity earth connection is not already available, it may be less expensive and complicated to use galvanic isolators for the installation of a single BA364G Counter.

Terminals 2, 6, 10 and RS2 of the BA364G Counter are internally connected together. If any of these terminals are earthed, as shown in Figs 2 & 3, the other terminals should only be connected to the same earth, i.e. the barrier busbar, or to circuits that have 500V rms insulation to earth.

Any certified Zener barriers may be used with the BA364G Counter providing their output parameters do not exceed the input parameters of the terminals to which they are connected. Only one polarity of Zener barrier i.e. positive or negative, may be used in each Counter system.

Fig 2 illustrates the basic circuit that is used for all BA364G Counter installations protected by Zener barriers. For simplicity, connections for the pulse output and optional alarms and 4/20mA output are shown separately in sections 7 and 10 of this manual.




Fig 2 BA364G used with Zener barriers

Alternatively the pulse sources may be located in the safe area. Fig 3 shows how an additional Zener barrier is used to transfer the signal to the Counter in the hazardous area. When more than one Zener barrier is used in a system all must have the same polarity. i.e. all positive or all negative barriers.

When designing a system it is important to remember that terminals 2, 6, 10 and RS2 are interconnected within the BA364G. See Fig 1.




Fig 3 BA364G used with Zener barriers pulse source in safe area.

### 4.1.1 Power supply

The BA364G Counter requires a minimum of 10V between terminal 1 & 2 and consumes:

	10mA	without optional backlight
plus	16mA	for optional backlight
plus	6mA	when terminals 3 & 4 are linked
plus	6mA	when terminals 7 & 8 are linked

Any certified Zener barrier may be used to power a BA364G Counter providing the output safety parameters of the barrier are equal to or less than the input safety parameters of terminals 1 & 2 of the BA364G Counter.

Although this allows a wide variety of barriers to be used, a positive polarity 28V; 93mA; 300Ω Zener barrier, which has an end-to-end resistance of about 340Ω, is an industry standard device which is frequently used. With this barrier the supply voltage in the safe area, with both counter inputs energised, must be between 17.5V and the maximum working voltage of the Zener barrier which, depending upon manufacturer, will be approximately 26V. The minimum voltage increases to 23V if a display backlight is fitted.

#### 4.1.2 Pulse input

As shown in Fig 2 the BA364G can count pulses from a wide variety of sensors in the hazardous area, or from the safe area as shown in Fig 3.

No Zener barrier is required in series with each input if the intrinsically safe pulse source is located within the same hazardous area as the BA364G Counter. The following table shows the switching thresholds for the various types of sensor. For reliable counting the pulse input must fall below the lower threshold and rise above the upper threshold.

Input sensor	Switching thresholds	
	Lower	Upper
Switch	100Ω	1000Ω
Proximity detector	1.2mA	2.1mA
Open collector	2kΩ	10kΩ
Magnetic pick-off	0mV	40mV peak
Voltage pulse low	1.0V	3.0V
Voltage pulse high	3.0V	10.0V

#### 4.1.3 Switch contact input

Any mechanically activated switch contact located in the same hazardous area as the BA364G Counter may be directly connected to the pulse input terminals 5 & 6 or 9 & 10 providing the switch and associated wiring can withstand a 500V rms insulation test to earth. Most magnetically activated reed relays comply with these requirements. The BA364G contains a configurable debounce circuit to prevent contact bounce being counted.

See section 6.6 for details of debounce configuration and the typical maximum counting frequency.

#### 4.1.4 2-wire proximity detector input

Most certified intrinsically safe 2-wire proximity detectors complying with NAMUR switching thresholds may be connected to the BA364G Counter inputs, providing the input safety parameters of the proximity detector are equal to or greater than the output safety parameters of the Counter inputs i.e.

$$\begin{aligned} U_i &\geq 10.5V \text{ dc} \\ I_i &\geq 9.2mA \text{ dc} \\ P_i &\geq 24mW \end{aligned}$$

and the minimum operating voltage of the proximity detector is less than 7.5V.

See section 6.6 for details of the typical maximum counting frequency.

#### 4.1.5 Open collector input

Most certified open collector sensors located in the same hazardous area as the BA364G Counter may be directly connected to pulse input terminals 5 & 6 and 9 & 10 providing the sensor and associated wiring can withstand a 500V rms insulation test to earth. The open collector device must comply with the requirements for *simple apparatus* or have input safety parameters equal to or greater than:

$$\begin{aligned} U_i &\geq 10.5V \text{ dc} \\ I_i &\geq 9.2mA \text{ dc} \\ P_i &\geq 24mW \end{aligned}$$

See section 6.6 for details of the typical maximum counting frequency.

#### 4.1.6 Magnetic pick-off input

$\text{L}_{0,1}$  in the input configuration menu is a low level voltage pulse input intended for use with magnetic pick-off sensors producing an ac output. For a  $\text{L}_{0,1}$  input the pulse input terminals 5 & 6 and 9 & 10 of the BA364G Counter comply with the requirements of *simple apparatus* allowing connection to any certified intrinsically safe magnetic pick-off within the hazardous area having output parameters equal to or less than:

$$\begin{aligned} U_o &\leq 28V \text{ dc} \\ I_o &\leq 200mA \text{ dc} \\ P_o &\leq 0.84W \end{aligned}$$

The maximum permitted cable parameters will be defined by the magnetic pick-off's intrinsic safety certificate less the Counter's input parameters  $C_i$  and  $L_i$  which are small and can often be ignored.

See section 6.6 for details of the typical maximum counting frequency.

#### 4.1.7 Voltage pulse input

Two voltage pulse input ranges are selectable in the configuration menu,  $U_{0,1} \leq 5 \text{ L}$  and  $U_{0,1} \leq 5 \text{ H}$ . When configured for either of the voltage pulse ranges, the pulse input terminals 5 & 6 and 9 and 10 of the BA364G Counter comply with the requirements of *simple apparatus* allowing connection to any intrinsically safe voltage source within the hazardous area having output parameters equal to or less than:

$$\begin{aligned} U_o &\leq 28V \text{ dc} \\ I_o &\leq 200mA \text{ dc} \\ P_o &\leq 0.84W \end{aligned}$$

The maximum permitted cable parameters will be defined by the voltage source intrinsic safety certificate less the BA364G Counter input parameters which are small and can often be ignored.

See section 6.6 for details of the typical maximum counting frequency.

#### 4.1.8 Remote reset

The BA364G Counter total display may be remotely reset to zero by connecting terminals RS1 & RS2 together for more than one second. Permanent interconnection inhibits counting. Remote resetting may be accomplished by any mechanically operated switch located in the same hazardous area as the Counter providing it and the associated wiring can withstand a 500V rms insulation test to earth. No Zener barrier is required.

A BA364G may also be remotely reset from the safe area. Any switch may be used but a Zener barrier is required to transfer the contact closure into the hazardous area which may be combined with the supply barrier so that only one package is required. A diode return barrier is not suitable for this application. Fig 2 illustrates how the BA364G total display may be reset from both the safe and the hazardous area.

**Note:** The BA364G can be configured to reset the total display to zero when the ▼ and ▲ push buttons are operated simultaneously for more than three seconds - see 6.24.

#### 4.2 Use with Galvanic Isolators

Galvanic isolators are probably the simplest intrinsically safe interface to install as they provide isolation and do not require a high integrity earth connection.

Any certified galvanic isolator with output parameters less than the input parameters of the BA364G having the correct function may be used.




Fig 4 BA364G protected by galvanic isolators.

Fig 4 illustrates the basic circuit that is used for all BA364G Counter installations protected by galvanic isolators. For simplicity, connections for the pulse output, optional alarms and 4/20mA output are shown separately in sections 7 and 10 of this manual.

Alternatively the pulse source may be located in the safe area. Fig 5 shows how an additional galvanic isolator is used to transfer the signal to the BA364G Counter in the hazardous area, although it may be difficult to find isolators for some sensors.




Fig 5 Pulse source in safe area

#### 4.2.1 Power supply

The BA364G Counter requires a minimum of 10V between terminal 1 & 2 and consumes 10mA plus 6mA for each input that is energised, a maximum total of 22mA if both inputs are energised. The optional backlight increases the current consumption by 16mA. Any certified galvanic isolator may be used to power a BA364G Counter providing the output safety parameters of the isolator are equal to or less than the input safety parameters of terminals 1 & 2 of the BA364G Counter. These requirements are not restrictive and allow a wide range of galvanic isolators, such as solenoid drivers, to be used.

#### 4.2.2 Pulse input

As shown in Fig 4 the BA364G can count pulses from a wide variety of sensors in the hazardous area, or from the safe area as shown in Fig 5.

No galvanic isolator is required in series with the input if the intrinsically safe pulse source is located within the same hazardous area as the BA364G Counter.

The following table shows the switching thresholds for the various types of sensor. For reliable counting the pulse input must fall below the lower threshold and rise above the upper threshold.

Input sensor	Switching thresholds	
	Lower	Upper
<b>Switch</b>	100Ω	1000Ω
<b>Proximity detector</b>	1.2mA	2.1mA
<b>Open collector</b>	2kΩ	10kΩ
<b>Magnetic pick-off</b>	0mV	40mV peak
<b>Voltage pulse low</b>	1.0V	3.0V
<b>Voltage pulse high</b>	3.0V	10.0V

#### 4.2.3 Switch contact input

Any mechanically activated switch contact located in the same hazardous area as the BA364G Counter may be directly connected to pulse input terminals 5 & 6 or 9 & 10 providing the switch and associated wiring can withstand a 500V rms insulation test to earth. Most magnetically activated reed relays comply with these requirements. The BA364G contains a configurable debounce circuit to prevent contact bounce being counted. Three levels of debounce protection are independently available. See section 6.6.

See section 6.6 for details of the typical maximum counting frequency.

#### 4.2.4 2-wire proximity detector input

Most certified intrinsically safe 2-wire proximity detectors complying with NAMUR switching thresholds may be connected to the BA364G Counter inputs, providing the input safety parameters of the proximity detector are equal to or greater than the output safety parameters of the Counter inputs i.e.

$$\begin{aligned}
 U_i &\geq 10.5V \text{ dc} \\
 I_i &\geq 9.2mA \text{ dc} \\
 P_i &\geq 24mW
 \end{aligned}$$

and the minimum operating voltage of the proximity detector is less than 7.5V.

See section 6.6 for details of the typical maximum counting frequency.



#### 4.2.5 Open collector input

Most certified open collector sensors located in the same hazardous area as the BA364G Counter may be directly connected to pulse input terminals 5 & 6 or 9 & 10 providing the sensor and associated wiring can withstand a 500V rms insulation test to earth. The open collector device must comply with the requirements for *simple apparatus* or have input safety parameters equal to or greater than:

$U_i$	>	10.5V dc
$I_i$	>	9.2mA dc
$P_i$	>	24mW

See section 6.6 for details of the typical maximum counting frequency.

#### 4.2.6 Magnetic pick-off input

$U_{OL}$  in the input configuration menu is a low level voltage pulse input intended for use with magnetic pick-off sensors producing an ac output. For a  $U_{OL}$  input the pulse input terminals 5 & 6 or 9 & 10 of the BA364G Counter comply with the requirements of *simple apparatus* allowing connection to any certified intrinsically safe magnetic pick-off within the same hazardous area as the Counter having output parameters equal to or less than:

$U_o$	≤	28V dc
$I_o$	≤	200mA dc
$P_o$	≤	0.84W

The maximum permitted cable parameters will be defined by the magnetic pick-off's intrinsic safety certificate less the Counter's input parameters  $C_i$  &  $L_i$  which are small and can often be ignored.

See section 6.6 for details of the typical maximum counting frequency.

#### 4.2.7 Voltage pulse input

Two voltage pulse input ranges are selectable in the configuration menu,  $U_{OLLS} L$  and  $U_{OLLS} H$ . When configured for either of the voltage pulse ranges, the pulse input terminals 5 & 6 or 9 & 10 of the BA364G Counter comply with the requirements of *simple apparatus*. This allows direct connection to any intrinsically safe voltage source within the same hazardous area as the Counter having output parameters equal to or less than:

$U_o$	≤	28V dc
$I_o$	≤	200mA dc
$P_o$	≤	0.84W



The maximum permitted cable parameters will be defined by the voltage source intrinsic safety certificate less the BA364G Counter input parameters which are small and can usually be ignored.

See section 6.6 for details of the typical maximum counting frequency.

#### 4.2.8 Remote reset

The BA364G Counter's total display may be remotely reset by connecting terminals RS1 & RS2 together for more than one second. Permanent interconnection inhibits totalisation. Remote resetting may be accomplished by any mechanically operated switch located in the same hazardous area as the Counter providing it and the associated wiring can withstand a 500V rms insulation test to earth. No galvanic isolator is required.

A BA364G Counter may also be remotely reset to zero from the safe area. Any switch may be used but a galvanic isolator or IS relay is required to transfer the contact closure into the hazardous area. Almost any device with a contact that may be connected to equipment in the hazardous area may be used for this application. Fig 4 illustrates how a BA364G Counter may be reset from both the safe and the hazardous area.

**Note:** The BA364G can also be configured to reset the total display when the  and  push buttons are operated simultaneously for more than three seconds - see 6.24.

## 5. INSTALLATION

### 5.1 Location

The BA364G Counter is housed in robust IP66 glass reinforced polyester (GRP) enclosure incorporating an armoured glass window and stainless steel fittings making it suitable for exterior mounting in most industrial on-shore and off-shore installations. The Counter should be positioned where the display is not in continuous direct sunlight. Special conditions apply for Zone 0 installations, see section 3.3.

Field wiring terminals are located on the rear of the Counter assembly as shown in Fig 7.

To ensure electrical continuity between the two conduit or cable entries, the enclosure is fitted with a bonding plate which includes an M4 earth stud. This may be mounted on the inside or outside of the enclosure. If the carbon loaded GRP enclosure is not bolted to an earthed post or structure, this earth stud should be connected to a local earth or the plant potential equalising conductor.


An insulated M4 stud is provided in the bottom right hand corner of the back-box for interconnecting cable screens.

The BA364G Counter may be pipe mounted using a BA393G pipe mounting kit, or panel mounted using a BA394G or BA395G panel mounting kit.

### 5.2 Installation Procedure


Fig 6 illustrates the instrument installation procedure.

- Remove the Counter assembly by unscrewing the four captive 'A' screws.
- Mount the enclosure back-box on a flat surface and secure with screws or bolts through the four 'B' holes. Alternatively use one of the pipe or panel mounting kits which are available as accessories.
- Remove the temporary hole plug and install an appropriate IP and temperature rated M20 x 1.5mm cable gland or conduit fitting. If two entries are required, the supplied IP66 stopping plug should be replaced with an appropriate IP and temperature rated M20 x 1.5mm cable gland or conduit fitting.
- Connect the field wiring to the terminals as shown in Fig 7. Replace the instrument assembly on the back-box and evenly tighten the four 'A' screws.




#### Step A

Unscrew the four captive 'A' screws and separate the indicator assembly and the back-box.




#### Step B

Secure the enclosure back-box to a flat surface with M6 screws through the four 'B' holes. Alternatively use a pipe mounting kit.



#### Step C

Remove the temporary hole plug and install an appropriate IP rated cable gland or conduit fitting. Feed the field wiring through the cable entry.



#### Step D

Terminate field wiring on the indicator assembly. Replace the indicator assembly on the enclosure back-box and tighten the four 'A' screws.

Fig 6 BA364G installation procedure





Fig 7 Dimensions and terminal connections

### 5.3 EMC

The BA364G complies with the requirements of the European EMC Directive and the UK Statutory Requirements. For specified immunity all wiring should be in screened twisted pairs, with the screens earthed at one point in the safe area.

### 5.4 Units of measurement and tag marking on scale card.

The Counter's units of measurement and tag information are shown on a scale card which slides into the instrument.

New Counters are supplied with a printed scale card showing the requested units of measurement and tag information. If this information is not supplied when the instrument is ordered, a blank scale card will be fitted which can easily be marked on-site with a dry transfer or a permanent marker. Custom printed scale cards are available from BEKA associates as an accessory.

To remove the scale card from a Counter carefully pull the transparent tab at the rear of the instrument assembly away from the assembly as shown in Fig 8a.




Fig 8a Removing scale card

To replace the scale card carefully insert it into the slot on the right hand side of the input terminals as shown in Fig 8b. Force should be applied evenly to both sides of the scale card to prevent it twisting. The card should be inserted until about 2mm of the transparent tab remains protruding.




Fig 8b Inserting scale card into the instrument assembly.

## 6.0 CONFIGURATION & CALIBRATION

The BA364G Counter is configured and calibrated via four front panel push buttons. All the configuration functions are contained in an easy to use intuitive menu that is shown diagrammatically in Fig 10.

Each menu function is summarised in section 6.3 of this manual and each summary includes a reference to more detailed information.

The isolated pulse output, including configuration, is described in section 7 of this manual. When factory fitted optional alarms and the optional 4/20mA output are included, additional functions appear in the configuration menu which are described in section 10 of this manual.

All new BA364G Counters are supplied calibrated as requested at the time of ordering. If calibration is not requested, Counters will have default configuration as shown in the following table, but can easily be re-configured on-site.

Function	Display	Default
Input A	INP. TYPE	oP. CoL
Debounce	dEBouNCE	dEFRAULt
Input b	INP. TYPE	oP. CoL
Debounce	dEBouNCE	dEFRAULt
Counting edge A	CntEdG-A	EdGE 1
Counting edge b	CntEdG-b	EdGE 1
Update	uPdRtE	Q5
Count	Count	Rb
Upper display	d1 SP-1	totRL
Lower display	d1 SP-2	on
Decimal point	dP	Rate 00000.0 Total 00000000
Total scale factor	SCALE.t	00 1.00
Rate scale factor	SCALE.r	00 1.00
Timebase	t-bRSE	tB-0 1
Filter	F, LTER	24
Counter direction	uP or dN	uP
Clear value	CLr VAL	00000000
Local clear	CLr CLr	
Local total reset	CLr tot	oFF
Local grand total reset	CLr Gtot	oFF
Security code	CoDE	0000

**Note:** While the instrument is being configured counting continues so that any input pulses occurring during this time are recorded.

### 6.1 Calibration structure

Fig 9 shows the calibration structure of the BA364G Counter. The two pulse inputs are processed by the count function to produce a single output having the selected arithmetic function, such as the sum of pulse input A and pulse input b. This output is passed to the SCALE.r and SCALE.t functions allowing the rate and total displays to have different engineering units.

SCALE.t is a dividing factor that converts the output from the Counter function into the required total display in engineering units. e.g. if the output from the Counter function is two pulses per pump stroke and a total display of thousands of pump strokes is required, SCALE.t should be set to 2000.

SCALE.r is a dividing factor that converts the output from the Counter function into a rate display with the required engineering units. e.g. if the output from the Counter function is two pulses per pump stroke and it is required to display the pump stroke rate, SCALE.r should be set to 2.

The timebase t-bRSE is a multiplying factor that determines if the instrument displays rate per second, per minute or per hour.

The BA364G uses 'real' decimal points. Moving the position of a decimal point in a scale factor will affect the instrument calibration.

















Fig 9 Calibration structure

## 6.2 Accessing configuration functions

Throughout this manual the instrument front panel push buttons are shown as , ,  and  and legends displayed by the instrument are shown in a seven segment font as displayed by the Counter e.g. *F1LLEr* and *5RLER*.

Access to the configuration menu is obtained by operating the  and  push buttons simultaneously. If the instrument is not protected by a security code the first parameter *IPUL-R* will be displayed. If a security code other than the default code *0000* has already been entered, the instrument will display *LoDE*. Press  to clear this prompt and enter the security code for the instrument using the  or  push button to adjust the flashing digit, and the  push button to transfer control to the next digit. If the correct code has been entered pressing  will cause the first parameter *IPUL-R* to be displayed. If an incorrect code is entered, or a push button is not operated within ten seconds, the instrument will automatically return to the display mode.

All configuration functions and prompts are shown on the upper eight digit display.

Once within the configuration menu the required function can be selected by scrolling through the menu using the  and  push buttons. The configuration menu is shown diagrammatically in Fig 10.

When returning to the display mode following reconfiguration, the BA364G Counter will display *dRER* followed by *SRUE* while the new information is stored in permanent memory.

If after accessing the configuration menu the interval between operating any front panel push button exceeds one minute, the BA364G will automatically return to the display mode and any configuration changes will not be stored in permanent memory. When making changes to multiple configuration functions, it is therefore sensible to occasionally return to the display mode to save the changes that have already been made.

## 6.3 Summary of configuration functions

This section summarises all the configuration functions. When read in conjunction with Fig 10 it provides a quick aid for configuring the Counter. If more detail is required, each summary contains a reference to a full description of the function.

Display	Summary of function
<i>IPUL-R</i>	Contains sub-menu with two functions: <i>IP.ETYPE</i> Select Input type <i>dEBOUNCE</i> Set debounce <b>See section 6.4</b>
<i>IP.ETYPE</i>	[for Input-A] Configures input-A to accept one of six types of input: <i>oP.LoL</i> Open collector * <i>UoLLE5 L</i> Voltage pulse <1 >3V <i>UoLLE5 H</i> Voltage pulse <3 >10V <i>Lo, L</i> Magnetic pick-off <i>Pr.dEt</i> Proximity detector * <i>LoNtRLE</i> Switch contact *  * Link terminals 3 & 4 <b>See section 6.5</b>
<i>dEBOUNCE</i>	[for Input-A] Defines level of input debounce applied to the pulse input A to prevent false counting: <i>dEFRAULt</i> <i>HERUY</i> <i>L, GHE</i> <b>See section 6.6</b>
<i>IPUL-b</i>	Contains sub-menu with two functions: <i>IP.ETYPE</i> Select Input type <i>dEBOUNCE</i> Set debounce <b>See section 6.7</b>
<i>IP.ETYPE</i>	[for Input-b] Configures input-b to accept one of six types of input: <i>oP.LoL</i> Open collector * <i>UoLLE5 L</i> Voltage pulse <1 >3V <i>UoLLE5 H</i> Voltage pulse <3 >10V <i>Lo, L</i> Magnetic pick-off <i>Pr.dEt</i> Proximity detector * <i>LoNtRLE</i> Switch contact *  * Link terminals 7 & 8 <b>See section 6.8</b>

Display	Summary of function
	<p><b>dEBounce</b> [for Input-b] Defines level of input debounce applied to the pulse input b to prevent false counting:              dEFAULt              HERUy              L, GHt</p> <p><b>See section 6.9</b></p>
<b>CountG-A</b>	<p><b>Input A pulse counting edge</b> Defines whether the Counter is incremented/decremented on the leading or trailing edge of a pulse on input A.  <b>See section 6.10</b></p>
<b>CountG-b</b>	<p><b>Input b pulse counting edge</b> Defines whether the Counter is incremented/decremented on the leading or trailing edge of a pulse on input b.  <b>See section 6.11</b></p>
<b>uPdAtE</b>	<p><b>Display update interval</b> Defines the interval between display updates between 0.5 and 5 seconds.  <b>See section 6.12</b></p>
<b>Count</b>	<p><b>Counting function</b> Defines the arithmetic relationship of the two pulse inputs. The total display can be derived from:</p> <p>    <b>Rb</b>      Input A + Input b</p> <p>    <b>R-b</b>      Input A - Input b</p> <p>    <b>R Con b</b> Input A controlled by Input b.</p> <p>    <b>R rEL b</b> Quadrature input (for position display)</p> <p><b>See section 6.13</b></p>
<b>d, SP- 1</b>	<p><b>Upper display</b> Defines whether rAtE or tOtAL is shown on the upper display. The other variable will be shown on the lower display, providing the lower display is on in function d, SP-2.  <b>See section 6.14</b></p>

Display	Summary of function
<b>d, SP-2</b>	<p><b>Lower display</b> Turns the lower display, which normally shows rate, on or off.  <b>See section 6.15</b></p>
<b>dP</b>	<p><b>Position of decimal points</b> Defines the position of the decimal point in both the total and rate displays.  <b>See section 6.16</b></p>
<b>SCALE.t</b>	<p><b>Total Scale Factor</b> SCALE.t is a dividing factor that converts the pulse output from arithmetic Count function into the required total display in engineering units. SCALE.t may be adjusted between 0.0001 and 99999. e.g. if one pulse represents 1 centimetre of dispensed cable and the total display is required in metres, SCALE.t should be set to 100.0 which is the number of centimetres in a metre.          The total display is independent of the rate display.  <b>See section 6.17</b></p>
<b>SCALE.r</b>	<p><b>Rate scale factor</b> SCALE.r is a dividing factor that converts the pulse output from the arithmetic Count function into the required rate display in engineering units. SCALE.r may be adjusted between 0.0001 and 99999. e.g. if one pulse represents 2 pump strokes and the rate display is required in pump strokes, SCALE.r should be set to 0.5.          The rate display is independent of the total display.  <b>See section 6.18</b></p>
<b>t-bASE</b>	<p><b>Timebase</b> Selectable multiplier allowing rate to be displayed in units per second, per minute or per hour.          Select:</p> <p>    <b>tb-01</b>    for rate / second</p> <p>    <b>tb-50</b>    for rate / minute</p> <p>    <b>tb-3600</b>   for rate / hour</p> <p><b>See section 6.19</b></p>

Display	Summary of function
---------	---------------------



<b>FILTEr</b>	<p><b>Display filter</b></p> <p>Is an adjustable digital filter to reduce the noise on the rate display. The filter has two parameters each represented by a digit adjustable between 0 and 9. The first digit defines the amount of filtering applied to the display, the second digit the deviation from the displayed rate at which the filter will be overridden and the rate display will move rapidly to the new value.</p> <p><b>See section 6.20</b></p>
---------------	--

<b>uP or dn</b>	<p><b>Direction of count</b></p> <p>Determines whether pulses at inputs A and b increment or decrement the total display.</p> <p><b>See section 6.21</b></p>
-----------------	--

<b>CLr VAL</b>	<p><b>Reset value</b></p> <p>Defines a preset number to which the total display will be set when the BA364G Counter is locally or remotely reset. Enables the instrument to count down from a preset number.</p> <p><b>See section 6.22</b></p>
----------------	---



<b>LoC CLr</b>	<p><b>Local clear</b></p> <p>Contains sub-menu with two functions enabling the total and the grand total to be reset via the front panel push buttons while the Counter is in the display mode.</p> <p><b>See section 6.23</b></p>
----------------	--

**CLr tot**

When **on** is selected total display is reset when  and  buttons are operated simultaneously for more than 3 seconds in the display mode.

**See section 6.24**

**CLr Gtot**

When **on** is selected the grand total may be reset when  and  buttons are operated simultaneously for more than 10 seconds in the display mode - see section 2.2 for details.

**Note:** Once reset, the grand total can not be restored.


**See section 6.25**

Display	Summary of function
---------	---------------------

<b>CLr Gtot</b>	<p><b>Resets grand total to zero from within configuration menu.</b></p> <p>This function resets the grand total to zero from within the configuration menu when <b>CLr GEE</b> is selected.</p> <p><b>Note:</b> Once reset, the grand total can not be recovered.</p> <p><b>See section 6.26</b></p>
-----------------	---

<b>Code</b>	<p><b>Access code</b></p> <p>Defines a four digit alphanumeric code that must be entered to gain access to the configuration menu. Default code 0000 disables the security function and allows unrestricted access to all configuration functions.</p> <p><b>See section 6.27</b></p>
-------------	---

<b>rSEt dEF</b>	<p><b>Reset to factory defaults</b></p> <p>Returns the BA364G Counter to the factory defaults shown in section 6.0 To prevent accidental use the request must be confirmed by entering <b>SurE</b> before the reset will be executed.</p> <p><b>See section 6.28</b></p>
-----------------	--




\* Followed by identical function for input b  
 Unless otherwise specified menu functions are shown on the upper display

Fig 10 Configuration menu



Pulse output & when fitted optional  
alarms and 4/20mA appear here



<p><b>Timebase</b></p> <p>▼ or ▲ to select rate display timebase.</p> <p>t-b-01 for pulses/sec</p> <p>t-b-60 for pulses/min</p> <p>t-b-3600 for pulses/hour</p>	<p><b>Filter input</b></p> <p>▼ or ▲ to adjust value of each digit and (P) to transfer control to the next digit.</p> <p>First digit: filter magnitude</p> <p>Second digit: step response</p> <p><b>Note:</b> While making adjustments the filtered rate display is shown on lower display so stability can be assessed</p>	<p><b>Direction of count</b></p> <p>▼ or ▲ to toggle between uP and dn</p>	<p><b>Reset value</b></p> <p>▼ or ▲ to adjust value of each digit and (P) to transfer control to the next digit</p>	<p><b>Local total reset</b></p> <p>▼ or ▲ to turn the local total reset function on or oFF. When on, total display may be reset when ▼ and ▲ are pressed simultaneously for more than 3 seconds in the display mode</p>	<p><b>Local grand total reset</b></p> <p>▼ or ▲ to turn the local grand total reset function on or oFF. When on, grand total display may be reset when (E) and ▲ are pressed simultaneously for more than 10 seconds in the display mode</p>	<p><b>Grand total reset</b></p> <p>press ▼ or ▲ to select CLr.YES to reset grand total to zero.</p> <p>Confirm instruction by entering SurE. Press ▼ or ▲ to adjust each digit and (P) to move to next digit</p>	<p><b>Define Security Code</b></p> <p>Enter by pressing ▼ or ▲ and (P) to move to next digit.</p> <p>Default code 0000 allows direct access to configuration menu</p>	<p><b>Reset configuration to factory defaults</b></p> <p>Confirm instruction by entering SurE. Press ▼ or ▲ to adjust each digit and (P) to move to next digit</p>
---	---	--	---	---	--	--	---	--

## 6.4 Input A: $\text{Input-A}$

The Input A function contains two sub-functions  $\text{Input-A type}$  and  $\text{Debounce}$  that define the type of input and the amount of input noise rejection.

## 6.5 Input A type: $\text{Input-A type}$

$\text{Input-A type}$  is a sub-menu in the  $\text{Input-A}$  function which defines the type of input sensor or input pulse that the instrument will count at Input-A. To check or change the type of input, select  $\text{Input-A}$  in the configuration menu and press  $\text{P}$  which will reveal the  $\text{Input-A type}$  prompt, pressing  $\text{P}$  again will show the existing Input-A setting. If set as required press  $\text{E}$  twice to return to the configuration menu, or repeatedly press the  $\text{Down}$  or  $\text{Up}$  button until the required type of input is displayed and then press  $\text{E}$  twice to return to the configuration menu.

One of following six types of input may be selected:

		Switching thresholds	
		Low	High
$\text{Open collector}^2$	Open collector <sup>2</sup>	2	10k $\Omega$
$\text{Voltage pulse low}^1$	Voltage pulse low <sup>1</sup>	1	3V
$\text{Voltage pulse high}^1$	Voltage pulse high <sup>1</sup>	3	10V
$\text{Magnetic pick-off}$	Magnetic pick-off	0	40mV
$\text{Proximity detector}^2$	Proximity detector <sup>2</sup>	1.2	2.1mA
$\text{Switch contact}^2$	Switch contact <sup>2</sup>	100	1000 $\Omega$

### Notes:

1. Maximum voltage input +28V.
2. For sensors connected to Input-A that require energising i.e. proximity detectors, switch contacts or open collector sensors, terminals 3 & 4 of the BA364G should be linked together.
3. To count correctly, the input pulse must fall below the lower switching threshold and rise above the higher switching threshold.
4. See section 6.6 for typical maximum counting frequency.

## 6.6 Input A debounce: $\text{Debounce}$

$\text{Debounce}$  is an adjustable sub-menu in both the  $\text{Input-A}$  and  $\text{Input-B}$  functions which prevents the input miscounting when the input pulse has noisy edges, such as those resulting from a mechanical contact closing and bouncing. The debounce function only applies to the input in which the function is located.

Three levels of protection may be independently selected for each input. The amount of debounce applied depends upon the type of Counter input that has been selected for the input in the associated  $\text{Input-A type}$  function.

Select  $\text{Input-A}$  or  $\text{Input-B}$  in the configuration menu and press  $\text{P}$  which will reveal the  $\text{Input-A type}$  prompt, press the  $\text{Down}$  or  $\text{Up}$  button to select  $\text{Debounce}$  followed by  $\text{P}$  to reveal the existing setting. Pressing the  $\text{Down}$  or  $\text{Up}$  button will scroll through the three levels. When the required level has been selected, pressing  $\text{E}$  twice will enter the selection and return the display to the configuration menu.

The following table shows the minimum time that the input pulse must be continuously above the upper input switching threshold and continuously below the lower switching threshold to ensure that the Counter processes the input pulse. Input switching thresholds are shown in section 4.1.2.

debounce level	Min input pulse width	
	Type of Input	
	Contact	All others
<b>Default</b>	1600 $\mu$ s	40 $\mu$ s
<b>Heavy</b>	3200 $\mu$ s	350 $\mu$ s
<b>Light</b>	400 $\mu$ s	5 $\mu$ s

The maximum counting frequency of the BA364G depends upon the debounce level selected, the shape of the input pulse and its amplitude. The following table assumes a square wave input and is included for guidance. The maximum counting frequency will be lower if the input pulses have sloping edges and the pulse amplitude only slightly exceeds the input switching thresholds.

ONLY FOR GUIDANCE		
debounce level	Max counting frequency	
	Type of input	
	Contact	All others
<b>Default</b>	250Hz	12kHz
<b>Heavy</b>	120Hz	2kHz
<b>Light</b>	1000Hz	100kHz

Minimum input counting frequency is 0.01Hz. Below this frequency the rate display will be forced to zero.

### 6.7 Input b: $\text{Input-b}$

The Input b function contains two sub-functions  $\text{Input-type}$  and  $\text{Debounce}$  that define the type of input and the amount of input noise rejection.

### 6.8 Input b type: $\text{Input-type}$

$\text{Input-type}$  is a sub-menu in the  $\text{Input-b}$  function which defines the type of input sensor or input pulse that the instrument will count at Input-b. To check or change the type of input, select  $\text{Input-b}$  in the configuration menu and press  $\text{P}$  which will reveal the  $\text{Input-type}$  prompt, pressing  $\text{P}$  again will show the existing Input-b setting. If set as required press  $\text{E}$  twice to return to the configuration menu, or repeatedly press the  $\text{Down}$  or  $\text{Up}$  button until the required type of input is displayed and then press  $\text{E}$  twice to return to the configuration menu.

One of following six types of input may be selected:

		Switching thresholds	
		Low	High
$\text{Open collector}^2$	Open collector <sup>2</sup>	2	10k $\Omega$
$\text{Voltage pulse low}^1$	Voltage pulse low <sup>1</sup>	1	3V
$\text{Voltage pulse high}^1$	Voltage pulse high <sup>1</sup>	3	10V
$\text{Magnetic pick-off}$	Magnetic pick-off	0	40mV
$\text{Proximity detector}^2$	Proximity detector <sup>2</sup>	1.2	2.1mA
$\text{Switch contact}^2$	Switch contact <sup>2</sup>	100	1000 $\Omega$

#### Notes:

1. Maximum voltage input +28V.
2. For sensors connected to Input-b that require energising i.e. proximity detectors, switch contacts or open collector sensors, terminals 7 & 8 of the BA364G should be linked together.
3. To count correctly, the input pulse must fall below the lower switching threshold and rise above the higher switching threshold.
4. See section 6.6 for the maximum counting frequency.

### 6.9 Input b debounce: $\text{Debounce}$

Exactly as input A, please see section 6.6

### 6.10 Input A pulse counting edge: $\text{Counting-A}$

This function allows the edge on which a count occurs to be selected. It applies to input A for all counting modes except quadrature ( $\text{Quadrature}$ ).

To check or change the input A pulse edge on which the count occurs select  $\text{Counting-A}$  from the configuration menu and press  $\text{P}$  which will reveal  $\text{Edge 1}$  or  $\text{Edge 2}$ . If required press the  $\text{Down}$  or  $\text{Up}$  button to change the setting, followed by the  $\text{E}$  button to return to the configuration menu.

#### Edge 1

Type of input	Counting edge
Voltage	Low to high
Switch contact	Closed to open
Open collector	Closed to open
Proximity detector	High to low current

#### Edge 2

Type of input	Counting edge
Voltage	High to low
Switch contact	Open to closed
Open collector	Open to closed
Proximity detector	Low to high current

#### Note:

The counting edge function  $\text{Counting-A}$  is not included in the configuration menu when the BA364G Counter has a quadrature input  $\text{Quadrature}$ . In quadrature mode the instrument will count up when the rising edge of input-b leads the rising edge of input-A.  
See section 6.13.

### 6.11 Input b pulse counting edge: $\text{Counting-b}$

This function allows the edge on which a count occurs to be selected. It applies to input b for all counting modes except quadrature  $\text{Quadrature}$  and input A controlled by input b  $\text{A controlled by b}$ .

To check or change the input b pulse edge on which the count occurs select  $\text{Counting-b}$  from the configuration menu and press  $\text{P}$  which will reveal  $\text{Edge 1}$  or  $\text{Edge 2}$ . If required press the  $\text{Down}$  or  $\text{Up}$  button to change the setting, followed by the  $\text{E}$  button to return to the configuration menu.

#### Edge 1

Type of input	Counting edge
Voltage	Low to high
Switch contact	Closed to open
Open collector	Closed to open
Proximity detector	High to low current

#### Edge 2

Type of input	Counting edge
Voltage	High to low
Switch contact	Open to closed
Open collector	Open to closed
Proximity detector	Low to high current

**Note:**

The counting edge function  $\text{Count} \rightarrow b$  is not included in the configuration menu when the BA364G Counter has a quadrature input  $R \rightarrow EL \ b$  or when input A is controlled by input b  $R \rightarrow \text{Dir} \ b$ . In quadrature mode the instrument will count up when the rising edge of input-b leads the rising edge of input-A.

See section 6.13.

**6.12 Display update interval:  $\text{Update} \rightarrow$** 

If either the rate or the total display is likely to change rapidly, a longer interval between display updates may simplify reading. This function allows one of six different display intervals between 0.5 and 5 seconds to be selected. The selected display update interval does not affect the update time of any other instrument function.

To adjust the update interval select  $\text{Update} \rightarrow$  from the configuration menu and press **P** to reveal the current update interval. Pressing the **▼** or **▲** button will scroll through the six times. When the required interval has been selected press **E** to enter the selection and return to the configuration menu.

**6.13 Counting function:  $\text{Count} \rightarrow$** 

This function defines the arithmetic relationship between Inputs A and Input b. The following four modes may be selected:

Display	Input count mode						
$R \rightarrow b$	Pulses at input A added to pulses at input b.						
$R \rightarrow -b$	Pulses at input b subtracted from pulses at input A. *						
$R \rightarrow \text{Dir} \ b$	Input b controls count direction of input A. *						
	<table> <tr> <th>Input b</th><th>Input A</th></tr> <tr> <td>Low</td><td>Up counter</td></tr> <tr> <td>High</td><td>Down counter</td></tr> </table>	Input b	Input A	Low	Up counter	High	Down counter
Input b	Input A						
Low	Up counter						
High	Down counter						
$R \rightarrow EL \ b$	Quadrature input with sensors electrically 90° apart. *						

\* The pulse output is not available with these count modes.

Fig 11 shows the voltage waveforms at the two inputs and the resulting total display when the BA364G is configured to count up on a rising edge.




Fig 11 Counting waveforms

**Note:**

For a quadrature input the two signals do not require equal marks and spaces to achieve reliable counting.

**6.14 Upper display:  $\text{d} \rightarrow 5P \rightarrow$** 

Usually the total count is shown on the larger upper eight digit display, but this function reverses the display locations allowing rate to be shown on the larger upper display and total on the smaller lower display.

To check the setting for the display, select  $\text{d} \rightarrow 5P \rightarrow$  from the configuration menu and press **P** which will reveal if the display is showing  $\text{Rate} \rightarrow$  or  $\text{Total} \rightarrow$ . The setting can be changed by pressing the **▼** or **▲** button followed by the **E** button to enter the selection and return to the configuration menu.

### 6.15 Lower display: $dP-2$

This function turns the lower display *on* or *off*. When turned *off*, the BA364G will only have one eight digit display which may be configured in the  $dP-1$  function to show the total count or rate.

To check the setting for the lower display, select  $dP-2$  from the configuration menu and press  $\boxed{P}$  that will reveal if the lower display is *on* or *off*. The setting may be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  button followed by the  $\boxed{E}$  button to enter the selection and return to the configuration menu.

### 6.16 Position of the decimal points: $dP$

The upper and lower displays have eight and six digits respectively. This function enables the position of the decimal point in both displays to be independently positioned as shown below.

#### Upper display

<b>Total</b>	0 0 0.0.0.0.0	1 of 5 positions or absent
<b>Rate</b>	0.0.0.0.0	1 of 4 positions or absent

#### Lower display

<b>Total</b>	0.0.0.0.0.0	1 of 5 positions or absent
<b>Rate</b>	0.0.0.0.0	1 of 4 positions or absent

To adjust the position of the decimal points select  $dP$  from the configuration menu and press  $\boxed{P}$ . The upper display defined as the rate or total display by function  $dP-1$  (section 6.14) will be activated and identified by the display annunciator as Rate or Total. The decimal point, which may be positioned as shown in the table above, is moved by operating the  $\blacktriangledown$  or  $\blacktriangle$  push button. The  $\blacktriangledown$  button moves the position of the decimal point to the left and the  $\blacktriangle$  button moves the decimal point position to the right.

When the decimal point in the upper display has been positioned pressing the  $\boxed{P}$  button will transfer control to the lower display variable, but it will be shown and annunciated on the larger upper display. The position of the decimal point may be positioned in the same way by operating the  $\blacktriangledown$  and  $\blacktriangle$  push buttons. When both decimal points are positioned as required, enter the settings and return to the configuration menu by operating the  $\boxed{E}$  button.

#### Note:

Adjustment of a decimal point position will disable the following outputs which must be re-enabled after the adjustment is complete:

Pulse output

Optional Alarm outputs

Optional 4/20mA output

### 6.17 Total scale factor: $SCALE.t$

$SCALE.t$  is a dividing factor adjustable between 0.0001 and 99999 that enables the total to be displayed in engineering units. e.g. if one pulse from the arithmetic count function represents 1 centimetre of dispensed cable and the total display is required in metres,  $SCALE.t$  should be set to 100.0 which is the number of centimetres in a metre. If just the total number of input pulses is required,  $SCALE.t$  should be set to 1.0. The total display is independent of the rate display.

To check or change the total scale factor select  $SCALE.t$  from the configuration menu and press  $\boxed{P}$  which will reveal the existing value with one digit flashing. The value of the flashing digit may be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  button. When this digit has been adjusted as required, pressing  $\boxed{P}$  will transfer control to the next digit. When all the digits have been adjusted pressing  $\boxed{P}$  will transfer control to the decimal point that may be positioned between any of the digits, or may be omitted by moving it to the right of the least significant digit. When the total scale factor has been entered, press  $\boxed{P}$  to return to the  $SCALE.t$  prompt in the configuration menu.

#### Note:

Adjustment of  $SCALE.t$  will disable the following outputs which must be re-enabled after the adjustment is complete:

Pulse output

Optional Alarm outputs

Optional 4/20mA output

### 6.18 Rate scale factor: $SCALE.r$

$SCALE.r$  is a dividing factor adjustable between 0.0001 and 99999 that enables the rate display to be shown in engineering units. e.g. if one pulse from the arithmetic count function represents 2 pump strokes and the rate display is required in pump strokes,  $SCALE.r$  should be set to 0.5. If just the rate of input pulses is required,  $SCALE.r$  should be set to 1.0. The rate display is independent of the total display.

The units of the rate display are counts per unit of time. The unit of time is the timebase of the instrument which is determined by  $t-BASE$  described in section 6.19.

To check or change the rate scale factor select  $SCALE.r$  from the configuration menu and press  $\boxed{P}$  which will reveal the existing value with one digit flashing. The value of the flashing digit may be adjusted by pressing the  $\blacktriangledown$  or  $\blacktriangle$  button.

When this digit has been adjusted as required, pressing **[P]** will transfer control to the next digit. When all the digits have been adjusted pressing **[P]** will transfer control to the decimal point that may be positioned between any of the digits, or may be omitted by moving it to the right of the least significant digit. When the required rate scale factor has been entered, press **[E]** to return to the **5[RL]E.r** prompt in the configuration menu.

**Note:**

Adjustment of **5[RL]E.r** will disable the following outputs which must be re-enabled after the adjustment is complete:

Pulse output

Optional Alarm outputs

Optional 4/20mA output

### 6.19 Timebase: **t-b[5E]**

The timebase multiplies the rate display by 1, 60 or 3,600 depending upon whether the BA364G Counter is required to display rate per second, per minute or per hour. See Fig 9.

To check or change the timebase, select **t-b[5E]** from the configuration menu and press **[P]** which will reveal the current setting. Pressing the **[▼]** or **[▲]** button will scroll through the three options:

<b>t-b-1</b>	for pulses / second
<b>t-b-60</b>	for pulses / minute
<b>t-b-3600</b>	for pulses / hour

When the required multiplier is displayed press **[E]** to return to the **t-b[5E]** prompt in the configuration menu.

### 6.20 Display filter: **F, [L]E.r**

The digital display filter has two independent adjustable parameters enabling the rate display response to be tailored for optimum performance. The filter parameters are controlled by a two digit number. The first digit defines the amount of filtering applied to the display as shown below.

First digit	Filter time constant Seconds
0X	0
1X	1.3
2X	4.3
3X	6.5
4X	8.7
5X	11.3
6X	15.7
7X	20.9
8X	25.2
9X	31.5

The second digit defines the deviation from the displayed rate at which the filter will be overridden and the rate display will move rapidly to the new value.

Second digit	Magnitude of step change which will produce a rapid response
X0	Off
X1	1%
X2	2%
X3	4%
X4	8%
X5	12%
X6	16%
X7	24%
X8	32%
X9	64%

By careful adjustment of the two parameters a stable display with an acceptable input step response can be obtained for most applications.

During commissioning it is recommended that initially the second digit is set to **0** (off) and the first digit is adjusted to provide acceptable rate display stability. The second digit should then be increased until the selected step size is greater than the noise on the display signal, at which setting the rate display will become stable. These will be the optimum filter parameters for acceptable rate display stability and a fast response to a large rate signal change.

To check or change the filter select **F, [L]E.r** in the configuration menu and press **[P]** which will reveal the current settings with the first digit flashing. Pressing the **[▼]** or **[▲]** button will adjust the flashing digit and **[P]** will transfer control to the second digit. While making adjustments the filtered rate display is shown on the lower display so that stability can be assessed while adjustments are being made. When set as required, press the **[E]** button to enter the revised parameters and return to the **F, [L]E.r** prompt in the configuration menu.

### 6.21 Direction of count: $\uparrow$ or $\downarrow$

This function defines whether input pulses increment or decrement the total display. i.e. whether Input A is an up-counter or a down counter.

When configured as a down-counter with a non-zero number entered for the reset value  $\text{CLR URL}$ , the BA364G will count down from the re-set value to zero.

To check or change the count direction select  $\uparrow$  or  $\downarrow$  from the configuration menu and press  $\text{P}$  which will reveal the present setting.  $\uparrow$  indicates that the instrument is an up-counter and  $\downarrow$  that it is a down counter. Pressing the  $\blacktriangledown$  or  $\blacktriangle$  buttons will toggle the instrument between the two settings. When set as required, press the  $\text{E}$  button to enter the setting and return to the configuration menu.

#### Note:

The Count function described in section 6.13 also affects the direction in which the BA364G counts.

### 6.22 Reset value: $\text{CLR URL}$

This function defines the value to which the total display is reset when the local or remote reset are operated. This allows the BA364G to be used as a pre-set down counter.

When the instrument is used as an up-counter,  $\text{CLR URL}$  is normally set to zero.

To check or change the reset value select  $\text{CLR URL}$  from the configuration menu and press  $\text{P}$  which will reveal the current setting with one digit flashing. The flashing digit may be adjusted by pressing the  $\blacktriangledown$  or  $\blacktriangle$  button. When this digit is correct, pressing  $\text{P}$  will transfer control to the next digit.

When all the digits have been adjusted press the  $\text{E}$  button to enter the revised number and return to the configuration menu.

### 6.23 Local reset: $\text{LoC CLR}$

The Local reset function contains two sub-functions  $\text{CLR EoE}$  and  $\text{CLR GEoE}$  which when enabled allow the total display and grand total to be reset via the instrument front panel push buttons while the BA364G Counter is in the display mode.

### 6.24 Local total reset: $\text{CLR EoE}$

$\text{CLR EoE}$  is a sub-menu in the  $\text{LoC CLR}$  function. When activated it allows an operator to reset the total display to the reset value [see section 6.22] while the BA364G Counter is in the display mode by operating the  $\blacktriangledown$  and  $\blacktriangle$  push buttons simultaneously for more than three seconds.

To check or change the setting select  $\text{LoC CLR}$  in the configuration menu and press  $\text{P}$  which will reveal the  $\text{CLR EoE}$  prompt, operating  $\text{P}$  again will show if the local total reset is  $\text{on}$  or  $\text{off}$ . If set as required operate the  $\text{E}$  button twice to return to the configuration menu, or the  $\blacktriangledown$  or  $\blacktriangle$  button to change the setting followed by the  $\text{E}$  button twice to enter the change and return to the  $\text{LoC CLR}$  prompt in the configuration menu.

#### Note:

The total display may also be remotely reset to the reset value by connecting terminals RS1 and RS2 together for more than one second. See sections 3.6; 4.1.8 and 4.2.8 of this manual.

### 6.25 Local grand total reset: $\text{CLR GEoE}$

The grand total is a separate sixteen digit counter which is incremented or decremented in parallel with the total display, but is not reset when the total display is reset. The grand total may be viewed in the display mode in two eight digit sections as described in section 2.2 of this manual.

$\text{CLR GEoE}$  is a sub-menu in the  $\text{LoC CLR}$  function which when activated allows the operator to reset the grand total display to zero from the display mode by operating the  $\text{E}$  and  $\blacktriangle$  push buttons simultaneously for more than ten seconds.

To check or change the setting select  $\text{LoC CLR}$  in the configuration menu and press  $\text{P}$  which will reveal  $\text{CLR GEoE}$ . Using the  $\blacktriangledown$  or  $\blacktriangle$  button to select  $\text{CLR GEoE}$  and press  $\text{P}$  which will show if local grand total reset is  $\text{on}$  or  $\text{off}$ . If set as required operate the  $\text{E}$  button twice to return to the configuration menu, or the  $\blacktriangledown$  or  $\blacktriangle$  button to change the setting followed by the  $\text{E}$  button twice to enter the change and return to the  $\text{LoC CLR}$  prompt in the configuration menu.

#### Note:

Once reset, the grand total can not be recovered.

### 6.26 Reset grand total from configuration menu: $\text{CLR GEoE}$

The grand total is a separate sixteen digit counter which is incremented or decremented in parallel with the total display, but is not reset when the total display is reset. The grand total may be viewed in the display mode in two eight digit sections as described in section 2.2 of this manual.

To zero the grand total from within the configuration menu select  $\text{CLR GEoE}$  and press  $\text{P}$  which will cause the instrument to display  $\text{CLR.no}$  with  $\text{no}$  flashing.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button change  $\text{ELr nd}$  to  $\text{ELr YEE}$  pressing  $\text{P}$  will result in the instrument displaying 0000 with the first digit flashing. This is a request to confirm the reset instruction by entering 5urE. Using the  $\blacktriangledown$  or  $\blacktriangle$  button set the first flashing digit to 5 and press  $\text{P}$  to transfer control to the second digit which should be set to u. When 5urE has been entered pressing the  $\text{E}$  button will reset the grand total which will be confirmed by a brief display of  $\text{Et ELrd}$ , the instrument will automatically return to the  $\text{ELr Et}$  prompt in the configuration menu.

**Note:**

Once reset, the grand total can not be recovered.

### 6.27 Security code: $\text{LodE}$

Access to the instrument configuration menu may be protected by a four digit security code which must be entered to gain access. New instruments are configured with the default security code 0000 which allows unrestricted access to all configuration functions.

To enter a new security code select  $\text{LodE}$  from the configuration menu and press  $\text{P}$  which will cause the BA364G Counter to display 0000 with one digit flashing. The flashing digit may be adjusted using the  $\blacktriangledown$  and  $\blacktriangle$  push buttons, when set as required operating the  $\text{P}$  button will transfer control to the next digit. When all the digits have been adjusted press  $\text{E}$  to return to the  $\text{LodE}$  prompt. The revised security code will be activated when the BA364G Counter is returned to the display mode.

Please contact BEKA associates sales department if the security code is lost.

### 6.28 Reset configuration to factory defaults $\text{rSEt dEF}$

This function returns the BA364G Counter to the factory defaults shown in section 6.0. To prevent accidental use the request must be confirmed by entering 5urE before the configuration change will be executed.

Select  $\text{rSEt dEF}$  from the configuration menu and press  $\text{P}$ . the instrument will display 0000 with the first digit flashing. To confirm the instruction to reset all the configuration functions to factory defaults 5urE must be entered. Using the  $\blacktriangledown$  or  $\blacktriangle$  button set the first flashing digit to 5 and press  $\text{P}$  to transfer control to the second digit which should be set to u. When 5urE has been entered pressing the  $\text{E}$  button will reset all the configuration functions to the factory default settings and zero both the total display and the grand total. While resetting the BA364G Counter will display - - - - - before automatically returning to the display mode when the operation is complete.

### 6.29 Display overflow

The BA364G Counter total has a maximum display range of -9999999 to 99999999 when shown on the eight digit upper display. If this range is exceeded the display will be as shown below with all of the decimal points flashing:

Overrange	99999999
Underrange	-99999999

When the total is shown on the lower six digit display the maximum display range is -99999 to 999999.

When a total overflow occurs the actual total may be obtained from the instrument's grand total display which has sixteen digits - see 2.2.

To prevent future total display overflows occurring the total scale factor  $\text{SCALE.E}$  and the position of the decimal point in the total display  $\text{dP}$  should be reviewed.



## 7. Pulse output

The BA364G Counter has an opto-isolated solid state pulse output. The output is an open collector having the following electrical parameters:

$R_{on}$	=	$60\Omega + 3V$
$R_{off}$	=	1M
$I_{max}$	=	10mA

The output pulse may be a duplicate of Input A or Input b for re-transmission applications, or it may be derived from the total display. When derived from the total display the output pulse frequency may be divided and the output pulse width defined.

The retransmitted RTx annunciator on the instrument display shows the status of the retransmitted pulse output. Annunciator activation depends upon the setting of *Source* in the pulse output configuration menu.

### SCALE#

Annunciator activated each time pulse output open collector is on, i.e.  $R_{on}$  is less than  $60\Omega + 3V$ .

### di RECT

Annunciator continuously activated

### 7.1 Intrinsic safety

The pulse output is an optically isolated separate intrinsically safe circuit that has zero output safety parameters. The output therefore complies with the requirements for *simple apparatus*. This allows pulse output terminals P1 and P2 to be directly connected to any intrinsically safe circuit protected by a certified Zener barrier or galvanic isolator providing the output parameters do not exceed:

$U_o$	=	28V dc
$I_o$	=	200mA
$P_o$	=	0.84W




Fig 12 Generating voltage pulse in safe area using Zener barriers.

The equivalent capacitance and inductance of the pulse output are both zero which allows the maximum permissible cable parameters specified by the certificate for the Zener barrier or galvanic isolator powering the pulse output circuit to be used.

### 7.2 System design

The BA364G Counter pulse output is a passive circuit i.e. not powered, but it is totally isolated from all other Counter circuits. Subject to complying with intrinsic safety interconnection requirements, the terminals P1 and P2 may be connected to another instrument with an open collector input. The pulse output may also be transferred to the safe area via a galvanic isolator or a Zener barrier.

Fig 12 shows how a 2-channel Zener barrier may be used to produce a voltage pulse in the safe area that could be used to drive a safe area counter. The positive terminal of the pulse output circuit P1 is connected to the BA364G Counter's positive supply terminal 1 at the instrument. When an output pulse occurs and the open collector output 'closes', P2 is connected to P1 and a pulse current flows through the diode return barrier to resistor R1 in the safe area. The current flowing in the circuit is determined by R1 which should be chosen to limit the pulse output current to less than 10mA. For a 24V supply R1 should be greater than 2,200 $\Omega$ .

### 7.3 Configuration

The pulse output is configured via a **PULSE oP** sub-menu located between the **LoC CLr** and the **CLr CLot** functions in the configuration menu as shown in Fig 13.




This sub-menu allows the source of the output pulse to be selected. For re-transmission applications the output pulse may be a synchronous duplicate of the pulse at Input A or at Input b by selecting **d, rECLt A** or **d, rECLt b** in the **Source** sub-function.

Selecting **SCALEd** derives the output pulse from the total display and introduces two additional functions, **d, U, dE** and **durAtion**, to the sub-menu allowing the output pulse frequency to be divided and the output pulse width (duration) to be defined.

If the **d, U, dE** and **durAtion** functions are configured such that the output pulse frequency with the specified pulse width can not be output in real time, the number of pulses will be stored and transmitted at the maximum possible speed.

When the total display is reset to zero or the power supply to the BA364G Counter is disconnected or turned off, any stored pulses will not be retained.

### 7.4 Access Pulse output sub-menu: **PULSE oP**

Using the  or  push button scroll through the Counters configuration menu until **PULSE . oP** is displayed, pressing  will then access the pulse output sub-menu which is shown in Fig 13.










Fig 13 Pulse output configuration sub-menu







### 7.5 Enable pulse output: **EnbL**

This function allows the pulse output to be disabled or enabled without altering any of the pulse output parameters. Using the  or  push button select **EnbL** in the pulse output sub-menu and press  to reveal the existing setting **on** or **oFF**. The function can be changed by pressing the  or  push button followed by the  button to return to **EnbL** prompt.

### 7.6 Source of output pulse: *Source*

The output pulse may be derived from:







<i>direct A</i>	Output is duplicate of input A pulse.
<i>direct b</i>	Output is duplicate of input b pulse.
<i>Source</i>	Output is derived from the total display and is only functional when the <i>Count</i> function is configured for <i>A+b</i> . When <i>Source</i> is selected two additional functions, <i>div</i> , <i>dE</i> and <i>duration</i> , appear in the pulse output sub-menu.

Using the  or  push button select *Source* in the pulse output sub-menu and press  to reveal the existing pulse source. The function can be changed by pressing the  or  push button followed by the  button to return to *Source* prompt.

### 7.7 Divide output pulse frequency: *div*, *dE*

When the output pulse is derived from the total display the output pulse frequency may be divided by:

1  
10  
100  
1000  
10000







Using the  or  push button select *div*, *dE* in the pulse output sub-menu and press  to reveal the existing divisor. The value can be changed by pressing the  or  push button to select the required value followed by the  button to return to *div*, *dE* prompt.

**Note:** This function only appears in the sub-menu when the output pulse is derived from the total display.

### 7.8 Output pulse width: *duration*

When the output pulse is derived from the total display, the pulse width is defined by this function. One of 11 pulse widths in milliseconds may be selected:

0.1  
0.5  
1  
2.5  
5  
10  
25  
50  
100  
250  
500

Using the  or  push button select *duration* in the pulse output sub-menu and press  to reveal the existing pulse duration. The value can be changed by pressing the  or  push button to select the required value followed by the  button to return to *duration* prompt.

**Note:** This function only appears in the pulse output sub-menu when the output pulse is derived from the total display.

## 8. CONFIGURATION EXAMPLE

A BA364G Counter is required to display the position and speed, including direction, of a cable which is sensed by two proximity detectors mounted on a wheel with a circumference of 1m over which the cable runs. The sensors, which produce fifteen pulses per revolution, are positioned so their outputs are electrically 90° apart. The BA364G is required to display the position of the cable relative to a starting point in metres with a resolution of 0.1m, and to show speed of the cable in metres per second with a resolution of 1m. The total display (position) is to be resettable by an external contact, not from the BA364G Counter front panel. Similarly the grand total is not to be resettable from the BA364G Counter front panel. To prevent tampering the instrument configuration menu is to be protected by security code 1209.

The BA364G may be configured on-site without disconnection from the power supply or from the two proximity detectors.

If after accessing the configuration menu the interval between operating any front panel push button exceeds one minute the BA364G will automatically return to the display mode and any configuration changes will not be stored in permanent memory. When making multiple changes it is therefore sensible to occasionally return to the display mode to save the changes that have already been made.

### Step 1 Enter the configuration menu

Put the BA364G Counter in the configuration mode by simultaneously pressing **[P]** and **[E]** push buttons. Assuming a security code has not already been entered the instrument will respond by displaying **1 nPUL-R** which is the first parameter in the configuration menu.

See Fig 10

### Step 2 Select the type of inputs

With **1 nPUL-R** displayed; press **[P]** to reveal the existing setting. Using the **[▼]** or **[▲]** button select **Pr.dEt**, the input for a 2-wire proximity detector, and then return to the **1 nPUL-R** prompt in the configuration menu by pressing **[E]**.

Repeat for the second input **1 nPUL-b**

### Step 3 Select input count mode

The two proximity detectors are positioned so their outputs are electrically 90° apart. From this information, in the quadrature input mode the BA364G Counter can sense the direction and angular movement of the wheel to which the proximity detectors are attached. Hence, the relative position of the cable can be displayed by the counter.

Select **Count** from the configuration menu and press **[P]**. Using the **[▼]** or **[▲]** button select **REL** b the quadrature function and press **[E]** to return to the 'Count' prompt in the configuration menu.

### Step 4 Define function of upper display

In the example the cable position (total display) is required on the eight digit upper display.

Select **d.5P-1** from the configuration menu and press **[P]** which will reveal if the upper display is showing **rate** or **total**. Using the **[▼]** or **[▲]** button select **total** followed by the **[E]** button to enter the selection and return to the configuration menu.

### Step 5 Activate lower rate display

A rate display is required so the lower display must be activated.

Select **d.5PLRY.2** from the main menu and press **[P]** to show the existing setting. Using the **[▼]** or **[▲]** button select **on** followed by **[E]** to enter the selection and return to the configuration menu.

### Step 6 Position of decimal point

In this example the BA364G is required to display total (position) with a resolution of one decimal place and rate (speed) with no decimal point.

Select **d.P.** from the configuration menu and press **[P]**. The BA364G will show and identify the total display with all the digits activated. Using the **[▼]** or **[▲]** button position the decimal point between the first and second least significant digits.

Operating the **[P]** button will show and identify the rate display with all the digits activated. Using the **[▼]** or **[▲]** button position the decimal point to the right of the least significant digit i.e. not visible. Finally press **[E]** to return to the configuration menu.

**Step 7 Enter the total scale factor**

In this example the proximity detectors produce fifteen pulses per one metre movement of the cable. The position display is required in metres so the total (position) scale factor  $SCALE.t$  should be set to 15.0.

Select  $SCALE.t$  from the configuration menu and press  $\boxed{P}$  to view the current value with one digit flashing. Use the  $\boxed{\nabla}$  and  $\boxed{\blacktriangle}$  buttons to adjust each digit in turn and the  $\boxed{P}$  button to transfer control to the next digit and to the decimal point. Enter 15.0 and return to the  $SCALE.t$  prompt in the configuration menu by pressing  $\boxed{E}$ .

**Step 8 Enter the rate scale factor**

In this example the proximity detectors produce fifteen pulses per one metre movement of the cable. The rate display is required in metres per second so the rate (speed) scale factor  $SCALE.r$  should be set to 15.0.

Select  $SCALE.r$  from the configuration menu and press  $\boxed{P}$  to view the current value with one digit flashing. Use the  $\boxed{\nabla}$  and  $\boxed{\blacktriangle}$  buttons to adjust each digit in turn and the  $\boxed{P}$  button to transfer control to the next digit and to the decimal point. Enter 15.0 and return to the  $SCALE.r$  prompt in the configuration menu by pressing  $\boxed{E}$ .

**Step 9 Set the display timebase**

In this example the rate display (speed) is required in metres per second.

Select  $t-bASE$  from the configuration menu and press  $\boxed{P}$  to reveal the current setting. Using the  $\boxed{\nabla}$  or  $\boxed{\blacktriangle}$  button scroll through the three options and select  $t-b-1$ . Return to the  $t-bASE$  prompt in the configuration menu by pressing  $\boxed{E}$ .

**Step 10 Adjust the rate display filter**

The rate display filter parameters should be adjusted experimentally after installation to provide a stable rate display with an acceptable step response.

During commissioning it is recommended that initially the second digit of the rate parameters is set to 0 (step response off) and the first digit (amount of filtering) is adjusted to provide acceptable rate display stability. The second digit should then be increased until acceptable rate display stability is once again achieved.

To adjust the filter parameters select  $FILTER$  from the main menu and press  $\boxed{P}$  to reveal the current setting. The first digit will be flashing and may be adjusted using the  $\boxed{\nabla}$  or  $\boxed{\blacktriangle}$  button. The  $\boxed{P}$  button will transfer control to the second digit. When both are set as required, return to the  $FILTER$  prompt in the main menu by pressing  $\boxed{E}$ .

**Note:** While adjusting the filter, the rate is shown on the lower display so that stability can be assessed.

**Step 11 Direction of count**

In this application the direction of count will determine whether a cable movement is shown as a positive or negative position and rate. If input A occurs before input b, a positive display will result when the BA364G is configured to count up.

Select  $uP$  or  $dn$  from the main menu and press  $\boxed{P}$  to reveal the existing setting. Using the  $\boxed{\nabla}$  or  $\boxed{\blacktriangle}$  button select  $uP$  followed by  $\boxed{E}$  to enter the selection and return to the configuration menu.

**Step 12 Turn local clear off**

In this example the operator must not be able to zero the total (cable position) display or the grand total from the instrument front panel. Both local clear functions should therefore be turned off.

Select **LOC CLR** from the main menu and press **[P]** which will result in **CLR Tot** being displayed, press **[P]** again to show if the function is turned **on** or **off**. Using the **[▼]** or **[▲]** button toggle the display to **off** and press **[E]** to return to the **CLR Tot** prompt from which **CLR Gtot** can be selected by pressing the **[▼]** or **[▲]** button. Turn this function off in exactly the same way before returning to the configuration menu by pressing the **[E]** button twice.

**Step 13 Define the security code**

Defining an access security code prevents unauthorised access to the configuration menu. Select **Code** in the configuration menu and press **[P]** which will reveal the existing security code with the first digit flashing. Using the **[▼]** and **[▲]** buttons enter the new code 1209 digit by digit. The **[P]** button transfers control between digits. When the new code has been entered, press **[E]** to return to the configuration menu.

**Step 14 Return to the display mode**

Following completion of configuration, return the BA364G to the display mode by pressing **[E]**. The instrument will display **AREA** followed by **SRUE** while the configuration changes are stored in permanent memory.

## 9. MAINTENANCE

### 9.1 Fault finding during commissioning

If a BA364G Counter fails to function during commissioning the following procedure should be followed:

Symptom	Cause	Check:
No display	No power supply, or incorrect wiring. Note: Terminals 2, 6, 10 & RS2 are interconnected within the instrument.	That there is between 10 and 28V on terminals 1 & 2 with terminal 1 positive.
Counter is receiving power but pulse input indicator not rotating.	No input pulses, incorrect input configuration, incorrect linking of terminals 3 & 4 and terminals 7 & 8.	Input configuration.  Linking of terminals 3 & 4. and terminals 7 & 8.  That input signal polarity is correct.
Pulse input indicator rotating but incorrect rate display.	Incorrect rate display calibration	SCALE, r t-BASE
Pulse input indicator rotating but incorrect total display.	Incorrect total display calibration.  Remote reset switch contacts closed.	SCALE, t  That RESET annunciator on display is not activated. If it is, check reset wiring and switch.
Pulse input indicator rotating but total display showing 9.9.9.9.9.9.9.9 or -9.9.9.9.9.9.9.9  Or if shown on the lower display 9.9.9.9.9.9 or -9.9.9.9.9	Total display has overflowed.	Reposition decimal point in total display or enter a different SCALE, t to reduce total display magnitude.
Unstable rate display	Noisy pulse input signal	Eliminate source of electrical noise. Increase debounce and/or display filter.
Unable to enter configuration menu.	Incorrect security code	That the correct security code is being used.  Contact BEKA if code is lost.
Alarms do not function	Alarms have been disabled following calibration change.	Re-enable both alarms.

### 9.2 Fault finding after commissioning

#### ENSURE PLANT SAFETY BEFORE STARTING MAINTENANCE

**Live maintenance is permitted on intrinsically safe equipment installed in a hazardous area, but only certified test equipment should be used unless a gas clearance certificate is available.**

If a BA364G Counter fails after it has been functioning correctly, the following table may help to identify the cause of the failure.

Symptom	Cause	Check:
No display	No power supply.	That there is between 10 and 28V on terminals 1 & 2
Pulse input indicator not rotating.	No input pulses	Output from sensor. Wiring between sensor and BA364G Counter.
Unstable rate display	Noisy pulse input signal	Locate source of electrical noise, or increase debounce and rate display filter.

If this procedure does not reveal the cause of the fault, it is recommended that the instrument is replaced.

### 9.3 Servicing

We recommend that faulty BA364G Counters are returned to BEKA associates or to your local BEKA agent for repair.

### 9.4 Routine maintenance

The mechanical and electrical condition of the instrument should be regularly checked. Inspection frequency should be adjusted to suit the environmental conditions.

### 9.5 Guarantee

Instruments which fail within the guarantee period should be returned to BEKA associates or your local agent. It is helpful if a brief description of the fault symptoms is provided.

### 9.6 Customer comments

BEKA associates is always pleased to receive comments from customers about our products and services. All communications are acknowledged and whenever possible, suggestions are implemented.

## 10. ACCESSORIES

### 10.1 Units of measurement & instrument identification.

New BA364G Counters are supplied with a printed scale card showing the units of measurement and tag information specified when the instrument was ordered. If this information was not supplied a blank scale card will be fitted which can easily be marked with a dry transfer or a permanent marker on-site.

Custom printed scale cards are available as accessories and may be easily fitted as shown in section 5.4 of this manual.

The BA364G can also be supplied with a blank or custom laser engraved stainless steel legend plate - see Fig 7. The plate, which after installation is visible from the front of the instrument, is supplied loose with two fixing screws for securing it to the rear of the instrument's back-box. This plate can typically accommodate:

- 1 row of 5 alphanumeric characters 10mm high
- or 1 row of 6 alphanumeric characters 7mm high
- or 2 rows of 10 alphanumeric characters 5mm high

### 10.2 Backlight

The BA364G Counter can be supplied with a factory fitted backlight that produces green illumination enhancing display contrast and enabling it to be read at night or in poor lighting conditions. The backlight is internally powered from the instrument power supply so that no additional wiring or intrinsically safe interface is required, but the supply current increases as shown below.

	<b>BA364G Maximum current consumption</b>
Without backlight	10mA
Additional for backlight	16mA
Addition with terminals 3 & 4 linked	6mA
Addition with terminals 7 & 8 linked	6mA
<b>Total current</b>	<b>38mA max</b>

### 10.3 Alarms

The BA364G Counter can be supplied with factory fitted dual alarms. Each may be independently configured as a rate display or total display, high or low alarm. with a normally open, or a normally closed solid state output.

Configurable functions for each alarm include adjustable setpoint, alarm delay time and alarm silence time. Hysteresis may be applied to rate alarms.

### CAUTION

**These alarm outputs should not be used for critical safety applications such as a shut down system.**

When the BA364G power supply is turned off or disconnected, alarm outputs will open irrespective of whether normally open or normally closed outputs have been selected. When designing a system an open output should therefore be chosen for the alarm condition.

Alarm annunciators on the instrument display indicate the status of each alarm. If an alarm delay or silence time has been selected the annunciator will flash during the delay or silence period.

The BA364G internal counters are up-dated and compared with the alarm setpoint twice per second, irrespective of the display update time selected. This may result in an alarm being delayed for up to half a second after the rate or total has exceeded the setpoint.

#### 10.3.1 Solid state output

Each alarm has a galvanically isolated single pole solid state switch output as shown in Fig 14. The outputs are polarised and current will only flow in one direction. Terminals A1 and A3 should be connected to the positive side of the supply.

$$\begin{aligned} R_{on} &= \text{less than } 5\Omega + 0.7V \\ R_{off} &= \text{greater than } 1M\Omega \end{aligned}$$

**Note:** Because of the series protection diode some test meters may not detect a closed alarm output




Fig 14 Equivalent circuit of each alarm output

#### 10.3.2 Intrinsic safety

Each alarm output is a separate galvanically isolated intrinsically safe circuit with output safety parameters complying with the requirements for *simple apparatus*. This allows the alarm output terminals A1 & A2 and A3 & A4 to be connected to almost any intrinsically safe circuit protected by a Zener barrier or galvanic isolator providing the output parameters of the circuit do not exceed:

$$\begin{aligned} U_o &= 28V \text{ dc} \\ I_o &= 200mA \\ P_o &= 0.84W \end{aligned}$$



The maximum equivalent capacitance and inductance between each set of alarm terminals is:

$$\begin{aligned} C_i &= 22\text{nF} \\ L_i &= 4\mu\text{H (Effectively 0)} \end{aligned}$$

To determine the maximum permissible cable parameters  $C_i$  should be subtracted from the maximum permitted external capacitance  $C_o$  specified by the certificate for the intrinsically safe interface powering the alarm circuit, such as the solenoid driver and switch transfer galvanic isolators shown in Fig 15




Fig 15 Typical alarm application

### 10.3.3 Summary of configuration functions

When a BA364G Counter is supplied with alarms the configuration menu is extended as shown in Fig 16. The alarm functions appear after  $\text{LoC}$   $\text{[Lr]}$  each alarm may be configured to operate on the rate or total display.

For simplicity Fig 16 only shows the configurable functions on the rate option of alarm AL1, the total option is identical except that the total alarms can not have hysteresis. Configuration of alarm AL2 is identical to alarm AL1.

The following table summarises each of the alarm configuration functions and includes a cross reference to more detailed information. Again only the functions on alarm AL1 are listed.

Display	Summary of function
<b>EnbL</b>	<b>Alarm enable</b> Enables or disables the alarm without changing the alarm parameters. See section 10.3.4
<b>TYPE</b>	<b>Type of alarm</b> Defines whether the alarm operates on the rate or total display. See section 10.3.5
<b>SP Lr</b> or <b>SP Lt</b>	<b>Alarm setpoint 1</b> Adjusts the alarm setpoint. The alarm is activated when the rate or total display equals the setpoint. <b>Note:</b> $\text{SP Lr}$ is displayed for a rate alarm and $\text{SP Lt}$ for a total alarm. See section 10.3.6
<b>H.Lo</b>	<b>Alarm function</b> Defines whether the alarm has a high or low function. See section 10.3.7
<b>no.nC</b>	<b>Normally open or normally closed output.</b> Determines whether the single pole alarm output is open or closed in the non-alarm condition. See section 10.3.8
<b>HSEr</b>	<b>Hysteresis</b> Adjusts the alarm hysteresis. Only available on a rate alarm. See section 10.3.9
<b>dELA</b>	<b>Alarm delay time</b> Adjusts the delay between the display equaling the setpoint and the alarm output being activated. See section 10.3.10
<b>S.L</b>	<b>Alarm silence time</b> Defines the time that the alarm output remains in the non-alarm condition following acceptance of an alarm. See section 10.3.11
<b>FLASH</b>	<b>Flash display when alarm occurs</b> When enabled, alternates the rate or total display between process value and alarm reference $\text{RL1}$ or $\text{RL2}$ when an alarm output is activated. See section 10.3.12
<b>ACCESSP</b>	<b>Access setpoint</b> Sub-menu that enables direct access to the alarm setpoints from the display mode and defines a separate security code. See section 10.3.13




Fig 16 Alarm Configuration Functions in Configuration Menu

### 10.3.4 Alarm enable: EnbL

This function allows the alarm to be enabled or disabled without altering any of the alarm parameters. Using the  $\nabla$  or  $\blacktriangle$  push button select AL1 or AL2 from the configuration menu and press P to reach EnbL in the alarm sub-menu. Pressing P will then reveal the existing setting. The function can be changed by pressing the  $\nabla$  or  $\blacktriangle$  push button followed by the E button to return to the alarm sub-menu.

### 10.3.5 Type of alarm: TYPE

Alarm 1 and Alarm 2 are totally independent, both may be rate or total alarms, or one may be conditioned for rate and the other for total.

Using the  $\nabla$  or  $\blacktriangle$  push button select TYPE from the selected alarm sub-menu and press P to check or change the function. The  $\nabla$  or  $\blacktriangle$  push button will toggle the selection between rate and total, when set as required press the E button to return to the alarm sub-menu.

**Note:** When TYPE is changed, the alarm configuration is automatically reset to the default values and the alarm is disabled. It must therefore be reconfigured before use.

### 10.3.6 Setpoint adjustment: $SP\ 1r$ & $SP2x$

The rate alarm setpoints  $SP1r$  and  $SP2r$  may be positioned anywhere between 000000 and 999999, and the total alarm setpoint  $SP1t$  and  $SP2t$  anywhere between 00000000 and 99999999.

All the setpoints are adjusted in the same way, for example, to adjust the setpoint of Alarm 1 which has been configured to operate on the rate display. Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $SP\ 1r$  in the AL1 sub-menu and press  $\text{P}$  which will reveal the existing setpoint with one digit flashing. The required setpoint can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the  $SP\ 1r$  prompt in the alarm 1 sub-menu.

### 10.3.7 Alarm function: $Hi,Lo$

Alarm 1 and Alarm 2 are totally independent, both may be Hi or Lo, or one may be conditioned as a Hi alarm and the other as a Lo alarm.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $Hi,Lo$  from the selected alarm sub-menu and press  $\text{P}$  to check or change the function. The  $\blacktriangledown$  or  $\blacktriangle$  push button will toggle the alarm function between  $Hi$  and  $Lo$ , when set as required, press the  $\text{E}$  button to return to the  $Hi,Lo$  prompt in the alarm sub-menu.

### 10.3.8 Alarm output status: $no,nf$

Each single pole alarm output may be open or closed in the non-alarm condition. When the BA364G power supply is turned off or disconnected, the alarm output(s) will open irrespective of whether normally open or normally closed outputs have been selected. Therefore, when designing an alarm system normally closed  $nf$  should be selected so that the output opens when an alarm occurs or if the power supply fails.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $no,nf$  from the selected alarm sub-menu and press  $\text{P}$  to check or change the function. The  $\blacktriangledown$  or  $\blacktriangle$  push button will toggle the contact status between  $no$  and  $nf$ , when set as required, press the  $\text{E}$  button to return to the  $no,nf$  prompt in the alarm sub-menu

### 10.3.9 Hysteresis: $H5tr$

Hysteresis is only available on rate alarms so the  $H5tr$  function only appears in the configuration sub-menu when alarm  $TYPE$  has been set to  $rate$ . During configuration hysteresis is shown in the units of rate previously configured for the rate display.

Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select  $H5tr$  in the selected alarm sub-menu and press  $\text{P}$  which will reveal the existing hysteresis with one digit flashing.

The required hysteresis can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the  $H5tr$  prompt in the alarm sub-menu.

e.g. A BA364G Counter configured to display a rate of 0 to 5000, with a high alarm set at 4000 and hysteresis of 100 will perform as follows:

High alarm will be activated when rate equals or exceeds 4000, but will not reset until the rate falls below 3900.

### 10.3.10 Alarm delay: $dELR$

This function enables activation of the alarm output to be delayed for a fixed time following the alarm condition occurring. The delay can be set in 1 second increments up to 3600 seconds. If a delay is not required zero should be entered.

To adjust the delay select  $dELR$  using the  $\blacktriangledown$  or  $\blacktriangle$  push button in the selected alarm sub-menu and press  $\text{P}$  which will reveal the existing delay time in seconds with one digit flashing. The required delay time can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the  $dELR$  prompt in the alarm sub-menu.

The alarm annunciator will start flashing immediately an alarm condition occurs and will continue for the delay time, after which the alarm output will be activated and the alarm annunciator will be permanently activated.

### 10.3.11 Alarm silence time: $S, L$

The alarm silence function is primarily intended for use in small installations where the alarm output directly operates an annunciator such as a sounder. When the alarm silence time is set to any figure other than zero, the  $\text{P}$  push button becomes an alarm accept button.







After an alarm has occurred, operating the  $\text{P}$  button will cause the alarm output to revert to the non-alarm condition for the alarm silence time. When an alarm is silenced the alarm annunciator will flash until the silence time expires.

To adjust the alarm silence time select  $S, L$  using the  $\blacktriangledown$  or  $\blacktriangle$  push button in the selected alarm sub-menu and press  $\text{P}$  which will reveal the existing alarm silence time in seconds with one digit flashing. The required silence time can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the  $S, L$  prompt in the alarm sub-menu.



### 10.3.12 Flash display when alarm occurs: FL5H










In addition to the two alarm annunciators on the left hand side of the BA364G Counter display which show the status of both alarms, this function provides an even more conspicuous indication that an alarm has occurred.








When enabled, this function alternates the rate or total display between the numerical value and the alarm identification AL1 or AL2 when an alarm occurs.

Using the  or  push button select FL5H from the selected alarm sub-menu and press  to check or change the function. The  or  push button will toggle the function between OFF and ON, when set as required, press the  button to return to the FL5H prompt in the alarm sub-menu.

### 10.3.13 Access Setpoint: RE5P








This function activates a separate menu that provides direct access to the alarm setpoints from the display mode by simultaneously operating the  and  buttons. An operator can therefore adjust the alarm setpoints without having access to the configuration and alarm sub-menus. Protection against unauthorised or accidental adjustment is provided by a separate security access code.



Using the  or  push button select RE5P from the configuration menu and press  to reach the enable function ENBL. Pressing  will reveal the existing setting which can be toggled between ON and OFF by pressing the  or  push button. When set as required, press the  button to return to the ENBL prompt from which a separate security access code can be entered using the REED function which can be selected using the  or  push button.

To enter a new security code select REED from the sub-menu and press  which will cause the BA364G Counter to display 0000 with one digit flashing. The flashing digit may be adjusted using the  or  push button, when set as required operating the  button will transfer control to the next digit. When all the digits have been adjusted press  to return to the REED prompt. The revised security code will be activated when the BA364G Counter is returned to the display mode. Default security access code 0000 will disable the security code allowing direct access to the setpoints in the display mode by pressing the  and  buttons simultaneously.

Please contact BEKA associates sales department if the security code is lost.

### 10.3.14 Adjusting alarm setpoints from the display mode

Access to the two alarm setpoints from the BA364G Counter's display mode is obtained by operating the  and  push buttons simultaneously as shown in Fig 17. If the setpoints are not protected by a security code the alarm setpoint prompt SP1r or SP1t will be displayed depending upon whether a rate or total alarm has been configured. If the setpoints are protected by a security code, CODE will be displayed first. Pressing  again will allow the alarm setpoint security code to be entered digit by digit using the  and  buttons to adjust the flashing digit and the  push button to move control to the next digit. If the correct code is entered pressing  will then cause alarm setpoint prompt SP1x to be displayed. If an incorrect security code is entered, or a button is not pressed within ten seconds, the instrument will automatically return to the display mode.

Once within the menu pressing the  or  buttons will toggle the display between the two alarm setpoint prompts SP1x and SP2x.




Fig 17 Setpoint adjustment from the display mode

To adjust an alarm setpoint select  $5P\ 1x$  or  $5P2x$  and press  $\boxed{P}$  which will reveal the current setting. The flashing digit of the setpoint may be adjusted using the  $\blacktriangledown$  or  $\blacktriangle$  push button and the  $\boxed{P}$  button to move control to the next digit. When the required setpoint has been entered, pressing  $\boxed{E}$  will return the display to the  $5P\ 1x$  or  $5P2x$  prompt from which the other setpoint may be selected, or the instrument may be returned to the display mode by pressing  $\boxed{E}$  again.

**Note:** Direct access to the alarm setpoints from the display mode is only available when the  $RE\ 5P$  menu is enabled - see section 10.3.13

#### 10.4 4/20mA output

The BA364G Counter can be supplied with an optional factory fitted galvanically isolated 4/20mA output which may be configured to represent the rate or total display.

##### 10.4.1 Intrinsic safety

The 4/20mA output has been certified as a separate galvanically isolated intrinsically safe circuit complying with the requirements for *simple apparatus*. This allows terminals C1 and C3 to be connected to any intrinsically safe circuit protected by a certified Zener barrier or galvanic isolator providing the output parameters do not exceed:

$$\begin{aligned} U_o &= 28V\text{ dc} \\ I_o &= 200mA \\ P_o &= 0.84W \end{aligned}$$

The maximum equivalent internal capacitance and inductance of the 4/20mA output is:

$$\begin{aligned} C_i &= 2.2nF \\ L_i &= 4\mu H \end{aligned}$$

To determine the maximum permissible cable parameters, these figures should be subtracted from the maximum cable capacitance and inductance specified by the certificate for the Zener barrier or galvanic isolator powering the 4/20mA output circuit.

##### 10.4.2 System design

The BA364G Counter 4/20mA output is a passive current sink i.e. not powered, but it is totally isolated from all other Counter circuits. It is effectively a 2-wire 4/20mA transmitter requiring a minimum supply of 10V with its current being controlled by the BA364G Counter. Subject to complying with intrinsic safety interconnection requirements, the terminals C1 and C3 may be directly connected to another instrument located in the same hazardous area which will accept a 4/20mA transmitter input. The 4/20mA current output may also be transferred to the safe area via a galvanic isolator or Zener barriers.

Fig 18 shows how a 2-channel Zener barrier may be used to transfer the 4/20mA current output into the safe area, alternatively a galvanic isolator may be used.




Fig 18 Application of 4/20mA output

#### 10.4.3 Configuration and calibration

When a BA364G Counter is supplied with an optional 4/20mA output the configuration menu is extended as shown in Fig 19. The 4/20mA output sub-menu is accessed via the 4-20 mA P function.

The 4/20mA output sub-menu allows the 4/20mA output to be controlled by the rate or the total display.




Fig 19 4/20mA output configuration sub-menu

#### 10.4.4 Access 4/20mA output sub-menu: 4-20 mA P

Access the BA364G Counter configuration menu as described in section 6.2. Using the  $\blacktriangledown$  and  $\blacktriangle$  push buttons scroll through the menu until 4-20 mA P is displayed, pressing  $\text{P}$  will then access the 4/20mA output sub-menu which is shown in Fig 19.

#### 10.4.5 Enable 4/20mA output: EnbL

This function allows the 4/20mA output to be disabled or enabled without altering any of the 4/20mA output parameters. Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select EnbL in the 4-20 mA P sub-menu and press  $\text{P}$  to reveal the existing setting on or oFF. The function can be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  push button followed by the  $\text{E}$  button to return to EnbL prompt.

**Note:** When the 4/20mA output is disabled by selecting oFF, the output is a constant 3.5mA irrespective of the instrument display.

#### 10.4.6 Select rate or total source: 4-20mA YPE

The 4/20mA output current can represent the BA364G Counter's rate or total display and this must be defined before any other 4/20mA current output functions are configured.








Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select 4-20mA YPE in the 4/20mA output sub-menu and press  $\text{P}$  to reveal the existing setting totRL or rRLtE. The function can be changed by pressing the  $\blacktriangledown$  or  $\blacktriangle$  push button followed by the  $\text{E}$  button to return to 4-20mA YPE prompt.

**Note:** If the controlling source of the 4/20mA output is changed i.e. from rate to total, the 4/20mA output will be disabled and the output will be a constant 3.5mA irrespective of the instrument display. The 4/20mA output must always be re-enabled and reconfigured following the controlling source being changed.

#### 10.4.7 Display which corresponds to 4mA output: 4.000

The BA364G Counter display which corresponds to a 4.000mA output current is defined by this function. Using the  $\blacktriangledown$  or  $\blacktriangle$  push button select 4.000 in the 4/20mA output sub-menu and press  $\text{P}$  to reveal the existing rate or total display with one digit flashing. The required display can be entered using the  $\blacktriangledown$  or  $\blacktriangle$  push button to adjust the flashing digit and the  $\text{P}$  button to transfer control to the next digit. When set as required press  $\text{E}$  to enter the value and return to the 4.000 prompt in the 4/20mA output sub-menu.

#### 10.4.8 Display which corresponds to 20mA output: 20.000

The BA364G Counter display which corresponds to 20.000mA output current is defined by this function. Using the  or  push button select 20.000 in the 4/20mA output sub-menu and press  to reveal the existing rate or total display with one digit flashing. The required display can be entered using the  or  push button to adjust the flashing digit and the  button to transfer control to the next digit. When set as required press  to enter the value and return to the 20.000 prompt in the 4/20mA output sub-menu.

**Note:** If the BA364G Counter and the 4/20mA current sink output are powered from separate supplies, the 4/20mA output current will continue to flow when the BA364G Counter supply fails or is turned off. Powering both from a common supply eliminates this effect.

## APPENDIX 1

### ATEX & UKEX Dust Certification

#### A1.0 ATEX & UKEX dust certification

In addition to ATEX & UKEX certification permitting installation in explosive gas atmospheres which is described in the main section of this instruction manual, the BA364G Counter also has ATEX & UKEX dust certification.

#### A1.1 Zones, and Maximum Surface Temperature.

The BA364G has been certified Group II Category 2D Ex ia IIIC T80°C Db, Ta = -40° to 60°C. When connected to a suitable system it may be installed in:

- Zone 21 explosive atmosphere in the form of a cloud of combustible dust in air is likely to occur occasionally in normal operation.
- Zone 22 explosive atmosphere in the form of a cloud of combustible dust in air is not likely to occur in normal operation, but if it does occur, will only persist for a short period.

Be used with dust in subdivisions:

- IIIA combustible flyings
- IIIB non-conductive dust
- IIIC conductive dust

Having a Minimum Ignition Temperature of:

Dust cloud 120°C

Dust layer on Rate 155°C  
Totaliser up to 5mm thick

Dust layer on Rate Refer to  
Totaliser over 5mm thick. EN 60079-14

At an ambient temperature between -40 and +60°C

#### A1.2 Installation and maintenance

The installation requirement described in the main sections of this manual for use in a gas explosive atmospheres also apply when the Counter is installed in a dust potentially explosive atmosphere.

The instrument assembly should only be removed from the enclosure back-box when dust can not enter the instrument enclosure. Before replacing the instrument assembly the sealing gasket should be inspected to ensure that it is undamaged and free from foreign bodies.

It is good practice to prevent dust accumulating on the Counter enclosure. If this can not be avoided, care should be taken to ensure that the layer thickness does not exceed 5mm for dusts having a minimum ignition temperature of 155°C.



## APPENDIX 2

### IECEEx certification

#### A2.0 The IECEEx Certification Scheme

IECEEx is a global certification scheme for explosion protected products which aims to harmonise international certification standards. For additional information about the IECEEx certification scheme and to view the BEKA associate certificates, please visit [www.iecex.com](http://www.iecex.com)

#### A2.1 IECEEx Certificate of Conformity

The BA364G Counter and the optional accessories have been issued with an IECEEx Certificate of Conformity number IECEEx ITS 16.0004X which specifies the following certification codes:

Ex ia IIC T5 Ga  
Ta = -40°C to 70°C  
Ex ia IIIC T80°C IP66 Db  
Ta = -40°C to 60°C

The specified IECEEx gas and dust intrinsic safety parameters are identical to the ATEX & UKEX safety parameters described in the main section and Appendix 1 of this manual.

The IECEEx certificate may be downloaded from the BEKA associate or the IECEEx websites or requested from the BEKA sales office.

#### A2.2 Installation

The IECEEx, ATEX & UKEX certificates specify identical safety parameters and installation requirements for both approvals as defined by IEC 60079-14. The ATEX & UKEX installation requirements specified in the main section and Appendix 1 of this manual may therefore be used for IECEEx installations, but the local code of practice should also be consulted.

## APPENDIX 3

### ETL & cETL certification for installations in USA and Canada.

#### A3.0 cETL Mark

For installations in the USA and Canada, the BA364G Counter has ETL and cETL intrinsic safety and nonincendive approval, Control Number 4008610. Copies of the Authorisation to Mark may be downloaded from the BEKA associates website [www.beka.co.uk](http://www.beka.co.uk) or requested from the BEKA associates sales office

#### A3.1 Intrinsic safety approval

The US and Canadian standards used for assessment and certification of the BA364G are listed on the cETL Authorisation to Mark.

Installations must comply with BEKA associates Control Drawing CI330-52, which is attached to this appendix.

The ETL safety parameters are the same as the ATEX and IECEx parameters, the systems shown in sections 3 and 4 of this manual may therefore also be used for US and Canadian installations subject to compliance with the local codes of practice.

### ETL and cETL intrinsic safety codes

#### USA & Canada

CL I Div 1 Groups A, B, C, D T5  
CL II Div 1 Groups E, F, G. CL III  
-40°C < Ta < 70°C

#### USA

CL I Zone 0 AEx ia IIC T5 Ga  
Zone 20 AEx ia IIIC T80°C Da  
-40°C < Ta < 70°C

#### Canada

Ex ia IIC T5 Ga  
Ex ia IIIC T80°C Da  
-40°C < Ta < 70°C


#### A3.2 Nonincendive approval

The BA364G Counter also has ETL nonincendive approval allowing installation in Division 2 hazardous (classified) locations without the need for Zener barriers or galvanic isolators.

Installations must comply with BEKA associates Control Drawing CI330-53, which is attached to this appendix, and with the local codes of practice.


### ETL and cETL nonincendive codes US & Canada


CL I Div 2 Groups A, B, C, D T5  
CL II Div 2 Groups F, G  
CL III Div 2  
-40°C < Ta < 70°C



Iss.	1	2	Date	05.05 2016	05.08 2016	Modification	New drawing	Field mounted rate totalisers added	Ckd.	QL	OL	Appd.	CB	B.B	Ckd.	Appd.	
 BEKA associates Hitchin England company confidential, copyright reserved.																	
<b>INTERCONNECTIONS FOR EXTERNALLY POWERED RATE TOTALISERS</b>																	
HAZARDOUS LOCATION									UNCLASSIFIED LOCATION See note 4								
<b>INPUTS IN HAZARDOUS AND UNCLASSIFIED LOCATIONS</b>																	
<b>INPUTS IN HAZARDOUS AND UNCLASSIFIED LOCATIONS</b>																	
<b>Title</b> ETL Intrinsically Safe Control Drawing for 'E' and 'G' series externally powered rate totalisers.																	
<b>Drawn</b> SQ <b>Checked</b> OL <b>Scale</b> —																	
<b>Drawing No.</b> C1330-52 <b>Sheet</b> 2 of 6																	
File No 330-52s02.dwg 05.08.16																	

Iss.	Date	Modification	Ckd.	Appd.	Notes																																								
1	05.05 2016	New drawing	QL	CB																																									
2	05.08 2016	Field mounted rate totalisers added	OL	3-3	<p>1. 1 and 2 input externally powered rate totalisers with model numbers and coding as shown in the following tables.</p> <p style="text-align: center;"><b>E PANEL MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp.</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 2 input rate totaliser 1 input counter 2 input counter 1 input timer 2 input timer</td> <td>BA317E BA318E BA337E BA338E BA388E BA367E BA368E BA377E BA378E</td> <td>Class I Division 1 Groups A, B, C &amp; D T5 Class II Division 1 Groups E, F &amp; G Class III Division 1</td> <td>Zone 0 AEx ia IIC T5 Ga</td> <td>-40°C to +70°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>E-SS PANEL MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp. (see note 9)</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 1 input counter 1 input timer</td> <td>BA317E-SS BA337E-SS BA367E-SS BA377E-SS</td> <td>Class I Division 1 Groups A, B, C &amp; D T5 Class II Division 1 Groups E, F &amp; G Class III Division 1</td> <td>Zone 0 AEx ia IIC T5 Ga Zone 20 AEx ia IIC T80°C Da</td> <td>-40°C to +60°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>G FIELD MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp. (see note 9)</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer</td> <td>BA314G BA334G BA384G BA364G BA374G</td> <td>Class I Division 1 Groups A, B, C &amp; D T5 Class II Division 1 Groups E, F &amp; G Class III Division 1</td> <td>Zone 0 AEx ia IIC T5 Ga Zone 20 AEx ia IIC T80°C Da</td> <td>-40°C to +60°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>E FIELD MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp.</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer</td> <td>BA314E BA334E BA384E BA364E BA374E</td> <td>Class I Division 1 Groups A, B, C &amp; D T5 Class II Division 1 Groups E, F &amp; G Class III Division 1</td> <td>Zone 0 AEx ia IIC T5 Ga</td> <td>-40°C to +70°C</td> </tr> </tbody> </table> <p>2. Terminals 7, 8, 9 and 10 only exist on 2 input instruments.</p>	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.	1 input tachometer 1 input rate totaliser 2 input rate totaliser 1 input counter 2 input counter 1 input timer 2 input timer	BA317E BA318E BA337E BA338E BA388E BA367E BA368E BA377E BA378E	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga	-40°C to +70°C	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp. (see note 9)	1 input tachometer 1 input rate totaliser 1 input counter 1 input timer	BA317E-SS BA337E-SS BA367E-SS BA377E-SS	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga Zone 20 AEx ia IIC T80°C Da	-40°C to +60°C	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp. (see note 9)	1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314G BA334G BA384G BA364G BA374G	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga Zone 20 AEx ia IIC T80°C Da	-40°C to +60°C	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.	1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314E BA334E BA384E BA364E BA374E	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga	-40°C to +70°C
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.																																									
1 input tachometer 1 input rate totaliser 2 input rate totaliser 1 input counter 2 input counter 1 input timer 2 input timer	BA317E BA318E BA337E BA338E BA388E BA367E BA368E BA377E BA378E	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga	-40°C to +70°C																																									
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp. (see note 9)																																									
1 input tachometer 1 input rate totaliser 1 input counter 1 input timer	BA317E-SS BA337E-SS BA367E-SS BA377E-SS	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga Zone 20 AEx ia IIC T80°C Da	-40°C to +60°C																																									
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp. (see note 9)																																									
1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314G BA334G BA384G BA364G BA374G	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga Zone 20 AEx ia IIC T80°C Da	-40°C to +60°C																																									
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.																																									
1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314E BA334E BA384E BA364E BA374E	Class I Division 1 Groups A, B, C & D T5 Class II Division 1 Groups E, F & G Class III Division 1	Zone 0 AEx ia IIC T5 Ga	-40°C to +70°C																																									
Iss.	Date	Modification	Ckd.	Appd.	<p>Title ETL Intrinsically Safe Control Drawing for 'E' and 'G' series externally powered rate totalisers.</p> <p>Drawn SQ</p> <p>Checked OL</p> <p>Scale -</p> <p>Drawing No. <b>CI330-52</b></p> <p>Sheet 3 of 6</p>																																								


Iss.		Date		Modification		Ckd.		Appd.																															
1		05.05.2016		New drawing																																			
2		05.08.2016		Field mounted rate totalisers added		OL		CB																															
<div style="display: flex; justify-content: space-between; align-items: center;"> <div style="text-align: center;">  <p><b>BEKA associates</b> Hitchin England company confidential, copyright reserved.</p> </div> <div style="text-align: right;"> <p>3. Installations shall be in accordance with ANSI/ISA RP 12.06.01 'Installation of Intrinsically Safe Systems for Hazardous (Classified) Locations' and the National Electrical Code ANSI/NFPA 70. Installations in Canada shall be in accordance with the Canadian Electrical Code C22.2.</p> <p>4. The associated protective barriers and galvanic isolators shall be NRTL approved and the manufacturers instructions shall be followed when installing this equipment. For installations in Canada the associated protective barriers and galvanic isolators shall be NRTL or CSA approved and the manufacturers installation drawings shall be followed when installing this equipment.</p> <p>5. One single channel or one two channel associated protective barrier or galvanic isolator with entity parameters complying with the following requirements:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 15%;">Uo</td> <td style="width: 35%;">equal or less than</td> <td style="width: 50%;">the lowest Ui of the NRTL or CSA approved apparatus installed in the loop.</td> </tr> <tr> <td>Io</td> <td>equal or less than</td> <td>the lowest li of the NRTL or CSA approved apparatus installed in the loop.</td> </tr> <tr> <td>Po</td> <td>equal or less than</td> <td>the lowest Pi of the NRTL or CSA approved apparatus installed in the loop.</td> </tr> <tr> <td>Lo</td> <td>equal or greater than</td> <td>the sum of the cable inductances and the internal inductances Li of each NRTL or CSA approved apparatus in the loop.</td> </tr> <tr> <td>Co</td> <td>equal or greater than</td> <td>the sum of the cable capacitance and the internal capacitance Ci of each NRTL or CSA approved apparatus in the loop.</td> </tr> </table> <p>6. Simple Apparatus as defined in the National Electrical Code ANSI/NFPA 70, or for installations in Canada by the Canadian Electrical Code C22.2 OR:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 15%;">Ui</td> <td style="width: 35%;">equal or greater than</td> <td style="width: 50%;">the highest Uo of the NRTL or CSA approved apparatus powering the loop.</td> </tr> <tr> <td>li</td> <td>equal or greater than</td> <td>the highest Io of the NRTL or CSA approved apparatus powering the loop.</td> </tr> <tr> <td>Pi</td> <td>equal or greater than</td> <td>the highest Po of the NRTL or CSA approved apparatus powering the loop.</td> </tr> <tr> <td>Lo</td> <td>of the NRTL or CSA approved apparatus powering the loop equal or greater than</td> <td>the sum of the cable inductances and the internal inductances Li of each NRTL or CSA approved apparatus in the loop.</td> </tr> <tr> <td>Co</td> <td>of the NRTL or CSA approved apparatus powering the loop equal or greater than</td> <td>the sum of the cable capacitances and the internal capacitances Ci of each NRTL or CSA approved apparatus in the loop.</td> </tr> </table> </div> </div>										Uo	equal or less than	the lowest Ui of the NRTL or CSA approved apparatus installed in the loop.	Io	equal or less than	the lowest li of the NRTL or CSA approved apparatus installed in the loop.	Po	equal or less than	the lowest Pi of the NRTL or CSA approved apparatus installed in the loop.	Lo	equal or greater than	the sum of the cable inductances and the internal inductances Li of each NRTL or CSA approved apparatus in the loop.	Co	equal or greater than	the sum of the cable capacitance and the internal capacitance Ci of each NRTL or CSA approved apparatus in the loop.	Ui	equal or greater than	the highest Uo of the NRTL or CSA approved apparatus powering the loop.	li	equal or greater than	the highest Io of the NRTL or CSA approved apparatus powering the loop.	Pi	equal or greater than	the highest Po of the NRTL or CSA approved apparatus powering the loop.	Lo	of the NRTL or CSA approved apparatus powering the loop equal or greater than	the sum of the cable inductances and the internal inductances Li of each NRTL or CSA approved apparatus in the loop.	Co	of the NRTL or CSA approved apparatus powering the loop equal or greater than	the sum of the cable capacitances and the internal capacitances Ci of each NRTL or CSA approved apparatus in the loop.
Uo	equal or less than	the lowest Ui of the NRTL or CSA approved apparatus installed in the loop.																																					
Io	equal or less than	the lowest li of the NRTL or CSA approved apparatus installed in the loop.																																					
Po	equal or less than	the lowest Pi of the NRTL or CSA approved apparatus installed in the loop.																																					
Lo	equal or greater than	the sum of the cable inductances and the internal inductances Li of each NRTL or CSA approved apparatus in the loop.																																					
Co	equal or greater than	the sum of the cable capacitance and the internal capacitance Ci of each NRTL or CSA approved apparatus in the loop.																																					
Ui	equal or greater than	the highest Uo of the NRTL or CSA approved apparatus powering the loop.																																					
li	equal or greater than	the highest Io of the NRTL or CSA approved apparatus powering the loop.																																					
Pi	equal or greater than	the highest Po of the NRTL or CSA approved apparatus powering the loop.																																					
Lo	of the NRTL or CSA approved apparatus powering the loop equal or greater than	the sum of the cable inductances and the internal inductances Li of each NRTL or CSA approved apparatus in the loop.																																					
Co	of the NRTL or CSA approved apparatus powering the loop equal or greater than	the sum of the cable capacitances and the internal capacitances Ci of each NRTL or CSA approved apparatus in the loop.																																					
Title						Drawn		Checked		Scale																													
ETL Intrinsically Safe Control Drawing for 'E' and 'G' series externally powered rate totalisers.						SQ		OL		—																													
						Drawing No.		Sheet 4 of 6		C1330-52																													


Iss.	Date	Modification	Ckd.	Appd.	 Hitchin company confidential, copyright reserved.	Iss.	Date	Modification	Ckd.	Appd.	<p>7. The unclassified location equipment shall not use or generate more than 250V rms or 250V dc.</p> <p>8. Safety parameters</p> <p>DC Power terminals 1 &amp; 2</p> <table> <tr> <td>Ui</td><td>=</td><td>28V</td> <td>Uo</td><td>=</td><td>0</td> </tr> <tr> <td>Ii</td><td>=</td><td>200mA</td> <td>Io</td><td>=</td><td>0</td> </tr> <tr> <td>Pi</td><td>=</td><td>0.84W</td> <td></td><td></td><td></td> </tr> <tr> <td>Ci</td><td>=</td><td>2nF</td> <td></td><td></td><td></td> </tr> <tr> <td>Li</td><td>=</td><td>4μH</td> <td></td><td></td><td></td> </tr> </table> <p>Terminals 4,5,6 (input A for models in notes 6 and 7), terminals 8,9,10 (input b for models in note 7).</p> <table> <tr> <td>Ui</td><td>=</td><td>28V</td> <td>Uo</td><td>=</td><td>1.1V</td> </tr> <tr> <td>Ii</td><td>=</td><td>200mA</td> <td>Io</td><td>=</td><td>0.5mA</td> </tr> <tr> <td>Pi</td><td>=</td><td>0.84W</td> <td>Po</td><td>=</td><td>0.2mW</td> </tr> <tr> <td>Ci</td><td>=</td><td>2nF</td> <td></td><td></td><td></td> </tr> <tr> <td>Li</td><td>=</td><td>4μH</td> <td></td><td></td><td></td> </tr> </table> <p>Optional pulse output terminals P1 &amp; P2</p> <table> <tr> <td>Ui</td><td>=</td><td>28V</td> <td>Uo</td><td>=</td><td>0</td> </tr> <tr> <td>Ii</td><td>=</td><td>200mA</td> <td>Io</td><td>=</td><td>0</td> </tr> <tr> <td>Pi</td><td>=</td><td>0.84W</td> <td></td><td></td><td></td> </tr> <tr> <td>Ci</td><td>=</td><td>0</td> <td></td><td></td><td></td> </tr> <tr> <td>Li</td><td>=</td><td>0</td> <td></td><td></td><td></td> </tr> </table> <p>Optional alarm output terminals A1, A2, A3 and A4</p> <table> <tr> <td>Ui</td><td>=</td><td>28V</td> <td>Uo</td><td>=</td><td>1.47V</td> </tr> <tr> <td>Ii</td><td>=</td><td>200mA</td> <td>Io</td><td>=</td><td>1μA</td> </tr> <tr> <td>Pi</td><td>=</td><td>0.84W</td> <td>Po</td><td>=</td><td>2μW</td> </tr> <tr> <td>Ci</td><td>=</td><td>22nF</td> <td></td><td></td><td></td> </tr> <tr> <td>Li</td><td>=</td><td>4μH</td> <td></td><td></td><td></td> </tr> </table> <p>Terminals RS1-RS2, (optional reset input)</p> <table> <tr> <td>Ui</td><td>=</td><td>28V</td> <td>Uo</td><td>=</td><td>3.8V</td> </tr> <tr> <td>Ii</td><td>=</td><td>200mA</td> <td>Io</td><td>=</td><td>1mA</td> </tr> <tr> <td>Pi</td><td>=</td><td>0.84W</td> <td>Po</td><td>=</td><td>1mW</td> </tr> <tr> <td>Ci</td><td>=</td><td>0</td> <td></td><td></td><td></td> </tr> <tr> <td>Li</td><td>=</td><td>0</td> <td></td><td></td><td></td> </tr> </table> <p>Terminal 3,4,5,6 (input A for models in notes 6 and 7), terminals 7,8,9,10 (input b for models in note 7).</p> <table> <tr> <td>Ui</td><td>=</td><td>14V</td> <td>Uo</td><td>=</td><td>10.5V</td> </tr> <tr> <td>Ii</td><td>=</td><td>200mA</td> <td>Io</td><td>=</td><td>9.2mA</td> </tr> <tr> <td>Pi</td><td>=</td><td>0.7W</td> <td>Po</td><td>=</td><td>24mW</td> </tr> <tr> <td>Ci</td><td>=</td><td>2nF</td> <td></td><td></td><td></td> </tr> <tr> <td>Li</td><td>=</td><td>4μH</td> <td></td><td></td><td></td> </tr> </table> <p>Optional 4-20mA output terminals C1, C2, C3 and C4</p> <table> <tr> <td>Ui</td><td>=</td><td>28V</td> <td>Uo</td><td>=</td><td>0</td> </tr> <tr> <td>Ii</td><td>=</td><td>200mA</td> <td>Io</td><td>=</td><td>0</td> </tr> <tr> <td>Pi</td><td>=</td><td>0.84W</td> <td></td><td></td><td></td> </tr> <tr> <td>Ci</td><td>=</td><td>2.2nF</td> <td></td><td></td><td></td> </tr> <tr> <td>Li</td><td>=</td><td>4μH</td> <td></td><td></td><td></td> </tr> </table> <p>9. When installed purely as intrinsically safe equipment in division 1, division 2, zone 0, zone 1 or zone 2, the ambient temperature range of the BA317E-SS, BA337E-SS, BA367E-SS, BA377E-SS, BA314G, BA334G, BA364G, BA374G and BA384G is: -40°C ≤ Ta ≤ +70°C.</p>	Ui	=	28V	Uo	=	0	Ii	=	200mA	Io	=	0	Pi	=	0.84W				Ci	=	2nF				Li	=	4μH				Ui	=	28V	Uo	=	1.1V	Ii	=	200mA	Io	=	0.5mA	Pi	=	0.84W	Po	=	0.2mW	Ci	=	2nF				Li	=	4μH				Ui	=	28V	Uo	=	0	Ii	=	200mA	Io	=	0	Pi	=	0.84W				Ci	=	0				Li	=	0				Ui	=	28V	Uo	=	1.47V	Ii	=	200mA	Io	=	1μA	Pi	=	0.84W	Po	=	2μW	Ci	=	22nF				Li	=	4μH				Ui	=	28V	Uo	=	3.8V	Ii	=	200mA	Io	=	1mA	Pi	=	0.84W	Po	=	1mW	Ci	=	0				Li	=	0				Ui	=	14V	Uo	=	10.5V	Ii	=	200mA	Io	=	9.2mA	Pi	=	0.7W	Po	=	24mW	Ci	=	2nF				Li	=	4μH				Ui	=	28V	Uo	=	0	Ii	=	200mA	Io	=	0	Pi	=	0.84W				Ci	=	2.2nF				Li	=	4μH			
												Ui	=	28V	Uo	=	0																																																																																																																																																																																																												
Ii	=	200mA	Io	=	0																																																																																																																																																																																																																								
Pi	=	0.84W																																																																																																																																																																																																																											
Ci	=	2nF																																																																																																																																																																																																																											
Li	=	4μH																																																																																																																																																																																																																											
Ui	=	28V	Uo	=	1.1V																																																																																																																																																																																																																								
Ii	=	200mA	Io	=	0.5mA																																																																																																																																																																																																																								
Pi	=	0.84W	Po	=	0.2mW																																																																																																																																																																																																																								
Ci	=	2nF																																																																																																																																																																																																																											
Li	=	4μH																																																																																																																																																																																																																											
Ui	=	28V	Uo	=	0																																																																																																																																																																																																																								
Ii	=	200mA	Io	=	0																																																																																																																																																																																																																								
Pi	=	0.84W																																																																																																																																																																																																																											
Ci	=	0																																																																																																																																																																																																																											
Li	=	0																																																																																																																																																																																																																											
Ui	=	28V	Uo	=	1.47V																																																																																																																																																																																																																								
Ii	=	200mA	Io	=	1μA																																																																																																																																																																																																																								
Pi	=	0.84W	Po	=	2μW																																																																																																																																																																																																																								
Ci	=	22nF																																																																																																																																																																																																																											
Li	=	4μH																																																																																																																																																																																																																											
Ui	=	28V	Uo	=	3.8V																																																																																																																																																																																																																								
Ii	=	200mA	Io	=	1mA																																																																																																																																																																																																																								
Pi	=	0.84W	Po	=	1mW																																																																																																																																																																																																																								
Ci	=	0																																																																																																																																																																																																																											
Li	=	0																																																																																																																																																																																																																											
Ui	=	14V	Uo	=	10.5V																																																																																																																																																																																																																								
Ii	=	200mA	Io	=	9.2mA																																																																																																																																																																																																																								
Pi	=	0.7W	Po	=	24mW																																																																																																																																																																																																																								
Ci	=	2nF																																																																																																																																																																																																																											
Li	=	4μH																																																																																																																																																																																																																											
Ui	=	28V	Uo	=	0																																																																																																																																																																																																																								
Ii	=	200mA	Io	=	0																																																																																																																																																																																																																								
Pi	=	0.84W																																																																																																																																																																																																																											
Ci	=	2.2nF																																																																																																																																																																																																																											
Li	=	4μH																																																																																																																																																																																																																											
1	05.05.2016	New drawing	OL	CB	3.3	2	05.08.2016	Field mounted rate totalisers added	OL																																																																																																																																																																																																																				

Title		Drawn	Checked	Scale
ETL Intrinsically Safe Control Drawing for 'E' and 'G' series externally powered rate totalisers.		SQ	OL	—
		Drawing No. CI330-52		
		Sheet 5 of 6		










Iss.	Date	Modification	Ckd.	Appd.	Notes																																																												
1	05.05.2016	New drawing			<p>1. 1 and 2 input externally powered rate totalisers with model numbers and coding as shown in the following tables.</p> <p style="text-align: center;"><b>NE PANEL MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking (see note 8)</th> <th>Ambient Temp. (see note 9)</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 1 input counter 1 input timer</td> <td>BA317NE BA337NE BA367NE BA377NE</td> <td>Class I Division 2 Groups A, B, C &amp; D T5 Class II Division 2 Groups F &amp; G Class III Division 2</td> <td>Zone 2 AEx nA ic IIC T5 Gc Zone 22 AEx ic tc IIIC T80°C Dc</td> <td>-40°C to +60°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>E PANEL MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp.</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 2 input rate totaliser 1 input counter 2 input counter 1 input timer 2 input timer</td> <td>BA317E BA337E BA338E BA388E BA367E BA368E BA377E BA378E</td> <td>Class I Division 2 Groups A, B, C &amp; D T5 Class II Division 2 Groups F &amp; G Class III Division 2</td> <td>None</td> <td>-40°C to +70°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>E-SS PANEL MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp.</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 1 input counter 1 input timer</td> <td>BA317E-SS BA337E-SS BA367E-SS BA377E-SS</td> <td>Class I Division 2 Groups A, B, C &amp; D T5 Class II Division 2 Groups F &amp; G Class III Division 2</td> <td>None</td> <td>-40°C to +70°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>NG FIELD MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking (see note 8)</th> <th>Ambient Temp. (see note 9)</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer</td> <td>BA314NG BA334NG BA384NG BA364NG BA374NG</td> <td>Class I Division 2 Groups A, B, C &amp; D T5 Class II Division 2 Groups F &amp; G Class III Division 2</td> <td>Zone 2 AEx nA ic IIC T5 Gc Zone 22 AEx ic tc IIIC T80°C Dc</td> <td>-40°C to +60°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>G FIELD MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp.</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer</td> <td>BA314G BA334G BA384G BA364G BA374G</td> <td>Class I Division 2 Groups A, B, C &amp; D T5 Class II Division 2 Groups F &amp; G Class III Division 2</td> <td>None</td> <td>-40°C to +70°C</td> </tr> </tbody> </table> <p style="text-align: center;"><b>E FIELD MOUNTING INSTRUMENTS</b></p> <table border="1"> <thead> <tr> <th>Type</th> <th>Model Nos.</th> <th>Division Marking</th> <th>Zonal Marking</th> <th>Ambient Temp.</th> </tr> </thead> <tbody> <tr> <td>1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer</td> <td>BA314E BA334E BA384E BA364E BA374E</td> <td>Class I Division 2 Groups A, B, C &amp; D T5 Class II Division 2 Groups F &amp; G Class III Division 2</td> <td>None</td> <td>-40°C to +70°C</td> </tr> </tbody> </table>	Type	Model Nos.	Division Marking	Zonal Marking (see note 8)	Ambient Temp. (see note 9)	1 input tachometer 1 input rate totaliser 1 input counter 1 input timer	BA317NE BA337NE BA367NE BA377NE	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	Zone 2 AEx nA ic IIC T5 Gc Zone 22 AEx ic tc IIIC T80°C Dc	-40°C to +60°C	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.	1 input tachometer 1 input rate totaliser 2 input rate totaliser 1 input counter 2 input counter 1 input timer 2 input timer	BA317E BA337E BA338E BA388E BA367E BA368E BA377E BA378E	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.	1 input tachometer 1 input rate totaliser 1 input counter 1 input timer	BA317E-SS BA337E-SS BA367E-SS BA377E-SS	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C	Type	Model Nos.	Division Marking	Zonal Marking (see note 8)	Ambient Temp. (see note 9)	1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314NG BA334NG BA384NG BA364NG BA374NG	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	Zone 2 AEx nA ic IIC T5 Gc Zone 22 AEx ic tc IIIC T80°C Dc	-40°C to +60°C	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.	1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314G BA334G BA384G BA364G BA374G	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C	Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.	1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314E BA334E BA384E BA364E BA374E	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C
Type	Model Nos.	Division Marking	Zonal Marking (see note 8)	Ambient Temp. (see note 9)																																																													
1 input tachometer 1 input rate totaliser 1 input counter 1 input timer	BA317NE BA337NE BA367NE BA377NE	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	Zone 2 AEx nA ic IIC T5 Gc Zone 22 AEx ic tc IIIC T80°C Dc	-40°C to +60°C																																																													
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.																																																													
1 input tachometer 1 input rate totaliser 2 input rate totaliser 1 input counter 2 input counter 1 input timer 2 input timer	BA317E BA337E BA338E BA388E BA367E BA368E BA377E BA378E	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C																																																													
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.																																																													
1 input tachometer 1 input rate totaliser 1 input counter 1 input timer	BA317E-SS BA337E-SS BA367E-SS BA377E-SS	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C																																																													
Type	Model Nos.	Division Marking	Zonal Marking (see note 8)	Ambient Temp. (see note 9)																																																													
1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314NG BA334NG BA384NG BA364NG BA374NG	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	Zone 2 AEx nA ic IIC T5 Gc Zone 22 AEx ic tc IIIC T80°C Dc	-40°C to +60°C																																																													
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.																																																													
1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314G BA334G BA384G BA364G BA374G	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C																																																													
Type	Model Nos.	Division Marking	Zonal Marking	Ambient Temp.																																																													
1 input tachometer 1 input rate totaliser 2 input rate totaliser 2 input counter 2 input timer	BA314E BA334E BA384E BA364E BA374E	Class I Division 2 Groups A, B, C & D T5 Class II Division 2 Groups F & G Class III Division 2	None	-40°C to +70°C																																																													
2	05.08.2016	Field mounted rate totalisers added																																																															


Iss.	Date	Modification	Ckd.	Appd.	Title	Drawn	Checked	Scale
						SQ	OL	-
1	05.05.2016	New drawing			<p style="text-align: center;">ETL Nonincendive Control Drawing for 'E' and 'G' series externally powered rate totalisers.</p>	Drawing No. <b>C1330-53</b>		
2	05.08.2016	Field mounted rate totalisers added				Sheet 3 of 6		

File No 330-53s03.dwg 05.08.16

Iss.	Date	Modification	Ckd.	Appd.		Iss.	Date	Modification	Ckd.	Appd.	
1	15.06.2016	New drawing	QL	CB		2					
2	05.08.2016	Field mounted rate totalisers added	OL	2.2							
Title ETL Nonincendive Control Drawing for 'E' and 'G' series externally powered rate totalisers.						2. Terminals 7, 8, 9 and 10 only exist on 2 input instruments.					
						3. Nonincendive field wiring installations shall be in accordance with the National Electrical Code ANSI/NFPA 70. The Nonincendive Field Wiring concept allows interconnection of Nonincendive Field Apparatus with Associated Nonincendive Field Wiring Apparatus using any of the wiring methods permitted for unclassified locations. Installations in Canada shall be in accordance with the Canadian Electrical Code C22.2.					
						4. Classified location equipment shall be NRTL Approved Nonincendive Field Wiring Apparatus or simple apparatus as defined in ANSI/NFPA70. For Canadian installations classified location equipment shall be NRTL or CSA Approved Nonincendive Field Wiring Apparatus.					
					5. Simple Apparatus as defined in the National Electrical Code ANSI/NFPA 70, 3r for installations in Canada by the Canadian Electrical Code C22.2 or as defined in note 2.						
					6. The unclassified location equipment shall not use or generate more than 250V rms or 250V dc.						
Title ETL Nonincendive Control Drawing for 'E' and 'G' series externally powered rate totalisers.					Drawn	Checked	Scale	Drawing No. <b>C1330-53</b> Sheet 4 of 6			
					SQ	OL	-				

Iss.	Date	Modification	Ckd.	Appd.
1	15.06.2016	New drawing		
2	05.08.2016	Field mounted rate totalisers added		

 <p><b>BEKA associates</b> Hitchin England company confidential, copyright reserved.</p>				
<p><b>7. Safety parameters</b></p> <div style="display: flex; justify-content: space-between;"> <div style="width: 48%;"> <p><b>DC Power terminals 1 &amp; 2</b></p> <p> <math>U_i = 30V</math>  <math>I_i = 100mA</math> </p> <p>Terminals 4,5,6 (input A for models in notes 5 and 6), terminals 8,9,10 (input b for models in note 6).</p> <p> <math>U_i = 30V</math>  <math>U_o = 1.1V</math>  <math>I_o = 0.5mA</math> </p> <p><b>Optional pulse output terminals P1 &amp; P2</b></p> <p> <math>U_i = 30V</math>  <math>I_i = 100mA</math>  <math>U_o = 0</math>  <math>I_o = 0</math> </p> <p><b>Optional alarm output terminals A1, A2, A3 and A4</b></p> <p> <math>U_i = 30V</math>  <math>I_i = 200mA</math>  <math>U_o = 1.47V</math>  <math>I_o = 1\mu A</math> </p> </div> <div style="width: 48%;"> <p><b>Terminals RS1-RS2, (optional reset input)</b></p> <p> <math>U_i = 30V</math>  <math>U_o = 3.8V</math>  <math>I_o = 1mA</math> </p> <p>Terminal 3,4,5,6 (for models in notes 5 and 6), terminals 7,8,9,10 (input b with terminals for models in note 6).</p> <p> <math>U_i = 15V</math>  <math>U_o = 10.5V</math>  <math>I_o = 9.2mA</math> </p> <p><b>Optional 4-20mA output terminals C1, C2, C3 and C4</b></p> <p> <math>U_i = 30V</math>  <math>U_o = 0</math>  <math>I_o = 0</math> </p> </div> </div>				
<p><b>8. The 'AEx ic' in codes refers to instrument push button contacts which are nonincendive.</b></p>				
<p><b>9. When installed purely as non-incendive equipment, the ambient temperature range of the BA317NE, BA337NE, BA367NE, BA377NE, BA314NG, BA334NG, BA364NG, BA374NG, and BA384NG is: <math>-40^{\circ}C \leq T_a \leq +70^{\circ}C</math>.</b></p>				

<p><b>Title</b></p> <p>ETL Nonincendive Control Drawing for 'E' and 'G' series externally powered rate totalisers.</p>		<p><b>Drawn</b> SQ</p>	<p><b>Checked</b> OL</p>	<p><b>Scale</b> —</p>
		<p><b>Drawing No.</b> Sheet 5 of 6 <b>CI330-53</b></p>		

File No 330-53s05.dwg 05.08.16

Iss.	Date	Modification	Ckd.	Appd.	<p><b>BEKA associates</b> Hitchin England company confidential, copyright reserved.</p>	Iss.	Date	Modification	Ckd.	Appd.	
1	15.06 2016	New drawing	OL	CB		1					
2	05.08 2016	Field mounted rate totalisers added	OL	B.B		2					

**10. CAUTION** The BA317E, BA318E, BA337E, BA338E, BA367E, BA368E, BA377E, BA378E and the BA388E Externally Powered rate totaliser enclosures may carry the following potential electrostatic warning:

**WARNING**  
Potential electrostatic charging hazard clean only with a damp cloth

**AVERTISSEMENT**  
Risque potentiel de charge  
électrostatique Nettoyer uniquement  
avec un chiffon humide

Alternatively, the enclosures may be manufactured from a conducting plastic per Article 250 of the National Electrical Code.

**11.** When mounting the BA317E, BA318E, BA337E, BA338E, BA367E, BA368E, BA377E, BA378E, BA388E, BA317E-SS, BA337E-SS, BA367E-SS, BA377E-SS, BA317NE, BA337NE, BA367NE & BA377NE panel mounting Externally Powered Rate Totalisers in an enclosure to maintain Type 4 front panel rating:

Minimum panel thickness should be 2mm (0.08inches) Steel  
3mm (0.12inches) Aluminium

Outside panel finish should be smooth, free from particles, inclusions, runs or build-ups around cut-out.

Panel cut-out for BA317E, BA337E, BA367E, and BA377E shall be:  
90.0 x 43.5mm -0.0 +0.5mm (3.54 x 1.71 inches -0.00 +0.02)

Two panel mounting clips are required for BA317E, BA337E, BA367E, and BA377E and each shall be tightened to between: 20 & 22cNm (1.77 to 1.95inLb)

Panel cut-out for BA318E, BA338E, BA368E, BA378E, and BA388E shall be:  
136.0 x 66.2mm -0.0 +0.5mm (5.35 x 2.60 inches -0.00 +0.02)

Four panel mounting clips are required for BA318E, BA338E, BA368E, BA378E, and BA388E and each shall be tightened to between: 20 & 22cNm (1.77 to 1.95inLb)

Panel cut-out for BA317E-SS, BA337E-SS, BA367E-SS, BA377E-SS, BA317NE, BA337NE, BA367NE & BA377NE shall be:  
(92.0mm -0.0 +0.8) x (45.0mm -0.0 +0.6)  
(3.62 inches -0.00 +0.03) x (1.77 inches - 0.00 +0.02)

Four panel mounting clips are required for BA317E-SS, BA337E-SS, BA367E-SS, BA377E-SS, BA317NE, BA337NE, BA367NE & BA377NE and each shall be tightened to at least: 22cNm (1.95inLb)

Title ETL Nonincendive Control Drawing for 'E' and 'G' series externally powered rate totalisers.		Drawn SQ	Checked OL	Scale —
		Drawing No. Sheet 6 of 6		

CI330-53

## APPENDIX 4

### BA364E Two input Counter

The BA364E Counter is functionally identical to the BA364G Counter described in the main sections of this manual, but differs in mechanical construction, certification and factory fitted options.

All BA364E Counters are fitted with:

A Green internally powered display backlight

Dual galvanically isolated alarms

An isolated 4/20mA current sink output

These are only available as factory fitted options for the BA364G Counter.

#### A4.1 Mechanical construction

The BA364E is housed in a robust GRP IP66 enclosure with a separate terminal compartment. Section A4.5 of this appendix describes the enclosure and installation procedure.

#### A4.2 Certification

The BA364E has the same ATEX, IECEx and ETL intrinsic safety certification as the BA364G, but the **BA364E does not have ATEX and IECEx dust certification.**

The safety parameters and certification numbers specified in this manual for the BA364G Counter also apply to the BA364E Counter. Therefore all of the systems described for the BA364G in the main section of this manual may also be used for the BA364E.

#### A4.3 Location

The BA364E Counter is housed in a robust IP66 glass reinforced polyester (GRP) enclosure incorporating an armoured glass window and stainless steel fittings. It is suitable for exterior mounting in most industrial installations, including off-shore and waste water treatment sites. The Counter should be positioned where the display is not in continuous direct sunlight.

The field terminals and the two mounting holes are located in a separate compartment with a sealed cover allowing the instrument to be installed without exposing the display assembly.

The enclosure is fitted with a bonding plate to ensure electrical continuity between the three conduit / cable entries.

### A4.4 BA364E Accessories

#### A4.4.1 Units of measurement & instrument identification.

The BA364E is fitted with a blank escutcheon around the liquid crystal display. This can be supplied printed with any units of measurement and tag information specified at the time of ordering. Alternatively, the information may be added on-site via an embossed strip, dry transfer or a permanent marker.

To gain access to the escutcheon remove the terminal cover by unscrewing the two 'A' screws which will reveal two concealed 'D' screws. Remove the push buttons by unscrewing the two 'C' screws and un-plug the five way connector. Finally, unscrew all four 'D' screws and carefully lift off the front of the instrument. The location of all the screws is shown in Fig A4.1.

Add the required legend to the display escutcheon, or stick a new pre-printed self-adhesive escutcheon, which is available from BEKA associates, on top of the existing escutcheon. Do not remove the original escutcheon.

The BA364E can also be supplied with a blank or custom laser engraved stainless steel plate secured by two screws to the front of the instrument enclosure. This plate can typically accommodate:

1 row of 9 alphanumeric characters 10mm high

or 1 row of 11 alphanumeric characters 7mm high

or 2 rows of 18 alphanumeric characters 5mm high.

#### A4.4.2 Pipe mounting kits


The BA364E Counter is surface mounting, but may be pipe mounted using the BA392D or the BA393 pipe mounting kit.

### A4.5 Installation Procedure

Fig A4.1 illustrates the instrument installation procedure.


- Remove the instrument terminal cover by unscrewing the two captive 'A' screws.
- Mount the instrument on a flat surface and secure with screws or bolts through the two 'B' holes. Alternatively secure to a vertical or horizontal pipe using a BA392D or BA393 pipe mounting kit.
- Remove the temporary hole plug and install an appropriate IP rated cable gland or conduit fitting. If more than one entry is required, one or both of the IP66 stopping plugs may be replaced with an appropriate IP rated cable gland or conduit fitting.
- Connect the field wiring to the terminals as shown in Fig A4.2.
- Replace the instrument terminal cover and evenly tighten the two 'A' screws.

If the BA364E is not bolted to an earthed post or structure, the earth terminal should be connected to the plant potential equalising conductor.




#### Step A

Remove the terminal cover by unscrewing the two 'A' screws



#### Step B

Secure the instrument to a flat surface with M6 screws through the two 'B' holes. Alternatively use a pipe mounting kit.



#### Step C and D

Remove the temporary hole plug and install an appropriate IP rated cable gland or conduit fitting and terminate field wiring. Finally replace the terminal cover and tighten the two 'A' screws.

Fig A4.1 BA364E installation procedure





Fig A4.2 Dimensions and terminal connections

### A4.6 EMC

The BA364E complies with the requirements of the European EMC Directive and the UK Statutory Requirements. For specified immunity all wiring should be in screened twisted pairs, with the screens earthed at one point in the safe area.